

FRONT AXLE & FRONT SUSPENSION


SECTION **FA**

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CONTENTS

PRECAUTIONS AND PREPARATION	2	FRONT AXLE	8
Precautions	2	Wheel Hub and Knuckle.....	8
Special Service Tools	2	Drive Shaft.....	12
Commercial Service Tools	3	FRONT SUSPENSION	20
FRONT SUSPENSION SYSTEM	4	Coil Spring and Strut Assembly.....	21
ON-VEHICLE SERVICE	5	Stabilizer Bar	22
Front Axle and Front Suspension Parts	5	Transverse Link and Lower Ball Joint	23
Front Wheel Bearing.....	6	SERVICE DATA AND SPECIFICATIONS (SDS)	25
Front Wheel Alignment	6	General Specifications.....	25
Drive Shaft.....	7	Inspection and Adjustment	26

PRECAUTIONS AND PREPARATION



Precautions

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
- *: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- After installing removed suspension parts, check wheel alignment and adjust if necessary.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.





Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
HT72520000 (J25730-A) Ball joint remover	<p>NT546</p>
HT71780000 (—) Spring compressor	<p>NT144</p>
ST35652000 (—) Strut attachment	<p>NT145</p>
KV38106700 (J34296) KV38106800 (J34297) Differential side oil seal protector	<p>NT147</p>

PRECAUTIONS AND PREPARATION

Commercial Service Tools

Tool name	Description
Front wheel hub drift	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Removing wheel hub</p> <p>a: 42 mm (1.65 in) dia. b: 33 mm (1.30 in) dia.</p> </div> </div> <p style="margin-top: 10px;">NT065</p>
Front wheel bearing outer race drift	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Removing and installing wheel bearing outer race</p> <p>a: 76 mm (2.99 in) dia. b: 72 mm (2.83 in) dia.</p> </div> </div> <p style="margin-top: 10px;">NT115</p>
Grease seal drift	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Installing outer grease seal</p> <p>a: 81 mm (3.19 in) dia. b: 76 mm (2.99 in) dia.</p> </div> </div> <p style="margin-top: 10px;">NT115</p>
<p>① Flare nut crows foot</p> <p>② Torque wrench</p>	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Removing and installing brake piping</p> <p>a: 10 mm (0.39 in)</p> </div> </div> <p style="margin-top: 10px;">NT360</p>

CI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

FRONT SUSPENSION SYSTEM

SEC. 391-400-401

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
 * Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.




: N·m (kg·m, ft·lb)

SFA703B

- ① Suspension member
- ② Stabilizer bar
- ③ Drive shaft

- ④ Rebound stopper
- ⑤ Coil spring
- ⑥ Strut assembly

- ⑦ Knuckle
- ⑧ Transverse link




Front Axle and Front Suspension Parts

Check front axle and front suspension parts for excessive play, cracks, wear or other damage.


- Shake each front wheel to check for excessive play.
- Make sure that cotter pins are inserted.
- Retighten all axle and suspension nuts and bolts to the specified torque.

Tightening torque:

Refer to FRONT SUSPENSION (FA-20).




- Check strut (shock absorber) for oil leakage or other damage.
- Check suspension ball joint for grease leakage and ball joint dust cover for cracks or other damage. If ball joint dust cover is cracked or damaged, replace transverse link.




- Check spring height from top of wheelarch to ground using the following procedure.

- Park vehicle on a level surface with vehicle unladen* .
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Check tires for proper inflation and wear (tread wear indicator must not be showing).
- Bounce vehicle up and down several times and measure dimensions Hf and Hr. Refer to SDS, FA-25. Spring height is not adjustable. If out of specification, check for worn springs or suspension parts.




- Check suspension ball joint end play.
- Jack up front of vehicle and set the stands.
 - Clamp dial indicator onto transverse link and place indicator tip on lower edge of brake caliper.
 - Make sure front wheels are straight and brake pedal is depressed.
 - Place a pry bar between transverse link and inner rim of road wheel.
 - While raising and releasing pry bar, observe maximum dial indicator value. **Vertical end play: 0 mm (0 in)**
If ball joint vertical end play exists, remove transverse link and recheck the ball joint. Refer to FA-23.



Front Wheel Bearing

- Check that wheel bearings operate smoothly.
- Check axial end play.
Axial end play: 0.05 mm (0.0020 in) or less
- If out of specification or wheel bearing does not turn smoothly, replace wheel bearing assembly.
Refer to FRONT AXLE — Wheel Hub and Knuckle (FA-8).



Front Wheel Alignment

Before checking front wheel alignment, be sure to make a preliminary inspection (Unladen*).

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.


PRELIMINARY INSPECTION

1. Check tires for wear and improper inflation.
2. Check wheel runout.

Wheel runout:

Refer to SDS (FA-26).

3. Check front wheel bearings for looseness.
4. Check front suspension for looseness.
5. Check steering linkage for looseness.
6. Check that struts work properly.
7. Check vehicle posture (Unladen).



CAMBER, CASTER AND KINGPIN INCLINATION


Camber, caster and kingpin inclination are preset at factory and cannot be adjusted.

1. Measure camber, caster and kingpin inclination of both right and left wheels with a suitable alignment gauge.

Camber, Caster and Kingpin inclination:

Refer to SDS (FA-26).

2. If camber, caster or kingpin inclination is not within specification, inspect front suspension parts. Replace damaged or worn out parts.



TOE-IN


Measure toe-in using the following procedure.

WARNING:

- **Always perform the following procedure on a flat surface.**
 - **Make sure that no person is in front of the vehicle before pushing it.**
1. Bounce front of vehicle up and down to stabilize the posture.
 2. Push the vehicle straight ahead about 5 m (16 ft).
 3. Put a mark on base line of tread (rear side) of both tires at the same height as hub center. These are measuring points.

ON-VEHICLE SERVICE

Front Wheel Alignment (Cont'd)




4. Measure distance "A" (rear tires).
5. Push the vehicle slowly ahead to rotate the wheels 180 degrees (1/2 turn).

If the wheels have rotated more than 180 degrees (1/2 turn), try the above procedure again from the beginning. Never push vehicle backward.

6. Measure distance "B" (front tires).

Total toe-in :

Refer to SDS, (FA-26).



7. Adjust toe-in by varying the length of steering tie-rods.

a. Loosen lock nuts.

b. Adjust toe-in by screwing tie-rods in and out.


Standard length "L":

Refer to ST section.

c. Tighten lock nuts to specified torque.

Lock nut tightening torque:

Refer to ST section.





FRONT WHEEL TURNING ANGLE

1. Set wheels in straight-ahead position. Then move vehicle forward until front wheels rest on turning radius gauge properly.
2. Rotate steering wheel all the way right and left; measure turning angle.

Do not hold the steering wheel on full lock for more than 15 seconds.

Wheel turning angle (Full turn): Refer to SDS (FA-26).




3. Check stopper bolt head to see whether it contacts stopper bracket at specified outside wheel angle. If not, adjust stopper bolt to contact stopper bracket at the correct angle.

Adjust protrusion of stopper bolt before placing stopper bolt cap.

Apply grease to face of stopper bracket that bolt touches.

Tighten stopper bolt lock nut.

Ⓜ: 54 - 72 N·m (5.5 - 7.3 kg-m, 40 - 53 ft-lb)



Drive Shaft

- Check for grease leakage or other damage.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

FRONT AXLE

SEC. 400



- | | | |
|---------------------|--------------------------|--------------------------|
| ① Drive shaft | ⑦ Wheel bearing assembly | ⑬ Wheel bearing lock nut |
| ② Inner grease seal | ⑧ Snap ring | ⑭ Cotter pin |
| ③ Snap ring | ⑨ Outer grease seal | ⑮ Disc rotor |
| ④ Knuckle | ⑩ Hub bolt | ⑯ Wheel nut |
| ⑤ Baffle plate | ⑪ Wheel hub | |
| ⑥ ABS sensor | ⑫ Plain washer | |



Wheel Hub and Knuckle

REMOVAL

CAUTION:

Before removing the front axle assembly, disconnect the ABS wheel sensor from the assembly. Then move it away from the front axle assembly area. Failure to do so may result in damage to the sensor wires and the sensor becoming inoperative.


1. Remove wheel bearing lock nut.
2. Remove brake caliper assembly and rotor.

Brake hose need not be disconnected from brake caliper. In this case, suspend caliper assembly with wire so as not to stretch brake hose.

Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.


FRONT AXLE

Wheel Hub and Knuckle (Cont'd)




3. Separate tie-rod from knuckle with Tool.

Install stud nut on stud bolt to prevent damage to stud bolt.




4. Separate drive shaft from knuckle by lightly tapping it. If it is hard to remove, use a puller.

Cover boots with shop towel so as not to damage them when removing drive shaft.




5. Remove strut lower mounting bolts.



6. Loosen lower ball joint tightening nut.

7. Separate knuckle from lower ball joint stud with Tool.

8. Remove knuckle from transverse link.



INSTALLATION

1. Install knuckle with wheel hub.

- Replace strut lower mounting nuts.

When installing knuckle to strut, be sure to hold bolts and tighten nuts.

: 140 - 159 N·m (14.3 - 16.2 kg-m, 103 - 117 ft-lb)

Before tightening, apply oil to threaded portion of drive shaft and both sides of plain washer.

2. Tighten wheel bearing lock nut.

: 235 - 314 N·m (24 - 32 kg-m, 174 - 231 ft-lb)

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA






EL

IDX

FRONT AXLE

Wheel Hub and Knuckle (Cont'd)

3. Check wheel bearing axial end play.
Axial end play:
0.05 mm (0.0020 in) or less.



DISASSEMBLY

CAUTION:

When removing wheel hub or wheel bearing from knuckle, replace wheel bearing assembly (outer race, inner races and grease seals) with a new one.

Wheel hub

Drive out hub with inner race (outside) from knuckle with a suitable tool.

Wheel bearing

When replacing wheel bearing, replace wheel bearing assembly (inner races and outer race).

1. Remove bearing inner race (outside), then remove outer grease seal.


2. Remove inner grease seal from knuckle.

3. Remove snap ring.

FRONT AXLE

Wheel Hub and Knuckle (Cont'd)

4. Press out bearing outer race.




INSPECTION

Wheel hub and knuckle

Check wheel hub and knuckle for cracks by using a magnetic exploration or dyeing test.

Snap ring

Check snap ring for wear or cracks. Replace if necessary.



ASSEMBLY

1. Install inner snap ring into groove of knuckle.
2. Press new wheel bearing assembly into knuckle.



Maximum load P:

29 kN (3 ton, 3.3 US ton, 3.0 Imp ton)

CAUTION:

- Do not press inner race of wheel bearing assembly.
- Do not apply oil or grease to mating surfaces of wheel bearing outer race and knuckle.

3. Install outer snap ring into groove of knuckle.
4. Pack grease seal lip with multi-purpose grease.



5. Install outer grease seal.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

FRONT AXLE

Wheel Hub and Knuckle (Cont'd)

6. Install inner grease seal.




7. Press wheel hub into knuckle.

Maximum load P:

49 kN (5 ton, 5.5 US ton, 4.9 Imp ton)

Be careful not to damage grease seal.




8. Check bearing operation.

- a. Add load P with press.

Load P:

49 kN (5 ton, 5.5 US ton, 4.9 Imp ton)

- b. Spin knuckle several turns in both directions.
- c. Make sure that wheel bearings operate smoothly.




Drive Shaft

REMOVAL


1. Remove wheel bearing lock nut.

Brake caliper need not be disconnected.

Do not twist or stretch brake hose when moving components.




2. Remove strut lower mounting bolts.
3. Remove brake hose clip.




FRONT AXLE

Drive Shaft (Cont'd)




4. Separate drive shaft from knuckle by slightly tapping it.
When removing drive shaft, cover boots with shop towel to prevent damage to them.

Refer to FRONT AXLE — Wheel Hub and Knuckle (FA-8).




5. Remove right drive shaft from transaxle.



6. Remove left drive shaft from transaxle.

—For M/T models—

- Pry off drive shaft from transaxle as shown at left.



—For A/T models—

- Insert screwdriver into transaxle opening for right drive shaft and strike with a hammer.

Be careful not to damage pinion mate shaft and side gear.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX



FRONT AXLE

Drive Shaft (Cont'd)

INSTALLATION

Transaxle side

1. Drive a new oil seal to transaxle. Refer to MT or AT section.
2. Set Tool along the inner circumference of oil seal.



3. Insert drive shaft into transaxle. Be sure to properly align the serrations and then withdraw Tool.
4. Push drive shaft, then press-fit circular clip on the drive shaft into circular clip groove of side gear.
5. After its insertion, try to pull the flange out of the slide joint by hand. If it pulls out, the circular clip is not properly meshed with the side gear.

Wheel side

- Install drive shaft into knuckle.
 - Tighten wheel bearing lock nut.
- Refer to FRONT AXLE — Wheel Hub and Knuckle (FA-8).

FRONT AXLE

Drive Shaft (Cont'd)


COMPONENTS

SEC. 391

Circular clip:

Circular clips should be properly meshed with differential side gear (transaxle side) and with joint assembly (wheel side). Make sure they will not come out.

Be careful not to damage boots. Use suitable protector or cloth during removal and installation.




: N·m (kg·m, ft·lb)

Transaxle side (DS90)

SFA602B

- | | | |
|-----------------------|--|----------------------------|
| ① Joint assembly | ⑩ Snap ring | ⑲ Snap ring |
| ② Boot | ⑪ Inner race | ⑳ Dust shield |
| ③ Boot band | ⑫ Cage | ㉑ Support bearing |
| ④ Circular clip | ⑬ Ball | ㉒ Support bearing retainer |
| ⑤ Drive shaft | ⑭ Snap ring | ㉓ Bracket |
| ⑥ Dynamic damper band | ⑮ Slide joint housing | ㉔ Snap ring |
| ⑦ Dynamic damper | ⑯ Dust shield | ㉕ Dust shield |
| ⑧ Boot | ⑰ Circular clip | |
| ⑨ Boot band | ⑱ Slide joint housing with extension shaft | |



SFA476

DISASSEMBLY

Transaxle side

1. Remove boot bands.
2. Put matchmarks on slide joint housing and inner race, before separating joint assembly.
3. Remove snap ring with a screwdriver, and pull out slide joint housing.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA


RA
BR
ST
RS

BT
HA

EL
IDX


FRONT AXLE

Drive Shaft (Cont'd)



4. Put matchmarks on inner race and drive shaft.
5. Remove snap ring, then remove ball cage, inner race and balls as a unit.
6. Draw out boot.

Cover drive shaft serrations with tape so as not to damage the boot.



Wheel side


CAUTION:

The joint on the wheel side cannot be disassembled.

1. Before separating joint assembly, put matchmarks on drive shaft and joint assembly.
2. Separate joint assembly with a suitable tool.


Be careful not to damage threads on drive shaft.

3. Remove boot bands.




Support bearing

1. Remove dust shield.



2. Remove snap ring.




3. Press support bearing assembly off of drive shaft.

FRONT AXLE

Drive Shaft (Cont'd)

4. Separate support bearing from retainer.



INSPECTION

Thoroughly clean all parts in cleaning solvent, and dry with compressed air. Check parts for evidence of deformation or other damage.

Drive shaft

Replace drive shaft if it is twisted or cracked.

Boot

Check boot for fatigue, cracks, or wear. Replace boot with new boot bands.

Joint assembly

Replace joint assembly if it is deformed or damaged.

Support bearing


Make sure wheel bearing rolls freely and is free from noise, cracks, pitting or wear.

Support bearing bracket

Check support bearing bracket for cracks with a magnetic exploration or dyeing test.

ASSEMBLY

- After drive shaft has been assembled, ensure that it moves smoothly over its entire range without binding.
- Use NISSAN GENUINE GREASE or equivalent after every overhaul.



Wheel side

1. Install boot and new small boot band on drive shaft.

Cover drive shaft serration with tape so as not to damage boot during installation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

FRONT AXLE


Drive Shaft (Cont'd)




- Set joint assembly onto drive shaft by lightly tapping it. Install joint assembly securely, ensuring marks which were made during disassembly are properly aligned.



- Pack drive shaft with specified amount of grease.
Specified amount of grease:
135 - 145 g (4.76 - 5.11 oz)
- Make sure that boot is properly installed on the drive shaft groove. Set boot so that it does not swell and deform when its length is "L₁".
Length "L₁":
96 - 98 mm (3.78 - 3.86 in)




- Lock new larger and smaller boot bands securely with a suitable tool.



Dynamic damper

- Use new damper band when reinstalling.
- Install dynamic damper from stationary-joint side while holding it securely.

		(Left side only)
Length	"A"	205 - 215 mm (8.07 - 8.46 in)
	"B"	50 mm (1.97 in)




Transaxle side


- Install boot and new small boot band on drive shaft.
Cover drive shaft serration with tape so as not to damage boot during installation.

FRONT AXLE


Drive Shaft (Cont'd)



2. Install ball cage, inner race and balls as a unit, making sure the marks which were made during disassembly are properly aligned.
3. Install new snap ring.




4. Pack drive shaft with specified amount of grease.
Specified amount of grease:
165 - 175 g (5.82 - 6.17 oz)
5. Install slide joint housing, then install new snap ring.
6. Make sure that boot is properly installed on the drive shaft groove.
Set boot so that it does not swell and deform when its length is " L_2 ".
Length " L_2 ": 97 - 99 mm (3.82 - 3.90 in)
7. Lock new larger and smaller boot bands securely with a suitable tool.




Support bearing

- Press bearing into retainer.



- Press drive shaft into bearing.



- Install snap ring.
- Install new dust shield.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL


IDX

FRONT SUSPENSION

SEC. 391-400-401

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

* Fuel, radiator coolant and engine oil full.
Spare tire, jack, hand tools and mats in designated positions.




- ① Spacer
- ② Strut mounting insulator
- ③ Strut mounting insulator bracket
- ④ Strut mounting bearing
- ⑤ Upper spring seat
- ⑥ Upper spring rubber seat
- ⑦ Bound bumper
- ⑧ Coil spring
- ⑨ (Polyurethane tube)
- ⑩ Strut assembly

- ⑪ Suspension member
- ⑫ Rebound stopper
- ⑬ Stabilizer clamp
- ⑭ Stabilizer bar
- ⑮ Link bushing pin
- ⑯ Transverse link
- ⑰ Connecting rod
- ⑱ Compression rod bushing clamp
- ⑲ Cotter pin
- ⑳ Drive shaft

- ㉑ Cap
- ㉒ Stopper bolt
- ㉓ Cotter pin
- ㉔ Knuckle
- ㉕ ABS sensor
- ㉖ Plain washer
- ㉗ Wheel bearing lock nut
- ㉘ Cotter pin

FRONT SUSPENSION



Coil Spring and Strut Assembly


REMOVAL AND INSTALLATION

- Remove strut assembly fixing bolts and nuts (to hood-ledge).
Do not remove piston rod lock nut on vehicle.

GI

MA

EM



DISASSEMBLY

1. Set strut assembly on vise with Tool, then **loosen** piston rod lock nut.

LC


Do not remove piston rod lock nut at this time.

EC

2. Compress spring with Tool so that the strut mounting insulator can be turned by hand.

FE

CL



3. Remove piston rod lock nut.

MT

AT

FA

RA

INSPECTION

Shock absorber assembly

- Check for smooth operation through a full stroke, both compression and extension.
- Check for oil leakage on welded or gland packing portion.
- Check piston rod for cracks, deformation or other damage.
- Replace if necessary.

ST

RS

BT

Mounting insulator and rubber parts

- Check cemented rubber-to-metal portion for separation or cracks. Check rubber parts for deterioration.
- Replace if necessary.

HA

EL

Thrust bearing

- Check thrust bearing parts for abnormal noise or excessive rattle in axial direction.
- Replace if necessary.


IDX

FRONT SUSPENSION

Coil Spring and Strut Assembly (Cont'd)


Coil spring

- Check for cracks, deformation or other damage. Replace if necessary.




ASSEMBLY

- When installing coil spring on strut, it must be positioned as shown in the figure at left.




- Install upper spring seat with its cutout facing the outer side of vehicle.



Stabilizer Bar

REMOVAL AND INSTALLATION


- Remove stabilizer bar.




- When installing stabilizer, make sure that paint mark and clamp face in their correct directions.

FRONT SUSPENSION


Stabilizer Bar (Cont'd)




- Make sure that slit in bushing is in the position shown in the figure.



- When removing and installing stabilizer bar.




- Install stabilizer bar with ball joint socket properly placed.



INSPECTION

- Check stabilizer for deformation or cracks. Replace if necessary.
- Check rubber bushings for deterioration or cracks. Replace if necessary.
- Check ball joint can rotate in all directions. If movement is not smooth and free, replace stabilizer bar connecting rod.



Transverse Link and Lower Ball Joint

REMOVAL AND INSTALLATION

1. Remove wheel bearing lock nut.
2. Remove tie-rod ball joint.
3. Remove strut lower bracket fixing bolts and nuts.
4. Separate drive shaft from knuckle by slightly tapping drive shaft end.

Cover boots with shop towel so as not to damage them when removing drive shaft.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT



HA

EL

IDX

FRONT SUSPENSION

Transverse Link and Lower Ball Joint (Cont'd)



5. Separate lower ball joint stud from knuckle with suitable tool. Refer to FRONT AXLE — Wheel Hub and Knuckle (FA-8).

6. Remove fixing bolts.
7. Remove transverse link and lower ball joint.
8. Install fixing bolts in order of number.


Tightening torque:

Refer to FRONT SUSPENSION (FA-20).

9. During installation, final tightening must be carried out at curb weight with tires on the ground.
10. After installation, check wheel alignment. Refer to ON-VEHICLE SERVICE — Front Wheel Alignment (FA-6).

INSPECTION

- Check transverse link for damage, cracks or deformation. Replace it if necessary.
- Check rubber bushing for damage, cracks and deformation. Replace transverse link if necessary.



- Check ball joint for excessive play. Replace transverse link assembly if any of the following exists:
 - Ball stud is worn.
 - Joint is hard to swing.
 - Play in axial direction is excessive.Before checking, turn ball joint at least 10 revolutions so that ball joint is properly broken in.

Swinging force "A":

(measuring point: cotter pin hole of ball stud):

7.8 - 77.5 N (0.8 - 7.9 kg, 1.8 - 17.4 lb)

Turning torque "B":

0.49 - 4.90 N·m (5.0 - 50 kg-cm, 4.3 - 43.4 in-lb)

Vertical end play "C":

0 mm (0 in)

- Check dust cover for damage. Replace it and cover clamp if necessary.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

COIL SPRING

Applied model		M/T	A/T
Wire diameter	mm (in)	13.7 (0.539)	13.9 (0.547)
Coil outer diameter	mm (in)	171.9 - 174.9 (6.77 - 6.89)	172.3 - 175.3 (6.78 - 6.90)
Free length	mm (in)	390 (15.35)	400 (15.75)
Identification color		Yellow x 2, Yellow x 1	Yellow x 2, White x 1


STRUT

Applied model		All
Piston rod diameter	mm (in)	22 (0.87)

FRONT STABILIZER BAR

Applied model		All
Stabilizer diameter	mm (in)	21 (0.83)
Identification color		White

WHEELARCH HEIGHT (Unladen*)



SFA818A

Applied model		*1	*2
Front (Hf)	mm (in)	713 (28.07)	713 (28.07)
Rear (Hr)	mm (in)	715 (28.15)	713 (28.07)

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.


*1: Models equipped with 205/65 R15 tires

*2: Models equipped with 215/60 R15 tires


DRIVE SHAFT

Applied model		All
Joint type		
Transaxle side		DS90
Wheel side		ZF100
Boot length	mm (in)	
Transaxle side L ₂		97 - 99 (3.82 - 3.90)
Wheel side L ₁		96 - 98 (3.78 - 3.86)
Grease		Nissan genuine grease or equivalent
Capacity	g (oz)	
Transaxle side		165 - 175 (5.82 - 6.17)
Wheel side		135 - 145 (4.76 - 5.11)

Boot length
Wheel side



Transaxle side



SFA396B

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

WHEEL ALIGNMENT (Unladen*1)

Camber	Degree minute (Decimal degree)	Minimum	-1°00' (-1.00°)	
		Nominal	-0°15' (-0.25°)	
		Maximum	0°30' (0.50°)	
		Left and right difference	45' (0.75°) or less	
Caster	Degree minute (Decimal degree)	Minimum	2°00' (2.00°)	
		Nominal	2°45' (2.75°)	
		Maximum	3°30' (3.50°)	
		Left and right difference	45' (0.75°) or less	
Kingpin inclination	Degree minute (Decimal degree)	Minimum	13°30' (13.50°)	
		Nominal	14°15' (14.25°)	
		Maximum	15°00' (15.00°)	
Total toe-in	Distance (A - B) mm (in)	Minimum	1 (0.04)	
		Nominal	2 (0.08)	
		Maximum	3 (0.12)	
	Angle (left plus right)	Degree minute (Decimal degree)	Minimum	5.5' (0.09°)
			Nominal	11' (0.18°)
			Maximum	16' (0.27°)
Wheel turning angle	Inside	Minimum	36°00' (36.00°)	
		Nominal	39°30' (39.50°)	
	Full turn*2 Outside	Maximum	40°30' (40.50°)	
		Nominal	32°00' (32.00°)	

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

WHEEL BEARING

Wheel bearing axial end play limit mm (in)	0.05 (0.0020)
Wheel bearing lock nut tightening torque N·m (kg·m, ft·lb)	235 - 314 (24 - 32, 174 - 231)

WHEEL RUNOUT

Unit: mm (in)

Wheel type	Aluminum wheel	Steel wheel
Maximum radial runout limit	0.3 (0.012)	0.5 (0.020)
Maximum lateral runout limit	0.3 (0.012)	0.8 (0.031)

LOWER BALL JOINT

Swinging force "A" (Measured at cotter pin hole) N (kg, lb)	7.8 - 77.5 (0.8 - 7.9, 1.8 - 17.4)
Turning torque "B" N·m (kg·cm, in·lb)	0.49 - 4.90 (5.0 - 50, 4.3 - 43.4)
Vertical end play limit "C" mm (in)	0 (0)