

SECTION **SE**
SEAT

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CONTENTS

WITH CLIMATE CONTROLLED SEATS	Description	17
BASIC INSPECTION	Component Function Check	17
DIAGNOSIS AND REPAIR WORK FLOW	Diagnosis Procedure	17
Work Flow	Component Inspection (Thermal Electric Device)....	18
FUNCTION DIAGNOSIS	CLIMATE CONTROLLED SEAT SWITCH	20
CLIMATE CONTROLLED SEAT SYSTEM	Description	20
System Diagram	Component Function Check	20
System Description	Diagnosis Procedure	20
Component Parts Location	Component Inspection (Climate Controlled Seat	
Component Description	Switch)	21
COMPONENT DIAGNOSIS	CLIMATE CONTROLLED SEAT SWITCH IN-	
POWER SUPPLY AND GROUND CIRCUIT	DICATOR	23
CLIMATE CONTROLLED SEAT CONTROL UNIT	Description	23
CLIMATE CONTROLLED SEAT CONTROL UNIT	Component Function Check	23
: Diagnosis Procedure	Diagnosis Procedure	23
CLIMATE CONTROLLED SEAT CONTROL UNIT	Component Inspection (Climate Controlled Seat	
: Component Inspection (Climate Controlled Seat	Switch Indicator)	24
Relay)	POWER SEAT	25
9	Wiring Diagram - POWER SEAT FOR DRIVER	
CLIMATE CONTROLLED SEAT BLOWER	SIDE -	25
MOTOR	Wiring Diagram - POWER SEAT FOR PASSEN-	
Description	GER SIDE -	29
Component Function Check	HEATED SEAT	33
Diagnosis Procedure	Wiring Diagram - HEATED SEAT -	33
Component Inspection (Climate Controlled Seat	LUMBAR SUPPORT	38
Blower Motor)	Wiring Diagram - LUMBAR SUPPORT SYSTEM	38
13	ECU DIAGNOSIS	41
SEAT CUSHION THERMAL ELECTRIC DE-	CLIMATE CONTROLLED SEAT CONTROL	
VICE	UNIT	41
Description	Reference Value	41
Component Function Check	Wiring Diagram - CLIMATE CONTROLLED SEAT	
Diagnosis Procedure	-	43
Component Inspection (Thermal Electric Device)...	Fail-safe	49
15	SYMPTOM DIAGNOSIS	52
SEATBACK THERMAL ELECTRIC DEVICE		

CLIMATE CONTROLLED SEAT SYSTEM	52	Wiring Diagram - POWER SEAT FOR PASSENGER SIDE -	83
Symptom Table	52		
SQUEAK AND RATTLE TROUBLE DIAGNOSES	53	HEATED SEAT	87
Work Flow	53	Wiring Diagram - HEATED SEAT -	87
Inspection Procedure	55	LUMBAR SUPPORT	92
Diagnostic Worksheet	57	Wiring Diagram - LUMBAR SUPPORT SYSTEM - ...	92
PRECAUTION	59	SYMPTOM DIAGNOSIS	95
PRECAUTIONS	59	SQUEAK AND RATTLE TROUBLE DIAGNOSES	95
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	59	Work Flow	95
Precautions Necessary for Steering Wheel Rotation after Battery Disconnect (Early Production, With Electronic Steering Column Lock)	59	Generic Squeak and Rattle Troubleshooting	97
Service Notice	60	Diagnostic Worksheet	99
Precaution for Work	60	PRECAUTION	101
PREPARATION	61	PRECAUTIONS	101
PREPARATION	61	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	101
Special Service Tool	61	Precautions Necessary for Steering Wheel Rotation after Battery Disconnect (Early Production, With Electronic Steering Column Lock)	101
Commercial Service Tools	61	Service Notice	102
ON-VEHICLE REPAIR	62	Precaution for Work	102
FRONT SEAT	62	PREPARATION	103
Exploded View	62	PREPARATION	103
Removal and Installation	65	Special Service Tool	103
REAR SEAT	67	Commercial Service Tool	103
Exploded View - Bucket Seat	67	ON-VEHICLE REPAIR	104
Removal and Installation	68	FRONT SEAT	104
DISASSEMBLY AND ASSEMBLY	69	Exploded View	104
FRONT SEAT	69	Removal and Installation	107
DRIVER SIDE	69	REAR SEAT	109
DRIVER SIDE : Exploded View	69	Exploded View - Bucket Seat	109
DRIVER SIDE : Disassembly and Assembly	71	Removal and Installation	110
PASSENGER SIDE	74	Exploded View - Bench Seat	111
PASSENGER SIDE : Exploded View	74	Removal and Installation	112
PASSENGER SIDE : Disassembly	76	DISASSEMBLY AND ASSEMBLY	113
REAR SEAT	77	FRONT SEAT	113
Exploded View - Bucket Seat	77	DRIVER SIDE	113
ARMREST	78	DRIVER SIDE : Exploded View	113
ARMREST : Disassembly and Assembly	78	DRIVER SIDE : Disassembly and Assembly	114
W/O CLIMATE CONTROLLED SEATS		PASSENGER SIDE	116
COMPONENT DIAGNOSIS	79	PASSENGER SIDE : Exploded View	117
POWER SEAT	79	PASSENGER SIDE : Disassembly	118
Wiring Diagram - POWER SEAT FOR DRIVER SIDE -	79	REAR SEAT	119
		Exploded View - Bucket Seat	119
		ARMREST	120

ARMREST : Disassembly and Assembly	120	Exploded View - Bench Seat	121
--	-----	----------------------------------	-----

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[WITH CLIMATE CONTROLLED SEATS]

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000005462026

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the malfunction (conditions and environment when the malfunction occurred) when the customer brings the vehicle in.

>> GO TO 2.

2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4.IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

CLIMATE CONTROLLED SEAT SYSTEM


< FUNCTION DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

FUNCTION DIAGNOSIS

CLIMATE CONTROLLED SEAT SYSTEM

System Diagram



System Description

INFOID:000000005462028

- The climate controlled seat system is controlled by the climate controlled seat control unit.
- Operation of the climate controlled seat switch sends heated or cooled airflow and adjusts the seat temperature.

SEAT CUSHION AND SEATBACK TEMPERATURE ADJUSTMENT FUNCTION

- A thermal electric device (TED) unit is installed in the seat cushion and seatback. The device heats or cools, sends airflow to the seat surface, and adjusts the seat temperature.
- The thermal electric device (TED) is a heat exchanger that has a function to heat or cool the airflow from the climate controlled seat blower motor. By changing the direction of the current from the power supply, the device takes or gives heat, and adjusts the heat exchange process depending on voltage.

NOTE:

The climate controlled seat blower motor maintains low speed for approximately 60 seconds after turning the climate controlled seat switch off.

CAUTION:

- **The thermal electric device has a dual-climate function that allows one side to operate at a high temperature and the other to operate at a low temperature simultaneously.**
- **Before starting work, always turn OFF the switch and check that the thermal electric device is cold.**

FAIL-SAFE

The fail-safe function is adopted for the climate controlled seat control unit. Refer to [SE-49, "Fail-safe"](#).


CLIMATE CONTROLLED SEAT SYSTEM

< FUNCTION DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Component Parts Location

INFOID:000000005462029



AWJ1A040SZZ

- | | | |
|--|--|--|
| 1. Climate controlled seat switch M302 | 2. Climate controlled seat relay M58 | 3. Seatback thermal electric device B218 |
| 4. Seat cushion thermal electric device B219 | 5. Climate controlled seat control unit B212, B216, B217 | 6. Climate controlled seat blower motor B220 |

Component Description

INFOID:000000005462030

Item	Function
Climate controlled seat relay	Supplies power to the climate controlled seat control unit in accordance with the key switch position that is ON or OFF
Climate controlled seat control unit	Installed in the seat cushion backside and controls the climate controlled seat blower motor, seatback thermal electric device, and seat cushion thermal electric device in accordance with the input signal
Climate controlled seat switch	Installed in the center console and transmits signals to climate controlled seat control unit in accordance with the HEAT (heated airflow) or COOL (cooled airflow) switch operation and the temperature switch operation
Climate controlled seat blower motor	Installed in the seat cushion backside and sends the airflow to the seatback thermal electric device and seat cushion thermal electric device in accordance with the control from the climate controlled seat control unit
Seatback thermal electric device	Installed in the seatback backside and heats or cools the airflow from the climate controlled seat blower motor in accordance with the control from the climate controlled seat control unit
Seat cushion thermal electric device	Installed in the seat cushion backside and heats or cools the airflow from the climate controlled seat blower motor in accordance with the control from the climate controlled seat control unit

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT CLIMATE CONTROLLED SEAT CONTROL UNIT

CLIMATE CONTROLLED SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:000000005462031

Regarding Wiring Diagram information, refer to [SE-43, "Wiring Diagram - CLIMATE CONTROLLED SEAT -"](#).

1. CHECK FUSES

Check for blown fuses.

System component	Power Source	Fuse or Fusible Link	Location
Climate controlled seat control unit	Ignition switch ON or START	3 (10A)	Fuse block (J/B)
	Battery	28 (15A)	Fuse and fusible link box
	Battery	H (40A)	Fuse and fusible link box

Is the inspection result normal?

YES >> GO TO 2.

NO >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link.

2. CHECK BATTERY POWER SUPPLY CIRCUIT


- Turn ignition switch OFF.
- Disconnect climate controlled seat control unit connector B217.
- Check voltage between climate controlled seat control unit connector B217 terminal 29 and ground.

Connector	Terminal	Ground	Voltage (Approx.)
B217	29	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 6.



3. CHECK IGNITION POWER SUPPLY CIRCUIT

- Disconnect climate controlled seat control unit connector B216.
- Check voltage between climate controlled seat control unit connector B216 terminal 21 and ground.


Connector	Terminal	Ground	Ignition switch	Voltage (Approx.)
B216	21	—	OFF	0V
			ON	Battery voltage
			START	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

4. CHECK GROUND CIRCUIT



POWER SUPPLY AND GROUND CIRCUIT

[WITH CLIMATE CONTROLLED SEATS]


< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Check continuity between climate controlled seat control unit connector B217 terminal 30 and ground.

Connector	Terminal	Ground	Continuity
B217	30	—	Yes

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair the harness or connectors.



5. CHECK CLIMATE CONTROLLED SEAT RELAY

Perform the climate controlled seat relay component inspection. Refer to [SE-9, "CLIMATE CONTROLLED SEAT CONTROL UNIT : Component Inspection \(Climate Controlled Seat Relay\)"](#).

Is the inspection result normal?

- YES >> GO TO 8.
NO >> Replace the climate controlled seat relay.


6. CHECK CIRCUIT BREAKER POWER SUPPLY CIRCUIT

1. Disconnect the circuit breaker connector M84.
2. Check voltage between circuit breaker connector M84 terminal 1 and ground.

Connector	Terminal	Ground	Voltage (Approx.)
M84	1	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Repair the harness or connectors.




7. CHECK BATTERY POWER SUPPLY CIRCUIT FOR OPEN

Check continuity between circuit breaker connector M84 (A) terminal 2 and climate controlled seat control unit connector B217 (B) terminal 29.

Circuit Breaker		Climate Controlled Seat Control Unit		Continuity
Connector	Terminal	Connector	Terminal	
M84 (A)	2	B217 (B)	29	Yes

Is the inspection result normal?

- YES >> Replace the circuit breaker.
NO >> Repair the harness or connectors.




8. CHECK CLIMATE CONTROLLED SEAT RELAY BATTERY POWER SUPPLY CIRCUIT

1. Disconnect climate controlled seat relay connector.
2. Check voltage between climate controlled seat relay connector M58 terminal 3 and ground.

Connector	Terminal	Ground	Voltage (Approx.)
M58	3	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 9.
NO >> Repair the harness or connectors.



9. CHECK CLIMATE CONTROLLED SEAT RELAY IGNITION POWER SUPPLY CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

Check voltage between climate controlled seat relay connector M58 terminal 2 and ground.

Connector	Terminal	Ground	Ignition switch	Voltage (Approx.)
M58	2	—	OFF	0V
			ON	Battery voltage
			START	Battery voltage

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair the harness or connectors.

10. CHECK IGNITION POWER SUPPLY CIRCUIT FOR OPEN

Check continuity between climate controlled seat relay connector M58 (A) terminal 5 and climate controlled seat control unit connector B216 (B) terminal 21.

Climate Controlled Seat Relay		Climate Controlled Seat Control Unit		Continuity
Connector	Terminal	Connector	Terminal	
M58 (A)	5	B216 (B)	21	Yes

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair the harness or connectors.

11. CHECK CLIMATE CONTROLLED SEAT RELAY GROUND CIRCUIT

Check continuity between climate controlled seat relay connector M58 terminal 1 and ground.

Connector	Terminal	Ground	Continuity
M58	1	—	Yes

Is the inspection result normal?




YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> Repair the harness or connectors.

CLIMATE CONTROLLED SEAT CONTROL UNIT : Component Inspection (Climate Controlled Seat Relay)

INFOID:000000005462032

1. CHECK CLIMATE CONTROLLED SEAT RELAY



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

[WITH CLIMATE CONTROLLED SEATS]


< COMPONENT DIAGNOSIS >

1. Apply battery voltage between terminals 2 and 1 of the climate controlled seat relay.
CAUTION:
Connect a fuse between the terminals when applying battery voltage.
2. Check continuity between climate controlled seat relay terminals 5 and 3.

Climate Controlled Seat Relay Terminals	Condition	Continuity
5 and 3	Battery voltage applied between terminals 2 and 1.	Yes

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace climate controlled seat relay.



CLIMATE CONTROLLED SEAT BLOWER MOTOR

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

CLIMATE CONTROLLED SEAT BLOWER MOTOR

Description

INFOID:000000005462033

Sends airflow to the seat cushion and seatback.

Component Function Check

INFOID:000000005462034

1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR FUNCTION

Turn the climate controlled seat switch to the H (Heat) LO, MED, and HI positions and the C (Cool) LO, MED, and HI positions. Check that the climate controlled seat blower motor operates at low, medium and high speed.

Is the inspection result normal?

- YES >> Climate controlled seat blower motor function is OK.
- NO >> Refer to [SE-11, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462035

Regarding Wiring Diagram information, refer to [SE-43, "Wiring Diagram - CLIMATE CONTROLLED SEAT -"](#).

1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR

Perform climate controlled seat blower motor component inspection. Refer to [SE-13, "Component Inspection \(Climate Controlled Seat Blower Motor\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace climate controlled seat blower motor.


2. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between climate controlled seat blower motor connector B220 terminal 2 and ground.

Climate controlled seat blower motor		Ground	Voltage (Approx.)
Connector	Terminal		
B220	2	—	Battery voltage

Is the inspection result normal?


- YES >> GO TO 4.
- NO >> GO TO 3.



3. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat blower motor connector and climate controlled seat control unit connector B212.
3. Check continuity between climate controlled seat blower motor connector B220 (A) terminal 2 and climate controlled seat control unit connector B212 (B) terminal 7.

Climate controlled seat blower motor		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B220 (A)	2	B212 (B)	7	Yes



4. Check continuity between climate controlled seat blower motor connector B220 (A) terminal 2 and ground.

CLIMATE CONTROLLED SEAT BLOWER MOTOR

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

Climate controlled seat blower motor		Ground	Continuity
Connector	Terminal		
B220 (A)	2	—	No

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit.
 NO >> Repair harness or connectors.


4. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR SPEED CONTROL SIGNAL

Check voltage between climate controlled seat blower motor connector B220 terminal 3 and ground.

Climate controlled seat blower motor		Ground	Condition	Voltage (Approx.)
Connector	Terminal		Climate controlled seat switch	
B220	3	—	HEAT or COOL	4.5V – 8.0V

Is the inspection result normal?


- YES >> GO TO 6.
 NO >> GO TO 5.



5. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR SPEED CONTROL SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect climate controlled seat blower motor connector and climate controlled seat control unit connector B212.
- Check continuity between climate controlled seat blower motor connector B220 (A) terminal 3 and climate controlled seat control unit connector B212 (B) terminal 4.

Climate controlled seat blower motor		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B220 (A)	3	B212 (B)	4	Yes



- Check continuity between climate controlled seat blower motor connector B220 (A) terminal 3 and ground.

Climate controlled seat blower motor		Ground	Continuity
Connector	Terminal		
B220 (A)	3	—	No

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit.
 NO >> Repair harness or connectors.


6. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR GROUND CIRCUIT

CLIMATE CONTROLLED SEAT BLOWER MOTOR

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

1. Disconnect climate controlled seat blower motor connector and climate controlled seat control unit connector B212.
2. Check continuity between climate controlled seat blower motor connector B220 (A) terminal 4 and climate controlled seat control unit connector B212 (B) terminal 6.



Climate controlled seat blower motor		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B220 (A)	4	B212 (B)	6	Yes

Is the inspection result normal?


- YES >> Replace climate controlled seat control unit.
 NO >> Repair harness or connectors.

Component Inspection (Climate Controlled Seat Blower Motor)

INFOID:000000005462036

1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR PART 1

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat blower motor connector.
3. Measure the resistance of the climate controlled seat blower motor between terminals 2 and 4.




Climate Controlled Seat Blower Motor Terminals		Resistance
2	4	600 – 800 Ω

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace climate controlled seat blower motor. Refer to [SE-62, "Exploded View"](#).

2. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR PART 2

Measure the resistance of the climate controlled seat blower motor between terminals 3 and 4.



Climate Controlled Seat Blower Motor Terminals		Resistance
3	4	2500 – 2800 Ω

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace climate controlled seat blower motor. Refer to [SE-62, "Exploded View"](#).

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SEAT CUSHION THERMAL ELECTRIC DEVICE

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SEAT CUSHION THERMAL ELECTRIC DEVICE

Description

INFOID:000000005462037

Provides cooling and heat for the seat cushion.

Component Function Check

INFOID:000000005462038

1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE FUNCTION

1. Turn the climate controlled seat switch to the H (Heat) HI position and check that the seat cushion thermal electric device operates correctly.
2. Turn the climate controlled seat switch to the C (Cool) HI position and check that the seat cushion thermal electric device operates correctly.

Is the inspection result normal?

- YES >> Seat cushion thermal electric device is OK.
 NO >> Refer to [SE-14, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462039

Regarding Wiring Diagram information, refer to [SE-43, "Wiring Diagram - CLIMATE CONTROLLED SEAT -"](#).

1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE


Perform thermal electric device component inspection for the seat cushion. Refer to [SE-15, "Component Inspection \(Thermal Electric Device\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace seat cushion thermal electric device.

2. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect seat cushion thermal electric device connector and climate controlled seat control unit connector B217.
3. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 1, 2 and climate controlled seat control unit connector B217 (B) terminals 26, 27.



AWJIA0394ZZ

Seat cushion thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B219 (A)	1	B217 (B)	27	Yes
	2		26	

4. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 1, 2 and ground.

Seat cushion thermal electric device		Ground	Continuity
Connector	Terminal		
B219 (A)	1		No
	2		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair harness or connectors.

SEAT CUSHION THERMAL ELECTRIC DEVICE


[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

3. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR CIRCUITS

1. Disconnect climate controlled seat control unit connector B212.
2. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 3, 4 and climate controlled seat control unit connector B212 (B) terminals 13, 14.

Seat cushion thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B219 (A)	3	B212 (B)	14	Yes
	4		13	



3. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 3, 4 and ground.

Seat cushion thermal electric device		Ground	Continuity
Connector	Terminal		
B219 (A)	3		No
	4		

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit.
 NO >> Repair harness or connectors.

Component Inspection (Thermal Electric Device)

INFOID:000000005462040


1. CHECK THERMAL ELECTRIC DEVICE

1. Turn ignition switch OFF.
2. Disconnect thermal electric device connector.
3. Measure the resistance of the thermal electric device between terminals 1 and 2.

NOTE:

The resistance value in the table below will change under any of the following conditions:

- air blowing across the thermal electric device
- changing the surrounding temperature of the thermal electric device
- measuring at other than 23°C (73°F)



Thermal electric device terminals		Temperature	Resistance
1	2	23°C (73°F)	0.9 – 10 Ω

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace thermal electric device. Refer to [SE-62, "Exploded View"](#).

2. CHECK THERMAL ELECTRIC DEVICE SENSOR


SEAT CUSHION THERMAL ELECTRIC DEVICE

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Measure the resistance of the thermal electric device sensor between terminals 3 and 4.

Thermal electric device terminals		Temperature	Resistance
3	4	0 – 10° C (32 – 50° F)	2785– 1660 Ω
		10 – 20° C (50 – 68° F)	1840 – 1135 Ω
		20 – 30° C (68 – 86° F)	1265 – 800 Ω
		30 – 40° C (86 – 104° F)	895 – 565 Ω
		40 – 50° C (104 – 122° F)	635 – 425 Ω



Is the inspection result normal?

YES >> Inspection End.

NO >> Replace thermal electric device. Refer to [SE-62, "Exploded View"](#).

SEATBACK THERMAL ELECTRIC DEVICE

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SEATBACK THERMAL ELECTRIC DEVICE

Description

INFOID:000000005462041

Provides cooling and heat for the seatback.

Component Function Check

INFOID:000000005462042

1. CHECK SEAT BACK THERMAL ELECTRIC DEVICE FUNCTION

1. Turn the climate controlled seat switch to the H (Heat) HI position and check that the seatback thermal electric device operates correctly.
2. Turn the climate controlled seat switch to the C (Cool) HI position and check that the seatback thermal electric device operates correctly.

Is the inspection result normal?

- YES >> Seatback thermal electric device is OK.
 NO >> Refer to [SE-17, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462043

Regarding Wiring Diagram information, refer to [SE-43, "Wiring Diagram - CLIMATE CONTROLLED SEAT -"](#).

1. CHECK SEATBACK THERMAL ELECTRIC DEVICE


Perform thermal electric device component inspection for the seatback. Refer to [SE-18, "Component Inspection \(Thermal Electric Device\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace seatback thermal electric device.

2. CHECK SEATBACK THERMAL ELECTRIC DEVICE CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect seatback thermal electric device connector and climate controlled seat control unit connector B217.
3. Check continuity between seatback thermal electric device connector B218 (A) terminals 1, 2 and climate controlled seat control unit connector B217 (B) terminals 25, 28.



Seatback thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B218 (A)	1	B217 (B)	28	Yes
	2		25	

4. Check continuity between seatback thermal electric device connector B218 (A) terminals 1, 2 and ground.

Seatback thermal electric device		Ground	Continuity
Connector	Terminal		
B218 (A)	1		No
	2		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair harness or connectors.

3. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR CIRCUITS


SEATBACK THERMAL ELECTRIC DEVICE

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

1. Disconnect climate controlled seat control unit connector B212.
2. Check continuity between seatback thermal electric device connector B218 (A) terminals 3, 4 and climate controlled seat control unit connector B212 (B) terminals 15, 16.

Seatback thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B218 (A)	3	B212 (B)	16	Yes
	4		15	



3. Check continuity between seatback thermal electric device connector B218 (A) terminals 3, 4 and ground.

Seatback thermal electric device		Ground	Continuity
Connector	Terminal		
B218 (A)	3		No
	4		

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit.
 NO >> Repair harness or connectors.

Component Inspection (Thermal Electric Device)

INFOID:000000005462044

1. CHECK THERMAL ELECTRIC DEVICE

1. Turn ignition switch OFF.
2. Disconnect thermal electric device connector.
3. Measure the resistance of the thermal electric device between terminals 1 and 2.

NOTE:

The resistance value in the table below will change under any of the following conditions:

- air blowing across the thermal electric device
- changing the surrounding temperature of the thermal electric device
- measuring at other than 23°C (73°F)

Thermal electric device terminals		Temperature	Resistance
1	2	23°C (73°F)	0.9 – 10 Ω

Is the inspection result normal?



- YES >> GO TO 2.
 NO >> Replace thermal electric device. Refer to [SE-62. "Exploded View"](#).

2. CHECK THERMAL ELECTRIC DEVICE SENSOR

Measure the resistance of the thermal electric device sensor between terminals 3 and 4.

Thermal electric device terminals		Temperature	Resistance
3	4	0 – 10° C (32 – 50° F)	2785 – 1660 Ω
		10 – 20° C (50 – 68° F)	1840 – 1135 Ω
		20 – 30° C (68 – 86° F)	1265 – 800 Ω
		30 – 40° C (86 – 104° F)	895 – 565 Ω
		40 – 50° C (104 – 122° F)	635 – 425 Ω

Is the inspection result normal?



SEATBACK THERMAL ELECTRIC DEVICE

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

YES >> Inspection End.

NO >> Replace thermal electric device. Refer to [SE-62, "Exploded View"](#).

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

CLIMATE CONTROLLED SEAT SWITCH

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

CLIMATE CONTROLLED SEAT SWITCH

Description

INFOID:000000005462045

Provides inputs to the climate controlled seat control unit for climate controlled seat operation.

Component Function Check

INFOID:000000005462046

1.CHECK CLIMATE CONTROLLED SEAT SWITCH FUNCTION

Turn the climate controlled seat switch to the H (Heat) LO, MED, and HI positions and the C (Cool) LO, MED, and HI positions. Check that the climate controlled seat operates at low, medium and high heat, and low, medium and high cool.

Is the inspection result normal?

YES >> Climate controlled seat switch function is OK.

NO >> Refer to [SE-20, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462047

Regarding Wiring Diagram information, refer to [SE-43, "Wiring Diagram - CLIMATE CONTROLLED SEAT -"](#).

1.CHECK CLIMATE CONTROLLED SEAT SWITCH

Perform climate controlled seat switch component inspection. Refer to [SE-21, "Component Inspection \(Climate Controlled Seat Switch\)"](#).


Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace climate controlled seat switch.

2.CHECK CLIMATE CONTROLLED SEAT SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat switch connector and climate controlled seat control unit connector B216.
3. Check continuity between climate controlled seat switch connector M302 (A) terminal 1 and climate controlled seat control unit connector B216 (B) terminal 24.



Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	1	B216 (B)	24	Yes

4. Check continuity between climate controlled seat switch connector M302 (A) terminal 1 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	1		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connectors.

3.CHECK CLIMATE CONTROLLED SEAT SWITCH COOL CIRCUIT


CLIMATE CONTROLLED SEAT SWITCH

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

1. Disconnect climate controlled seat control unit connector B212.
2. Check continuity between climate controlled seat switch connector M302 (A) terminal 2 and climate controlled seat control unit connector B212 (B) terminal 9.

Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	2	B212 (B)	9	Yes



3. Check continuity between climate controlled seat switch connector M302 (A) terminal 2 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	2		No


Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connectors.

4. CHECK CLIMATE CONTROLLED SEAT SWITCH HEAT CIRCUIT

1. Check continuity between climate controlled seat switch connector M302 (A) terminal 3 and climate controlled seat control unit connector B212 (B) terminal 1.

Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	3	B212 (B)	1	Yes



2. Check continuity between climate controlled seat switch connector M302 (A) terminal 3 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	3		No

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit.
 NO >> Repair harness or connectors.

Component Inspection (Climate Controlled Seat Switch)

INFOID:000000005462048

1. CHECK CLIMATE CONTROLLED SEAT SWITCH

1. Disconnect climate controlled seat switch connector.
2. Check continuity between climate controlled seat switch terminals.

Terminals		Condition	Continuity
1	3	Climate controlled seat switch HEAT	Yes
		Other than above	No
	2	Climate controlled seat switch COOL	Yes
		Other than above	No

CLIMATE CONTROLLED SEAT SWITCH

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace climate controlled seat switch. Refer to [SE-62. "Exploded View"](#).

CLIMATE CONTROLLED SEAT SWITCH INDICATOR

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

CLIMATE CONTROLLED SEAT SWITCH INDICATOR

Description

INFOID:000000005462049

Illuminates the climate controlled seat switch to indicate operating status.

Component Function Check

INFOID:000000005462050

1. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR FUNCTION

Check that the indicators for the climate controlled seat switch operate in both COOL and HEAT modes.

Is the inspection result normal?

- YES >> Climate controlled seat switch indicator function is OK.
- NO >> Refer to [SE-23, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005462051

Regarding Wiring Diagram information, refer to [SE-43, "Wiring Diagram - CLIMATE CONTROLLED SEAT -"](#).

1. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR


Perform climate controlled seat switch indicator component inspection. Refer to [SE-24, "Component Inspection \(Climate Controlled Seat Switch Indicator\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace climate controlled seat switch.

2. CHECK CLIMATE CONTROLLED SEAT SWITCH COOL INDICATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat switch connector and climate controlled seat control unit connector B216.
3. Check continuity between climate controlled seat switch connector M302 (A) terminal 4 and climate controlled seat control unit connector B216 (B) terminal 19.



Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	4	B216 (B)	19	Yes

4. Check continuity between climate controlled seat switch connector M302 (A) terminal 4 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	4		No

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connectors.

3. CHECK CLIMATE CONTROLLED SEAT SWITCH HEAT INDICATOR CIRCUIT


CLIMATE CONTROLLED SEAT SWITCH INDICATOR

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

1. Check continuity between climate controlled seat switch connector M302 (A) terminal 5 and climate controlled seat control unit connector B216 (B) terminal 20.

Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	5	B216 (B)	20	Yes



2. Check continuity between climate controlled seat switch connector M302 (A) terminal 5 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	5		No


Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair harness or connectors.

4. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR GROUND CIRCUIT

Check continuity between climate controlled seat switch connector M302 terminal 6 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302	6		Yes



Is the inspection result normal?

- YES >> Replace climate controlled seat control unit.
NO >> Repair harness or connectors.

Component Inspection (Climate Controlled Seat Switch Indicator)

INFOID:000000005462052

1. CHECK CLIMATE CONTROLLED SEAT SWITCH

1. Disconnect climate controlled seat switch connector.
2. Check continuity between climate controlled seat switch terminals.

Terminals		Continuity
4	6	
5		

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace climate controlled seat switch. Refer to [SE-62. "Exploded View"](#).

POWER SEAT

< COMPONENT DIAGNOSIS >


[WITH CLIMATE CONTROLLED SEATS]

POWER SEAT

Wiring Diagram - POWER SEAT FOR DRIVER SIDE -

INFOID:000000005462053

POWER SEAT FOR DRIVER SIDE - WITHOUT AUTOMATIC DRIVE POSITIONER




ABJWA0136GE

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER

Terminal No.	Color of Wire	Signal Name
20J	R/Y	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	B	GND1

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

ABJIA0241GB


POWER SEAT

< COMPONENT DIAGNOSIS >


[WITH CLIMATE CONTROLLED SEATS]

Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Connector No.	B209
Connector Name	POWER SEAT SWITCH LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
2	O	-
3	R/Y	-
4	B	-
5	GR	-
6	V	-
7	Y	-
8	B	-
9	R	-
10	V	-

Connector No.	B207
Connector Name	RECLINING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	O	-
2	GR	-

Connector No.	B204
Connector Name	FRONT POWER SEAT LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	SLIDER MOTOR
2	R	REAR LIFTER MOTOR
3	V	SLIDER MOTOR
4	GR	FRONT LIFTER MOTOR
5	O	FRONT LIFTER MOTOR
6	B/W	REAR LIFTER MOTOR

ABJIA0384GB

POWER SEAT


< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Wiring Diagram - POWER SEAT FOR PASSENGER SIDE -

INFOID:000000005462054

POWER SEAT FOR PASSENGER SIDE



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

ABJWA0137GE


POWER SEAT

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]


POWER SEAT FOR PASSENGER SIDE CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	R/Y	-

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	B	GND1

POWER SEAT

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]


Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	SB	-

Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B307
Connector Name	RECLINING MOTOR RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	GR	-

Connector No.	B306
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	Y	-

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
7	SB	-

ABJIA0385GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT

< COMPONENT DIAGNOSIS >


[WITH CLIMATE CONTROLLED SEATS]

Connector No.	B309
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	R/Y	-
4	B	-
5	W	-
6	V	-
7	Y	-
8	-	-
9	-	-
10	GR	-

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
7	R/Y	-

AAJIA0024GB

HEATED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >


HEATED SEAT

Wiring Diagram - HEATED SEAT -

INFOID:000000005462055

◊AD◊ : WITH AUTOMATIC DRIVE POSITIONER
 ◊CT◊ : WITHOUT CLIMATE CONTROLLED SEAT
 ◊XA◊ : WITHOUT AUTOMATIC DRIVE POSITIONER
 *1
 ◊AD◊ : 7
 ◊XA◊ : 4

HEATED SEAT



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

ABJWA0138GE


HEATED SEAT

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]


HEATED SEAT CONNECTORS

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8M	G/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18J	GR	-
19J	GR/R	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	GR/L	-
4	GR/B	-

Connector No.	M87
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
6	GR	-
9	GR/L	-
14	GR/R	-
15	B	-
16	G/R	-

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
6	GR	-
9	GR/L	-
14	GR/R	-
15	B	-
16	G/R	-

HEATED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >

Connector No.	M301
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	W	-
3	O	-
4	B	-

Connector No.	M300
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	SB	-
2	G	-
3	GR	-
4	B	-

Connector No.	M208
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
5	GR/R	-
6	B	-
7	G/R	-
9	GR/L	-
15	GR	-

Connector No.	M305
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
3	GR	-
5	O	-
6	B	-
7	P	-
9	G	-
15	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT

[WITH CLIMATE CONTROLLED SEATS]


< COMPONENT DIAGNOSIS >

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G	-
4	B	-
6	GR	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
4	GR	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	W	-
4	B	-
6	O	-
7	B/W	-

Connector No.	B304
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR/G	-
2	GR/R	-
3	B	-

Connector No.	B210
Connector Name	FRONT SEAT HEATER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR/W	-
3	W/B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
4	B	-
6	GR/W	-
7	GR/B	-

ABJIA0382GB


HEATED SEAT

< COMPONENT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR/G	-
4	B	-
6	GR/R	-

AAJIA0028GB

LUMBAR SUPPORT

< COMPONENT DIAGNOSIS >


[WITH CLIMATE CONTROLLED SEATS]

LUMBAR SUPPORT

Wiring Diagram - LUMBAR SUPPORT SYSTEM -

INFOID:000000005462056

LUMBAR SUPPORT SYSTEM



AAJWA0013GE


LUMBAR SUPPORT

[WITH CLIMATE CONTROLLED SEATS]

< COMPONENT DIAGNOSIS >


LUMBAR SUPPORT SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	B	GND1




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

LUMBAR SUPPORT

< COMPONENT DIAGNOSIS >


[WITH CLIMATE CONTROLLED SEATS]

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B221
Connector Name	LUMBAR SUPPORT MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-

Connector No.	B214
Connector Name	LUMBAR SUPPORT SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-
3	B	-
4	R/Y	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

CLIMATE CONTROLLED SEAT CONTROL UNIT

< ECU DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]


ECU DIAGNOSIS

CLIMATE CONTROLLED SEAT CONTROL UNIT

Reference Value

INFOID:000000005462057

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal	Wire color	Item	Signal Input/ Output	Condition		Voltage (Approx.)	
1	O	HEAT switch signal	Input	Ignition switch ON or START	Climate controlled seat switch select	HI HEAT	2.6V – 3.5V
						MED HEAT	1.6V – 2.5V
						LO HEAT	0.5V – 1.5V
						OFF	0V
4	V	Blower motor speed control signal	Input	Ignition switch ON or START	Climate controlled seat switch select	HEAT or COOL	4.5V – 8.0V
						OFF	0V
6	B	Blower motor ground	—	—		0V	
7	R	Blower motor power supply	Input	Ignition switch ON or START		Battery voltage	
9	L	COOL switch signal	Input	Ignition switch ON or START	Climate controlled seat switch select	HI COOL	2.6V – 3.5V
						MED COOL	1.6V – 2.5V
						LO COOL	0.5V – 1.5V
						OFF	0V
13	G/B	Seat cushion thermal electric device sensor ground	—	Ignition switch ON		0V	
14	G/R	Seat cushion thermal electric device sensor signal	Input	Blower motor operated		0.5V – 4.0V	
				Ignition switch OFF		0V	
15	G/Y	Seatback thermal electric device sensor ground	—	Ignition switch ON		0V	
16	G	Seatback thermal electric device sensor signal	Input	Blower motor operated		0.5V – 4.0V	
				Ignition switch OFF		0V	
19	V	COOL switch indicator signal	Output	Ignition switch ON or START	Climate controlled seat switch select	COOL	Battery voltage
						OFF	0V
20	BR	HEAT switch indicator signal	Output	Ignition switch ON or START	Climate controlled seat switch select	HEAT	Battery voltage
						OFF	0V
21	GR/W	Ignition switch power supply	Input	Ignition switch ON or START		Battery voltage	
24	GR	Climate controlled seat switch power supply	Input	Ignition switch ON or START		Battery voltage	

CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]

< ECU DIAGNOSIS >

Terminal	Wire color	Item	Signal Input/ Output	Condition			Voltage (Approx.)
25	Y	Seatback thermal electric device power supply (COOL)	Output	Ignition switch ON or START	Climate controlled seat switch select	COOL	Battery voltage
						HEAT	0V
						OFF	0V
26	Y/B	Seat cushion thermal electric device power supply (COOL)	Output	Ignition switch ON or START	Climate controlled seat switch select	COOL	Battery voltage
						HEAT	0V
						OFF	0V
27	L/O	Seat cushion thermal electric device power supply (HEAT)	Output	Ignition switch ON or START	Climate controlled seat switch select	HEAT	Battery voltage
						COOL	0V
						OFF	0V
28	L	Seatback thermal electric device power supply (HEAT)	Output	Ignition switch ON or START	Climate controlled seat switch select	HEAT	Battery voltage
						COOL	0V
						OFF	0V
29	GR/W	Battery power supply	Input	Ignition switch ON or OFF			Battery voltage
30	GR/B	Ground	—	—			0V


CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]

< ECU DIAGNOSIS >

Wiring Diagram - CLIMATE CONTROLLED SEAT -

INFOID:000000005462058



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

ABJWA0135GE


CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]

< ECU DIAGNOSIS >


CLIMATE CONTROLLED SEAT CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
81G	R/W	-
82G	W/B	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2N	G	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
20J	R/Y	-
58J	G	-
59J	R/G	-
60J	BR/Y	-
61J	G/R	-
98J	W	-
99J	GR	-

CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]

< ECU DIAGNOSIS >

Connector No.	M85
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	G	-
8	R/G	-
18	GR	-
19	BR/Y	-
20	G/R	-

Connector No.	M84
Connector Name	CIRCUIT BREAKER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	R/Y	-

Connector No.	M88
Connector Name	CLIMATE CONTROLLED SEAT RELAY
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	R/W	-
5	W	-

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
15	B	-

Connector No.	M200
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G	-
8	R/G	-
18	GR	-
19	BR/Y	-
20	G/R	-

Connector No.	M87
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
15	B	-


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]


< ECU DIAGNOSIS >

Connector No.	M208
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	R/G	-
6	B	-
10	G/R	-
11	BR/Y	-
12	GR	-
13	G	-

Connector No.	M302
Connector Name	CLIMATE CONTROLLED SEAT SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	LG	-
3	V	-
4	BR	-
5	O	-
6	B	-

Connector No.	M305
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	V	-
6	B	-
10	O	-
11	BR	-
12	W	-
13	LG	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABJIA0387GB

CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]

< ECU DIAGNOSIS >


Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BR	-
5	W	-
6	O	-
7	B/Y	-

Terminal No.	Color of Wire	Signal Name
20J	BR	-
58J	GR	-
59J	L	-
60J	G	-
61J	O	-
98J	O	-
99J	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B208
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	BR	-
12	V	-
13	L	-
14	O	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
5	GR	-
6	GR/W	-
7	GR/B	-

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	GR	-
12	L	-
13	G	-
14	O	-

AAJIA0015GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]

< ECU DIAGNOSIS >


Connector No.	B216
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
17	-	-
18	-	-
19	V	COOL ON INDICATOR
20	BR	HEAT ON INDICATOR
21	GR/W	IGN
22	-	-
23	-	-
24	GR	HEAT/COOL SW RESISTOR PWR


Terminal No.	Color of Wire	Signal Name
10	-	-
11	-	-
12	-	-
13	G/B	CUSHION SENSOR GND
14	G/R	CUSHION SENSOR SIGNAL
15	G/Y	BACK SENSOR GND
16	G	BACK SENSOR SIGNAL

Connector No.	B212
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	O	HEAT SWITCH INPUT
2	-	-
3	-	-
4	V	BLOWER MOTOR SPEED CONTROL
5	-	-
6	B	BLOWER GND
7	R	BLOWER POWER
8	-	-
9	L	COOL SWITCH INPUT

Connector No.	B219
Connector Name	SEAT CUSHION THERMAL ELECTRIC DEVICE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/O	TED + HEAT (-COOL)
2	Y/B	TED - HEAT (+COOL)
3	G/R	SENSOR SIGNAL
4	G/B	SENSOR RETURN

Connector No.	B218
Connector Name	SEAT BACK THERMAL ELECTRIC DEVICE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	TED + HEAT (-COOL)
2	Y	TED - HEAT (+COOL)
3	G	SENSOR SIGNAL
4	G/Y	SENSOR RETURN

Connector No.	B217
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
25	Y	BACK TED 1
26	Y/B	CUSHION TED 1
27	L/O	CUSHION TED 2
28	L	BACK TED 2
29	GR/W	BAT (PTC)
30	GR/B	GND

ABJIA0317GB

CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]



< ECU DIAGNOSIS >

A
B
C
D
E
F
G
H
I

SE

K
L
M
N
O

Connector No.	B220
Connector Name	CLIMATE CONTROLLED SEAT BLOWER MOTOR
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	-	-
2	R	POWER
3	V	RPM CONTROL PWM
4	B	GROUND
5	-	-

AAJIA0017GB

INFOID:000000005462059

P

Fail-safe

- Climate controlled seat control unit equips fail-safe function.
- When a malfunction occurs in the systems shown as per the following, climate controlled seat control unit stops output.

CLIMATE CONTROLLED SEAT CONTROL UNIT

[WITH CLIMATE CONTROLLED SEATS]

< ECU DIAGNOSIS >

Malfunction	Malfunctioning condition
<p>The temperature difference between the seatback thermal electric device and seat cushion thermal electric device is 30°C (86°F) or more</p>	<ul style="list-style-type: none"> When it detects for 4 seconds that the temperature difference between the seatback thermal electric device and seat cushion thermal electric device is 30°C (86°F) or more, stops the output to the thermal electric device, activates the climate controlled seat blower motor in the maximum position, and sends the external airflow for 30 seconds If the temperature difference is still 30°C (86°F) or more after 30 seconds pass, it stops all output and enters the system OFF condition When the temperature difference between seatback thermal electric device and seat cushion thermal electric device becomes 20°C (68°F) or less, the system recovers automatically If it detects that the temperature difference is 30°C (86°F) or more after the automatic system recovery, it immediately stops all output and enters the system OFF condition <p>NOTE: When the switch operation is performed before entering the system OFF condition, the fail-safe mode is reset.</p>
<p>The temperature of thermal electric device is 110°C (230°F) or more in the HEAT mode (any thermal electric device in the seatback or seat cushion)</p>	<ul style="list-style-type: none"> When it detects for 4 seconds that the temperature of the thermal electric device is 110°C (230°F) or more, stops the output to the thermal electric device, activates the climate controlled seat blower motor in the maximum position, and sends the external airflow for 30 seconds If the temperature does not become 105°C (221°F) or less after 30 seconds pass, it stops all output and enters the system OFF condition When the temperature of the thermal electric device becomes 105°C (221°F) or less, the system recovers automatically If it detects that the temperature of the thermal electric device is 110°C (230°F) or more after the automatic system recovery, it immediately stops all output and enters the system OFF condition
<p>The temperature of the thermal electric device is 45°C (113°F) or more in the COOL mode (any thermal electric device in the seatback or seat cushion)</p>	<ul style="list-style-type: none"> When it detects for 4 seconds that the temperature of the thermal electric device is between 45°C (113°F) and 70°C (158°F), it starts the temperature monitoring of the thermal electric device at 3 second intervals While monitoring, if it detects that the temperature raises 2°C (36°F) or more 4 times continuously or reaches 70°C (158°F) or more, it stops all output and enters the system OFF condition If it detects other results of monitoring, it continues activating in the COOL mode
<p>Thermal electric device sensor system open circuit</p>	<ul style="list-style-type: none"> When it detects for 4 seconds that the thermal electric device sensor system is an open circuit
<p>Climate controlled seat blower motor system open circuit</p>	<ul style="list-style-type: none"> When it detects for 2 seconds that climate controlled seat blower motor system is an open circuit while the climate controlled seat is being activated, it stops output to the thermal electric device When it detects for 10 seconds that the climate controlled seat blower motor system is an open circuit while the climate controlled seat is being activated, it stops all output and enters the system OFF condition <p>NOTE: After detecting the climate seat blower motor system open circuit for 2 seconds, the system recovers automatically if the activation of the climate controlled seat blower motor is detected for 1 second or more.</p>
<p>Switch input out of the specified range</p>	<ul style="list-style-type: none"> When it detects for 4 seconds that the rotary switch input is 30% or less of the vehicle battery voltage, it stops all output and enters the system OFF condition When the switch input returns to a value within the specified range, the system recovers automatically
<p>HEAT or COOL switch input out of the specified range</p>	<ul style="list-style-type: none"> When it detects for 4 seconds that rotary switch input is 6% or less of the vehicle battery voltage, it stops all output and enters the system OFF condition When the switch input returns to a value within the specified range, the system recovers automatically
<p>System voltage out of range</p>	<ul style="list-style-type: none"> System voltage* of the climate controlled seat control unit is out of the operation range (8.5 V – 16.5 V)

*: System voltage is the voltage between climate controlled seat control unit power source and the ground.

NOTE:

CLIMATE CONTROLLED SEAT CONTROL UNIT

< ECU DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

When the system enters in the fail-safe mode again after performing resetting procedure, perform diagnosis.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

CLIMATE CONTROLLED SEAT SYSTEM

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SYMPTOM DIAGNOSIS

CLIMATE CONTROLLED SEAT SYSTEM

Symptom Table

INFOID:000000005462060

Symptom	Inspection item
Climate controlled seat inoperative.	Power supply and ground circuit Refer to SE-7, "CLIMATE CONTROLLED SEAT CONTROL UNIT : Diagnosis Procedure" .
Climate controlled seat blower motor inoperative.	Climate controlled seat blower motor Refer to SE-11, "Diagnosis Procedure" .
Seat cushion thermal electric device inoperative.	Seat cushion thermal electric device Refer to SE-14, "Diagnosis Procedure" .
Seatback thermal electric device inoperative.	Seatback thermal electric device Refer to SE-17, "Diagnosis Procedure" .
Climate controlled seat switch LO, MED or HI inoperative.	Climate controlled seat switch Refer to SE-20, "Diagnosis Procedure" .
Climate controlled seat switch indicator inoperative.	Climate controlled seat switch indicator Refer to SE-23, "Diagnosis Procedure" .

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000005462061



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of the customer's comments; refer to [SE-57, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by a test drive with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Engine Ear or mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that is are suspected to be the cause of the noise.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that is are suspected to be the cause of the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration by hand by touching the component(s) that is are suspected to be the cause of the noise.
 - Placing a piece of paper between components that is are suspected to be the cause of the noise.
 - Looking for loose components and contact marks.
Refer to [SE-55, "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - Separate components by repositioning or loosening and retightening the component, if possible.
 - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. These insulators are available through the authorized Nissan Parts Department.

CAUTION:

Never use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

- URETHANE PADS
Insulates connectors, harness, etc.
- INSULATOR (Foam blocks)
Insulates components from contact. Can be used to fill space behind a panel.
- INSULATOR (Light foam block)
- FELT CLOTH TAPE
Used to insulate where movement does not occur. Ideal for instrument panel applications.
The following materials, not available through NISSAN Parts Department, can also be used to repair squeaks and rattles.
- UHMW (TEFLON) TAPE
Insulates where slight movement is present. Ideal for instrument panel applications.
- SILICONE GREASE
Used in place of UHMW tape that is be visible or does not fit.
Note: Will only last a few months.
- SILICONE SPRAY
Used when grease cannot be applied.
- DUCT TAPE
Used to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Inspection Procedure

INFOID:000000005462062

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. The areas can usually be insulated with felt cloth tape or insulator foam blocks to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for the following:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. Trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SEATS

When isolating seat noise it is important to note the position the seat is in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. Rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Diagnostic Worksheet

INFOID:000000005462063





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAI0071E

PRECAUTIONS

< PRECAUTION >

[WITH CLIMATE CONTROLLED SEATS]

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005462064

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions Necessary for Steering Wheel Rotation after Battery Disconnect (Early Production, With Electronic Steering Column Lock)

INFOID:000000005885928

NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Carry the Intelligent Key or insert it to the key slot and turn the push-button ignition switch to ACC position. (At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

[WITH CLIMATE CONTROLLED SEATS]

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

Service Notice

INFOID:000000005462066

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Precaution for Work

INFOID:000000005462067

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
 - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
 - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Never use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

[WITH CLIMATE CONTROLLED SEATS]

< PREPARATION >

PREPARATION



PREPARATION

Special Service Tool

INFOID:000000005462068

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.




Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit	Repairing the cause of noise



Commercial Service Tools

INFOID:000000005462069

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	Locating the noise
Remover tool	Remove clips, pawls and metal clips
Hook and pick tool	Remove the snap pins



FRONT SEAT

< ON-VEHICLE REPAIR >

[WITH CLIMATE CONTROLLED SEATS]

ON-VEHICLE REPAIR


FRONT SEAT

Exploded View

INFOID:000000005462070

DRIVER'S POWER SEAT

SEC. 870



ALIIA0320GB

FRONT SEAT

< ON-VEHICLE REPAIR >

[WITH CLIMATE CONTROLLED SEATS]

1. Seatback board	2. Seatback board clips	3. Seat cushion rear finisher	A
4. Driver seat wiring harness	5. Seat cushion inner finisher inside	6. Reclining device inner cover	
7. Seat cushion inner finisher	8. Seat belt buckle	9. Seat cushion trim and cushion	
10. Thigh extension tethers	11. Thigh extension assembly	12. Seat cushion front finisher	B
13. Front slide cover	14. Climate controlled seat control unit	15. Driver seat control unit	
16. Seat cushion thermal electric device (TED)	17. Lower seat duct	18. Seat frame	
19. Rear slide cover	20. Climate controlled seat blower motor filter	21. Climate controlled seat blower motor	C
22. Seat control switch	23. Seat slide and lifter switch knob	24. Reclining switch knob	
25. Seat lumbar switch	26. Seat cushion outer finisher	27. Reclining device outer cover	D
28. Seat cushion outer finisher inside	29. Seatback assembly	30. Seatback thermal electric device (TED)	
31. Upper seat duct	32. Headrest holder (locked)	33. Headrest holder (free)	E
34. Headrest			

PASSENGER'S POWER SEAT

F

G

H

I

SE

K

L

M

N

O


P

FRONT SEAT

< ON-VEHICLE REPAIR >

[WITH CLIMATE CONTROLLED SEATS]

SEC. 870



ALIA0321GB

- | | | |
|----------------------------------|--|--------------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Headrest |
| 4. Passenger seat wiring harness | 5. Seat cushion outer finisher inside | 6. Reclining device inner cover |
| 7. Seat cushion outer finisher | 8. Reclining switch knob | 9. Seat slide and lifter switch knob |
| 10. Seat control switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Seat frame | 15. Seat cushion inner finisher |
| 16. Reclining device inner cover | 17. Seat cushion inner finisher inside | 18. Seat belt buckle |

FRONT SEAT

[WITH CLIMATE CONTROLLED SEATS]

< ON-VEHICLE REPAIR >

19. Seatback assembly

20. Rear slide cover

21. Headrest holder (locked)

22. Headrest holder (free)

Removal and Installation

INFOID:000000005462071

CAUTION:


- When removing and installing, use shop cloths to protect parts from damage.

REMOVAL


NOTE:

Confirm the position of connector before starting work.


1. Slide the seat to the front most position.
2. Remove the side fixing points (A).



3. Remove the rear slide covers.
4. Remove the rear mount bolts.



5. Slide the seat to the rear most position.
6. Remove the front slide covers.
7. Remove the front mount bolts.



8. Disconnect battery negative and positive terminals.

CAUTION:

- Disconnect battery negative and positive terminals then wait for at least 3 minutes.

9. Disconnect harness connector under the seat and remove harness clamps.
10. Remove seat from the vehicle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


FRONT SEAT

< ON-VEHICLE REPAIR >


[WITH CLIMATE CONTROLLED SEATS]

Clamp the harness in position.

- When installing the front seats tighten the driver seat bolts in the specified order as shown.



- When installing the front seats tighten the passenger seat bolts in the specified order as shown.



REAR SEAT

< ON-VEHICLE REPAIR >


[WITH CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Bucket Seat

INFOID:000000005462072

SEC. 880



- 1. Headrest
- 4. Seatback frame

- 2. Headrest holder (free)
- 3. Headrest holder (locked)
- 5. Bumper
- 6. Seatback pad

- 7. Seatback frame
- 8. Seatback pad
- 9. Seatback frame
- 10. Seatback pad
- 11. Seatback frame

AWJIA0461ZZ

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT

[WITH CLIMATE CONTROLLED SEATS]

< ON-VEHICLE REPAIR >

- | | | |
|------------------------|-----------------------|---------------------|
| 7. Seatback trim | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion frame | 11. Seatback assembly | |

Removal and Installation


INFOID:000000005462073

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

Seat Cushion Removal

1. Pull the lock lever (1) at the front bottom of the seat cushion forward (one for each side), and pull the seat cushion upward to release the wire (2) from the seat cushion hook. Then pull the seat cushion forward to remove.
2. Remove the seat cushion from the vehicle.




Installation


Installation is in the reverse order of removal.

Seatback Removal

1. Remove the seat cushion.
2. Remove the headrest assemblies.
3. Remove the seatback frame bolts and nut.



4. Disconnect the harness connectors.
5. Lift the seatback to disengage seat hook wires from the hangers.



INSTALLATION

Installation is in the reverse order of removal.

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

DISASSEMBLY AND ASSEMBLY

FRONT SEAT

DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:000000005462074

DRIVER'S POWER SEAT

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O


P

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

SEC. 870



ALIHA0320GB

- | | | |
|--------------------------------|--|----------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Seat cushion rear finisher |
| 4. Driver seat wiring harness | 5. Seat cushion inner finisher inside | 6. Reclining device inner cover |
| 7. Seat cushion inner finisher | 8. Seat belt buckle | 9. Seat cushion trim and cushion |
| 10. Thigh extension tethers | 11. Thigh extension assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Climate controlled seat control unit | 15. Driver seat control unit |

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

- | | | |
|--|---|--|
| 16. Seat cushion thermal electric device (TED) | 17. Lower seat duct | 18. Seat frame |
| 19. Rear slide cover | 20. Climate controlled seat blower motor filter | 21. Climate controlled seat blower motor |
| 22. Seat control switch | 23. Seat slide and lifter switch knob | 24. Reclining switch knob |
| 25. Seat lumbar switch | 26. Seat cushion outer finisher | 27. Reclining device outer cover |
| 28. Seat cushion outer finisher inside | 29. Seatback assembly | 30. Seatback thermal electric device (TED) |
| 31. Upper seat duct | 32. Headrest holder (locked) | 33. Headrest holder (free) |
| 34. Headrest | | |


DRIVER SIDE : Disassembly and Assembly

INFOID:000000005462075

SEATBACK BOARD

Disassembly

1. Remove the seat from the vehicle. Refer to [SE-65. "Removal and Installation"](#)
2. Release the clips (D) from the seat cushion springs.
3. Pull the bottom of the backboard upward enough to release the inner clips (C).
4. Insert the proper tool to release the pawls (B).
5. Pull the backboard downward to disengage the hooks (A) and remove the backboard.




Assembly

Assembly is in the reverse order of disassembly.

SEATBACK THERMAL ELECTRIC DEVICE AND UPPER SEAT DUCT

Disassembly

1. Remove the seat from the vehicle. Refer to [SE-65. "Removal and Installation"](#)
2. Remove seatback board.
3. Remove seat cushion finisher.
4. Disconnect wiring harness (A) from the heater control unit (B).
5. Remove thermal electric device mounting bolts (C).
6. Disconnect the thermal electric device from upper seat duct (D) and remove from seat.
7. Disconnect upper seat duct (E) from lower seat duct and remove upper seat duct from seat.



Assembly


Assembly is in the reverse order of disassembly.

SEAT CUSHION THERMAL ELECTRIC DEVICE AND LOWER SEAT DUCT

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]



- | | | |
|---|---|----------------------|
| 1. Driver seat control unit | 2. Lower seat duct | 3. Seat wire harness |
| 4. Climate controlled seat blower motor | 5. Seat cushion thermal electric device | 6. Upper seat duct |

Disassembly

1. Remove the seat from the vehicle. Refer to [SE-65, "Removal and Installation"](#)
2. Remove seatback board.
3. Remove seat cushion finisher.
4. Disconnect wire harness connectors from driver seat control unit.
5. Remove driver seat control unit from seat.
6. Remove seat cushion thermal electric device bolts.
7. Remove climate controlled seat blower motor bolts.
8. Disconnect climate controlled seat blower motor from upper seat duct.
9. Remove climate controlled seat blower motor, lower seat duct and seat cushion thermal electric device from seat.

Assembly

Assembly is in the reverse order of disassembly.

THIGH EXTENSION ASSEMBLY


Disassembly

FRONT SEAT


< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]


1. Move the thigh extension to the front most position and release the trim cover clips (A).
2. Remove the trim cover and foam (B).



3. Cut the thigh extension tethers and drill out the upper rivets (A) that connect the thigh extension tethers (B) to the thigh extension assembly (C).




4. Insert suitable tool into the thigh extension top panel and release the clip (A).
5. Pull the thigh extension handle and remove the thigh extension assembly.



6. Drill out the lower rivets that connect the thigh extension tethers to the seat frame assembly.

Assembly

1. Replace the trim cover and clips and foam to the thigh extension assembly.
2. Rivet the thigh extension tethers to the seat frame assembly mounting hole (A).




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT


< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

3. Align the thigh extension assembly on the top rail.
4. Lift the thigh extension handle and slide the thigh extension assembly onto the seat.



5. Rivet the thigh extension tethers to the thigh extension assembly mounting hole (A).



PASSENGER SIDE

PASSENGER SIDE : Exploded View

INFOID:000000005462076


PASSENGER'S POWER SEAT

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

SEC. 870



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

- | | | |
|----------------------------------|--|--------------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Headrest |
| 4. Passenger seat wiring harness | 5. Seat cushion outer finisher inside | 6. Reclining device inner cover |
| 7. Seat cushion outer finisher | 8. Reclining switch knob | 9. Seat slide and lifter switch knob |
| 10. Seat control switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Seat frame | 15. Seat cushion inner finisher |
| 16. Reclining device inner cover | 17. Seat cushion inner finisher inside | 18. Seat belt buckle |

ALIA0321GB

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

19. Seatback assembly

20. Rear slide cover

21. Headrest holder (locked)

22. Headrest holder (free)

PASSENGER SIDE : Disassembly

INFOID:000000005462077


NOTE:

If the vehicle has been involved in a collision, the seat must be inspected for damage. Refer to [SR-20, "For Frontal Collision"](#).

SEATBACK BOARD

Disassembly

1. Remove the seat from the vehicle. Refer to [SE-65, "Removal and Installation"](#)
2. Release the clips (D) from the seat cushion springs.
3. Pull the bottom of the backboard upward enough to release the inner clips (C).
4. Insert the proper tool to release the pawls (B).
5. Pull the backboard downward to disengage the hooks (A) and remove the backboard.



Assembly

Assembly is in the reverse order of disassembly.

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >


[WITH CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Bucket Seat

INFOID:000000005462078

SEC. 880



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

- | | | |
|-------------------|---------------------------|-----------------------------|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Seatback frame | 5. Bumper | 6. Seatback pad |

AWJIA0461ZZ

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

- | | | |
|------------------------|-----------------------|---------------------|
| 7. Seatback trim | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion frame | 11. Seatback assembly | |


ARMREST

ARMREST : Disassembly and Assembly

INFOID:000000005462079

Disassembly

1. Remove the seat cushion and rear seatback. Refer to [SE-68, "Removal and Installation"](#)
2. Remove armrest bolts (A) and remove the armrest assembly.



Assembly

Assembly is in the reverse order of disassembly.

POWER SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]


COMPONENT DIAGNOSIS

POWER SEAT

Wiring Diagram - POWER SEAT FOR DRIVER SIDE -

INFOID:000000005531970

POWER SEAT FOR DRIVER SIDE - WITHOUT AUTOMATIC DRIVE POSITIONER




ABJWA0136GE

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER

Terminal No.	Color of Wire	Signal Name
20J	R/Y	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	B	GND1

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

ABJIA0241GB


POWER SEAT

< COMPONENT DIAGNOSIS >


[W/O CLIMATE CONTROLLED SEATS]

Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


ABJIA0383GB

POWER SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

Connector No.	B209
Connector Name	POWER SEAT SWITCH LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	O	-
3	R/Y	-
4	B	-
5	GR	-
6	V	-
7	Y	-
8	B	-
9	R	-
10	V	-

Connector No.	B207
Connector Name	RECLINING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	O	-
2	GR	-

Connector No.	B204
Connector Name	FRONT POWER SEAT LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	SLIDER MOTOR
2	R	REAR LIFTER MOTOR
3	V	SLIDER MOTOR
4	GR	FRONT LIFTER MOTOR
5	O	FRONT LIFTER MOTOR
6	B/W	REAR LIFTER MOTOR

ABJIA0384GB

POWER SEAT


< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

Wiring Diagram - POWER SEAT FOR PASSENGER SIDE -

INFOID:000000005531971

POWER SEAT FOR PASSENGER SIDE



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

ABJWA0137GE


POWER SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]


POWER SEAT FOR PASSENGER SIDE CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	R/Y	-

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	B	GND1

POWER SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]


Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	SB	-

Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B307
Connector Name	RECLINING MOTOR RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	GR	-

Connector No.	B306
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	Y	-

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
7	SB	-

ABJIA0385GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT

< COMPONENT DIAGNOSIS >


[W/O CLIMATE CONTROLLED SEATS]

Connector No.	B309
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	R/Y	-
4	B	-
5	W	-
6	V	-
7	Y	-
8	-	-
9	-	-
10	GR	-

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
7	R/Y	-

AAJIA0024GB

HEATED SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]


HEATED SEAT

Wiring Diagram - HEATED SEAT -

INFOID:000000005531972

◊AD◊ : WITH AUTOMATIC DRIVE POSITIONER
 ◊CT◊ : WITHOUT CLIMATE CONTROLLED SEAT
 ◊XA◊ : WITHOUT AUTOMATIC DRIVE POSITIONER
 *1
 ◊AD◊ : 7
 ◊XA◊ : 4

HEATED SEAT



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

ABJWA0138GE


HEATED SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]


HEATED SEAT CONNECTORS

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8M	G/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18J	GR	-
19J	GR/R	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	GR/L	-
4	GR/B	-

Connector No.	M87
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
6	GR	-
9	GR/L	-
14	GR/R	-
15	B	-
16	G/R	-

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
6	GR	-
9	GR/L	-
14	GR/R	-
15	B	-
16	G/R	-

HEATED SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

Connector No.	M301
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	W	-
3	O	-
4	B	-

Connector No.	M300
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	SB	-
2	G	-
3	GR	-
4	B	-

Connector No.	M208
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
5	GR/R	-
6	B	-
7	G/R	-
9	GR/L	-
15	GR	-

Connector No.	M305
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
3	GR	-
5	O	-
6	B	-
7	P	-
9	G	-
15	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT

< COMPONENT DIAGNOSIS >


[W/O CLIMATE CONTROLLED SEATS]

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G	-
4	B	-
6	GR	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
4	GR	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	W	-
4	B	-
6	O	-
7	B/W	-

Connector No.	B304
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR/G	-
2	GR/R	-
3	B	-

Connector No.	B210
Connector Name	FRONT SEAT HEATER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR/W	-
3	W/B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
4	B	-
6	GR/W	-
7	GR/B	-

ABJIA0382GB


HEATED SEAT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR/G	-
4	B	-
6	GR/R	-

AAJIA0028GB

LUMBAR SUPPORT

< COMPONENT DIAGNOSIS >


[W/O CLIMATE CONTROLLED SEATS]

LUMBAR SUPPORT

Wiring Diagram - LUMBAR SUPPORT SYSTEM -

INFOID:000000005531973

LUMBAR SUPPORT SYSTEM



AAJWA0013GE


LUMBAR SUPPORT

< COMPONENT DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]


LUMBAR SUPPORT SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	B	GND1




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

LUMBAR SUPPORT

< COMPONENT DIAGNOSIS >


[W/O CLIMATE CONTROLLED SEATS]

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	B221
Connector Name	LUMBAR SUPPORT MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-99, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lowerpitch noises/edge to surface = chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.Refer to [SE-97. "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit. Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000005462085

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Acrylic lens and combination meter housing
2. Instrument panel to front pillar finishers
3. Instrument panel to windshield
4. Instrument panel mounting pins
5. Wiring harnesses behind the combination meter
6. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition, look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.
3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

Diagnostic Worksheet

INFOID:000000005462086





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAI0071E

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005462087

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions Necessary for Steering Wheel Rotation after Battery Disconnect (Early Production, With Electronic Steering Column Lock)

INFOID:000000005885930

NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Carry the Intelligent Key or insert it to the key slot and turn the push-button ignition switch to ACC position. (At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >

[W/O CLIMATE CONTROLLED SEATS]

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

Service Notice

INFOID:000000005462089

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Precaution for Work

INFOID:000000005462090

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
 - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
 - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[W/O CLIMATE CONTROLLED SEATS]

PREPARATION



PREPARATION

Special Service Tool

INFOID:000000005462091

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.




Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit	Repairing the cause of noise



Commercial Service Tool

INFOID:000000005462092

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	Locating the noise
Remover tool	Remove clips, pawls and metal clips
Hook and pick tool	Remove the snap pins



FRONT SEAT

< ON-VEHICLE REPAIR >

[W/O CLIMATE CONTROLLED SEATS]

ON-VEHICLE REPAIR


FRONT SEAT

Exploded View

INFOID:000000005462093

DRIVER'S POWER SEAT

SEC. 870



ALIIA0339ZZ

FRONT SEAT

< ON-VEHICLE REPAIR >

[W/O CLIMATE CONTROLLED SEATS]

1. Headrest	2. Headrest holder (free)	3. Headrest holder (locked)	A
4. Seatback board	5. Seatback board clips	6. Seat cushion inner finisher inside	
7. Reclining device inner cover	8. Seat cushion inner finisher	9. Seat belt buckle	
10. Seat cushion trim and cushion	11. Thigh extension tethers	12. Thigh extension assembly (if equipped)	B
13. Seat cushion trim and pad (w/o thigh extension)	14. Driver seat wiring harness	15. Seat cushion front finisher	
16. Front slide cover	17. Seat frame	18. Driver seat control unit	C
19. Actuator bracket	20. Rear slide cover	21. Seat control switch	
22. Seat slide and lifter switch knob	23. Reclining switch knob	24. Seat lumbar switch (power)	D
25. Lumbar lever (manual)	26. Seat cushion outer finisher	27. Reclining device outer cover	
28. Seat cushion outer finisher inside	29. Seatback assembly		

PASSENGER'S POWER SEAT

E

F

G

H

I

SE

K

L

M

N

O


P

FRONT SEAT

< ON-VEHICLE REPAIR >

[W/O CLIMATE CONTROLLED SEATS]

SEC. 870



ALIIA0321GB

- | | | |
|----------------------------------|--|--------------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Headrest |
| 4. Passenger seat wiring harness | 5. Seat cushion outer finisher inside | 6. Reclining device inner cover |
| 7. Seat cushion outer finisher | 8. Reclining switch knob | 9. Seat slide and lifter switch knob |
| 10. Seat control switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Seat frame | 15. Seat cushion inner finisher |
| 16. Reclining device inner cover | 17. Seat cushion inner finisher inside | 18. Seat belt buckle |

FRONT SEAT

< ON-VEHICLE REPAIR >

[W/O CLIMATE CONTROLLED SEATS]

- 19. Seatback assembly
- 22. Headrest holder (free)

- 20. Rear slide cover

- 21. Headrest holder (locked)

Removal and Installation

INFOID:000000005462094

CAUTION:


- When removing and installing, use shop cloths to protect parts from damage.

REMOVAL


NOTE:

Confirm the position of connector before starting work.


1. Slide the seat to the front most position.
2. Remove the side fixing points (A).



3. Move the cover backward and remove the rear slide covers.
4. Remove the rear mount bolts.



5. Slide the seat to the rear most position.
6. Remove the front slide covers.
7. Remove the front mount bolts.



8. Disconnect battery negative and positive terminals.

CAUTION:

- Disconnect battery negative and positive terminals then wait for at least 3 minutes.

9. Disconnect harness connector under the seat and remove harness clamps.
10. Remove seat from the vehicle.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


FRONT SEAT

< ON-VEHICLE REPAIR >


[W/O CLIMATE CONTROLLED SEATS]

Clamp the harness in position.

- When installing the front seats tighten the driver seat bolts in the specified order as shown.



- When installing the front seats tighten the passenger seat bolts in the specified order as shown.



REAR SEAT

< ON-VEHICLE REPAIR >


[W/O CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Bucket Seat

INFOID:000000005462095

SEC. 880



- | | | |
|-------------------|---------------------------|-----------------------------|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Seatback frame | 5. Bumper | 6. Seatback pad |

AWJIA0461ZZ

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT

< ON-VEHICLE REPAIR >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|------------------------|-----------------------|---------------------|
| 7. Seatback trim | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion frame | 11. Seatback assembly | |

Removal and Installation


INFOID:000000005462096

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

Seat Cushion Removal

1. Pull the lock lever (1) at the front bottom of the seat cushion forward (one for each side), and pull the seat cushion upward to release the wire (2) from the seat cushion hook. Then pull the seat cushion forward to remove.
2. Remove the seat cushion from the vehicle.




Installation


Installation is in the reverse order of removal.

Seatback Removal

1. Remove the seat cushion.
2. Remove the headrest assemblies.
3. Remove the seatback frame bolts and nut.



4. Disconnect the harness connectors.
5. Lift the seatback to disengage seat hook wires from the hangers.



INSTALLATION

Installation is in the reverse order of removal.


REAR SEAT

< ON-VEHICLE REPAIR >

[W/O CLIMATE CONTROLLED SEATS]

Exploded View - Bench Seat

INFOID:000000005462097



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

- | | | |
|------------------------------|--------------------------------|---------------------------------|
| 1. Headrest | 2. Headrest holder (locked) | 3. Headrest holder (free) |
| 4. Seat lock covers | 5. Seat lock assemblies | 6. Seat belt hooks |
| 7. Halo upper frame assembly | 8. RH booster trim and pad | 9. RH seatback frame |
| 10. Seatback latch striker | 11. RH seatback pad and trim | 12. Armrest outer bracket |
| 13. Armrest frame | 14. Back inner armrest bracket | 15. Front inner armrest bracket |

REAR SEAT

< ON-VEHICLE REPAIR >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|---------------------------------|--------------------------------|-------------------------------|
| 16. Bumper | 17. Armrest cupholder assembly | 18. Armrest assembly |
| 19. Right inner armrest bracket | 20. Left inner armrest bracket | 21. Seat cushion hook |
| 22. Seat cushion and trim | 23. Seat cushion frame | 24. Halo lower frame assembly |
| 25. LH seatback pad and trim | 26. Seatback latch striker | 27. LH seatback frame |
| 28. LH booster trim and pad | A. Mounting screw | |

Removal and Installation

INFOID:000000005462098


CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

BENCH SEAT CUSHION

Removal

1. Pull the lock lever (1) at the front bottom of the seat cushion forward (one for each side), and pull the seat cushion upward to release the wire (2) from the seat cushion hook. Then pull the seat cushion forward to remove.
2. Remove the seat cushion from the vehicle.




Installation

Installation is in the reverse order of removal.


BENCH SEATBACK

Removal

1. Lock seatbacks in upright position.
2. Remove the lower frame halo anchor bolts and nut.
3. Fold seatbacks forward.



4. Remove latch covers (A).
5. Remove upper frame halo bolts (B).
6. Remove the seatback assembly.



Installation

Installation is in the reverse order of removal.

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

DISASSEMBLY AND ASSEMBLY


FRONT SEAT

DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:000000005462099

SEC. 870



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|---|---------------------------------|--|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Seatback board | 5. Seatback board clips | 6. Seat cushion inner finisher inside |
| 7. Reclining device inner cover | 8. Seat cushion inner finisher | 9. Seat belt buckle |
| 10. Seat cushion trim and cushion | 11. Thigh extension tethers | 12. Thigh extension assembly (if equipped) |
| 13. Seat cushion trim and pad (w/o thigh extension) | 14. Driver seat wiring harness | 15. Seat cushion front finisher |
| 16. Front slide cover | 17. Seat frame | 18. Driver seat control unit |
| 19. Actuator bracket | 20. Rear slide cover | 21. Seat control switch |
| 22. Seat slide and lifter switch knob | 23. Reclining switch knob | 24. Seat lumbar switch (power) |
| 25. Lumbar lever (manual) | 26. Seat cushion outer finisher | 27. Reclining device outer cover |
| 28. Seat cushion outer finisher inside | 29. Seatback assembly | |


DRIVER SIDE : Disassembly and Assembly

INFOID:000000005462100

SEATBACK BOARD

Disassembly

1. Remove the seat from the vehicle. Refer to [SE-107. "Removal and Installation"](#)
2. Release the clips (D) from the seat cushion springs.
3. Pull the bottom of the backboard upward enough to release the inner clips (C).
4. Insert the proper tool to release the pawls (B).
5. Pull the backboard downward to disengage the hooks (A) and remove the backboard.




Assembly

Assembly is in the reverse order of disassembly.

THIGH EXTENSION ASSEMBLY

Disassembly

1. Move the thigh extension to the front most position and release the trim cover clips (A).
2. Remove the trim cover and foam (B).




FRONT SEAT


< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

3. Cut the thigh extension tethers and drill out the upper rivets (A) that connect the thigh extension tethers (B) to the thigh extension assembly (C).




4. Insert suitable tool into the thigh extension top panel and release the clip (A).
5. Pull the thigh extension handle and remove the thigh extension assembly.




6. Drill out the lower rivets that connect the thigh extension tethers to the seat frame assembly.

Assembly

1. Replace the trim cover and clips and foam to the thigh extension assembly.
2. Rivet the thigh extension tethers to the seat frame assembly mounting hole (A).



3. Align the thigh extension assembly on the top rail.
4. Lift the thigh extension handle and slide the thigh extension assembly onto the seat.




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

5. Rivet the thigh extension tethers to the thigh extension assembly mounting hole (A).



PASSENGER SIDE

FRONT SEAT


< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

PASSENGER SIDE : Exploded View

INFOID:000000005462101

SEC. 870



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

- | | | |
|----------------------------------|---------------------------------------|--------------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Headrest |
| 4. Passenger seat wiring harness | 5. Seat cushion outer finisher inside | 6. Reclining device inner cover |
| 7. Seat cushion outer finisher | 8. Reclining switch knob | 9. Seat slide and lifter switch knob |
| 10. Seat control switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |

ALIA0321GB

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|----------------------------------|--|---------------------------------|
| 13. Front slide cover | 14. Seat frame | 15. Seat cushion inner finisher |
| 16. Reclining device inner cover | 17. Seat cushion inner finisher inside | 18. Seat belt buckle |
| 19. Seatback assembly | 20. Rear slide cover | 21. Headrest holder (locked) |
| 22. Headrest holder (free) | | |

PASSENGER SIDE : Disassembly

INFOID:000000005462102


NOTE:

If the vehicle has been involved in a collision, the seat must be inspected for damage. Refer to [SR-20, "For Frontal Collision"](#).

SEATBACK BOARD

Disassembly

1. Remove the seat from the vehicle. Refer to [SE-107, "Removal and Installation"](#)
2. Release the clips (D) from the seat cushion springs.
3. Pull the bottom of the backboard upward enough to release the inner clips (C).
4. Insert the proper tool to release the pawls (B).
5. Pull the backboard downward to disengage the hooks (A) and remove the backboard.



Assembly

Assembly is in the reverse order of disassembly.

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >


[W/O CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Bucket Seat

INFOID:000000005462103

SEC. 880



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

- | | | |
|-------------------|---------------------------|-----------------------------|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Seatback frame | 5. Bumper | 6. Seatback pad |

AWJIA0461ZZ

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|------------------------|-----------------------|---------------------|
| 7. Seatback trim | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion frame | 11. Seatback assembly | |


ARMREST

ARMREST : Disassembly and Assembly

INFOID:000000005462104

Disassembly

1. Remove the seat cushion and rear seatback. Refer to [SE-68, "Removal and Installation"](#)
2. Remove armrest bolts (A) and remove the armrest assembly.



Assembly

Assembly is in the reverse order of disassembly.


REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

Exploded View - Bench Seat

INFOID:000000005462105



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

- | | | |
|------------------------------|--------------------------------|---------------------------------|
| 1. Headrest | 2. Headrest holder (locked) | 3. Headrest holder (free) |
| 4. Seat lock covers | 5. Seat lock assemblies | 6. Seat belt hooks |
| 7. Halo upper frame assembly | 8. RH booster trim and pad | 9. RH seatback frame |
| 10. Seatback latch striker | 11. RH seatback pad and trim | 12. Armrest outer bracket |
| 13. Armrest frame | 14. Back inner armrest bracket | 15. Front inner armrest bracket |

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

-
- | | | |
|---------------------------------|---------------------------------|-------------------------------|
| 16. Bumper | 17. Armrest cup holder assembly | 18. Armrest assembly |
| 19. Right inner armrest bracket | 20. Left inner armrest bracket | 21. Seat cushion hook |
| 22. Seat cushion and trim | 23. Seat cushion frame | 24. Halo lower frame assembly |
| 25. LH seatback pad and trim | 26. Seatback latch striker | 27. LH seatback frame |
| 28. LH booster trim and pad | A. Mounting screw | |