

SECTION **SE**
SEAT

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CONTENTS

WITH CLIMATE CONTROLLED SEATS	Description	18
BASIC INSPECTION	Component Function Check	18
DIAGNOSIS AND REPAIR WORK FLOW	Diagnosis Procedure	18
Work Flow	Component Inspection (Thermal Electric Device)....	19
SYSTEM DESCRIPTION	CLIMATE CONTROLLED SEAT SWITCH	20
CLIMATE CONTROLLED SEAT SYSTEM	Description	20
System Diagram	Component Function Check	20
System Description	Diagnosis Procedure	20
Component Parts Location	Component Inspection (Climate Controlled Seat	
Component Description	Switch)	21
DTC/CIRCUIT DIAGNOSIS	CLIMATE CONTROLLED SEAT SWITCH IN-	
POWER SUPPLY AND GROUND CIRCUIT	DICATOR	23
CLIMATE CONTROLLED SEAT CONTROL UNIT	Description	23
CLIMATE CONTROLLED SEAT CONTROL UNIT	Component Function Check	23
: Diagnosis Procedure	Diagnosis Procedure	23
CLIMATE CONTROLLED SEAT CONTROL UNIT	Component Inspection (Climate Controlled Seat	
: Component Inspection (Climate Controlled Seat	Switch Indicator)	24
Relay)	ECU DIAGNOSIS INFORMATION	25
10	CLIMATE CONTROLLED SEAT CONTROL	
CLIMATE CONTROLLED SEAT BLOWER	UNIT	25
MOTOR	Reference Value	25
Description	Fail-safe	26
Component Function Check	WIRING DIAGRAM	28
Diagnosis Procedure	POWER SEAT FOR DRIVER SIDE	28
Component Inspection (Climate Controlled Seat	Wiring Diagram - Without Automatic Drive Posi-	
Blower Motor)	tioner	28
14	POWER SEAT FOR PASSENGER SIDE	32
SEAT CUSHION THERMAL ELECTRIC DE-	Wiring Diagram	32
VICE	HEATED SEAT	36
Description	Wiring Diagram	36
Component Function Check	LUMBAR SUPPORT SYSTEM	41
Diagnosis Procedure	Wiring Diagram	41
Component Inspection (Thermal Electric Device)...	CLIMATE CONTROLLED SEAT	44
16		
SEATBACK THERMAL ELECTRIC DEVICE		
18		

Wiring Diagram	44
SYMPTOM DIAGNOSIS	51
CLIMATE CONTROLLED SEAT SYSTEM	51
Symptom Table	51
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	52
Work Flow	52
Generic Squeak and Rattle Troubleshooting	53
Diagnostic Worksheet	56
PRECAUTION	58
PRECAUTIONS	58
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	58
Service Notice	58
Precaution for Work	58
PREPARATION	60
PREPARATION	60
Special Service Tools	60
Commercial Service Tools	60
CLIP LIST	61
Descriptions for Clips	61
REMOVAL AND INSTALLATION	65
FRONT SEAT	65
Exploded View	65
Removal and Installation	68
REAR SEAT	70
Exploded View - Fixed Seatback	70
Removal and Installation	70
Exploded View - 60:40 Split Seatback	72
Removal and Installation	73
CLIMATE CONTROLLED SEAT BLOWER FILTER	75
Removal and Installation	75
UNIT DISASSEMBLY AND ASSEMBLY ...	76
FRONT SEAT	76
DRIVER SIDE	76
DRIVER SIDE : Exploded View	76
DRIVER SIDE : Disassembly and Assembly	77
PASSENGER SIDE	84
PASSENGER SIDE : Exploded View	85
PASSENGER SIDE : Disassembly and Assembly ..	86
REAR SEAT	91
Exploded View - Fixed Seatback	91
Exploded View - 60:40 Split Seatback	91

W/O CLIMATE CONTROLLED SEATS	
WIRING DIAGRAM	94
POWER SEAT FOR DRIVER SIDE	94
Wiring Diagram - Without Automatic Drive Posi- tioner	94
POWER SEAT FOR PASSENGER SIDE	98
Wiring Diagram	98
HEATED SEAT	102
Wiring Diagram	102
LUMBAR SUPPORT SYSTEM	107
Wiring Diagram	107
SYMPTOM DIAGNOSIS	110
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	110
Work Flow	110
Generic Squeak and Rattle Troubleshooting	112
Diagnostic Worksheet	114
PRECAUTION	116
PRECAUTIONS	116
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	116
Service Notice	116
Precaution for Work	116
PREPARATION	118
PREPARATION	118
Special Service Tools	118
Commercial Service Tool	118
CLIP LIST	119
Descriptions for Clips	119
REMOVAL AND INSTALLATION	123
FRONT SEAT	123
Exploded View	123
Removal and Installation	126
REAR SEAT	128
Exploded View - Fixed Seatback	128
Removal and Installation	128
Exploded View - 60:40 Split Seatback	130
Removal and Installation	131
UNIT DISASSEMBLY AND ASSEMBLY ..	133
FRONT SEAT	133
DRIVER SIDE	133
DRIVER SIDE : Exploded View	133
DRIVER SIDE : Disassembly and Assembly	134

PASSENGER SIDE	139	REAR SEAT	146	
PASSENGER SIDE : Exploded View	140	Exploded View - Fixed Seatback	146	A
PASSENGER SIDE : Disassembly and Assembly.	141	Exploded View - 60:40 Split Seatback	146	

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000010049458

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected. Refer to [SE-51, "Symptom Table"](#).

>> GO TO 3.

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORK FLOW

[WITH CLIMATE CONTROLLED SEATS]

< BASIC INSPECTION >

Is malfunctioning part detected?

YES >> GO TO 4.

NO >> GO TO 2.

4. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5.

5. FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

CLIMATE CONTROLLED SEAT SYSTEM


< SYSTEM DESCRIPTION >

[WITH CLIMATE CONTROLLED SEATS]

SYSTEM DESCRIPTION

CLIMATE CONTROLLED SEAT SYSTEM

System Diagram



System Description

INFOID:000000010049460

- The climate controlled seat system is controlled by the climate controlled seat control unit.
- Operation of the climate controlled seat switch sends heated or cooled airflow and adjusts the seat temperature.

SEAT CUSHION AND SEATBACK TEMPERATURE ADJUSTMENT FUNCTION

- A thermal electric device (TED) unit is installed in the seat cushion and seatback. The device heats or cools, sends airflow to the seat surface, and adjusts the seat temperature.
- The thermal electric device (TED) is a heat exchanger that has a function to heat or cool the airflow from the climate controlled seat blower motor. By changing the direction of the current from the power supply, the device takes or gives heat, and adjusts the heat exchange process depending on voltage.

NOTE:

The climate controlled seat blower motor maintains low speed for approximately 60 seconds after turning the climate controlled seat switch off.

CAUTION:

- **The thermal electric device has a dual-climate function that allows one side to operate at a high temperature and the other to operate at a low temperature simultaneously.**
- **Before starting work, always turn OFF the switch and check that the thermal electric device is cold.**

FAIL-SAFE

The fail-safe function is adopted for the climate controlled seat control unit. Refer to [SE-26, "Fail-safe"](#).


CLIMATE CONTROLLED SEAT SYSTEM

[WITH CLIMATE CONTROLLED SEATS]

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:0000000110049461



- | | | |
|--|--|--|
| 1. Climate controlled seat switch M302 | 2. Climate controlled seat relay M58 | 3. Seatback thermal electric device B218 |
| 4. Seat cushion thermal electric device B219 | 5. Climate controlled seat control unit B212, B216, B217 | 6. Climate controlled seat blower motor B220 |

Component Description

INFOID:0000000110049462

Item	Function
Climate controlled seat relay	Supplies power to the climate controlled seat control unit in accordance with the key switch position that is ON or OFF
Climate controlled seat control unit	Installed in the seat cushion backside and controls the climate controlled seat blower motor, seatback thermal electric device, and seat cushion thermal electric device in accordance with the input signal
Climate controlled seat switch	Installed in the center console and transmits signals to climate controlled seat control unit in accordance with the HEAT (heated airflow) or COOL (cooled airflow) switch operation and the temperature switch operation
Climate controlled seat blower motor	Installed in the seat cushion backside and sends the airflow to the seatback thermal electric device and seat cushion thermal electric device in accordance with the control from the climate controlled seat control unit
Seatback thermal electric device	Installed in the seatback backside and heats or cools the airflow from the climate controlled seat blower motor in accordance with the control from the climate controlled seat control unit
Seat cushion thermal electric device	Installed in the seat cushion backside and heats or cools the airflow from the climate controlled seat blower motor in accordance with the control from the climate controlled seat control unit

A
B
C
D
E
F
G
H
I
SE

K
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT CLIMATE CONTROLLED SEAT CONTROL UNIT

CLIMATE CONTROLLED SEAT CONTROL UNIT : Diagnosis Procedure

INFOID:000000010049463

Regarding Wiring Diagram information, refer to [SE-44, "Wiring Diagram"](#).

1. CHECK FUSES

Check for blown fuses.

System component	Power Source	Fuse or Fusible Link	Location
Climate controlled seat control unit	Ignition switch ON or START	3 (10A)	Fuse block (J/B)
	Battery	28 (15A)	Fuse and fusible link box
	Battery	H (40A)	Fuse and fusible link box

Is the inspection result normal?

YES >> GO TO 2.

NO >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link.

2. CHECK BATTERY POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit connector B217.
3. Check voltage between climate controlled seat control unit connector B217 terminal 29 and ground.

Connector	Terminal	Ground	Voltage (Approx.)
B217	29	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 6.



3. CHECK IGNITION POWER SUPPLY CIRCUIT

1. Disconnect climate controlled seat control unit connector B216.
2. Check voltage between climate controlled seat control unit connector B216 terminal 21 and ground.


Connector	Terminal	Ground	Ignition switch	Voltage (Approx.)
B216	21	—	OFF	0V
			ON	Battery voltage
			START	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

4. CHECK GROUND CIRCUIT



POWER SUPPLY AND GROUND CIRCUIT

[WITH CLIMATE CONTROLLED SEATS]


< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Check continuity between climate controlled seat control unit connector B217 terminal 30 and ground.

Connector	Terminal	Ground	Continuity
B217	30	—	Yes

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Repair the harness or connectors.



5. CHECK CLIMATE CONTROLLED SEAT RELAY

Perform the climate controlled seat relay component inspection. Refer to [SE-10, "CLIMATE CONTROLLED SEAT CONTROL UNIT : Component Inspection \(Climate Controlled Seat Relay\)"](#).

Is the inspection result normal?

- YES >> GO TO 8.
 NO >> Replace the climate controlled seat relay.


6. CHECK CIRCUIT BREAKER POWER SUPPLY CIRCUIT

1. Disconnect the circuit breaker connector M84.
2. Check voltage between circuit breaker connector M84 terminal 1 and ground.

Connector	Terminal	Ground	Voltage (Approx.)
M84	1	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 7.
 NO >> Repair the harness or connectors.




7. CHECK BATTERY POWER SUPPLY CIRCUIT FOR OPEN

Check continuity between circuit breaker connector M84 (A) terminal 2 and climate controlled seat control unit connector B217 (B) terminal 29.

Circuit Breaker		Climate Controlled Seat Control Unit		Continuity
Connector	Terminal	Connector	Terminal	
M84 (A)	2	B217 (B)	29	Yes

Is the inspection result normal?

- YES >> Replace the circuit breaker.
 NO >> Repair the harness or connectors.




8. CHECK CLIMATE CONTROLLED SEAT RELAY BATTERY POWER SUPPLY CIRCUIT

1. Disconnect climate controlled seat relay connector.
2. Check voltage between climate controlled seat relay connector M58 terminal 3 and ground.

Connector	Terminal	Ground	Voltage (Approx.)
M58	3	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 9.
 NO >> Repair the harness or connectors.



9. CHECK CLIMATE CONTROLLED SEAT RELAY IGNITION POWER SUPPLY CIRCUIT

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

Check voltage between climate controlled seat relay connector M58 terminal 2 and ground.

Connector	Terminal	Ground	Ignition switch	Voltage (Approx.)
M58	2	—	OFF	0V
			ON	Battery voltage
			START	Battery voltage

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair the harness or connectors.

10. CHECK IGNITION POWER SUPPLY CIRCUIT FOR OPEN

Check continuity between climate controlled seat relay connector M58 (A) terminal 5 and climate controlled seat control unit connector B216 (B) terminal 21.

Climate Controlled Seat Relay		Climate Controlled Seat Control Unit		Continuity
Connector	Terminal	Connector	Terminal	
M58 (A)	5	B216 (B)	21	Yes

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair the harness or connectors.

11. CHECK CLIMATE CONTROLLED SEAT RELAY GROUND CIRCUIT




Check continuity between climate controlled seat relay connector M58 terminal 1 and ground.

Connector	Terminal	Ground	Continuity
M58	1	—	Yes

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair the harness or connectors.



CLIMATE CONTROLLED SEAT CONTROL UNIT : Component Inspection (Climate Controlled Seat Relay)

INFOID:000000010049464

1. CHECK CLIMATE CONTROLLED SEAT RELAY

POWER SUPPLY AND GROUND CIRCUIT

[WITH CLIMATE CONTROLLED SEATS]


< DTC/CIRCUIT DIAGNOSIS >

1. Apply battery voltage between terminals 2 and 1 of the climate controlled seat relay.
CAUTION:
Connect a fuse between the terminals when applying battery voltage.
2. Check continuity between climate controlled seat relay terminals 5 and 3.

Climate Controlled Seat Relay Terminals	Condition	Continuity
5 and 3	Battery voltage applied between terminals 2 and 1.	Yes

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace climate controlled seat relay.



A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

CLIMATE CONTROLLED SEAT BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

CLIMATE CONTROLLED SEAT BLOWER MOTOR

Description

INFOID:000000010049465

Sends airflow to the seat cushion and seatback.

Component Function Check

INFOID:000000010049466

1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR FUNCTION

Turn the climate controlled seat switch to the H (Heat) LO, MED, and HI positions and the C (Cool) LO, MED, and HI positions. Check that the climate controlled seat blower motor operates at low, medium and high speed.

Is the inspection result normal?

YES >> Climate controlled seat blower motor function is OK.

NO >> Refer to [SE-12, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010049467

Regarding Wiring Diagram information, refer to [SE-44, "Wiring Diagram"](#).

1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR

Perform climate controlled seat blower motor component inspection. Refer to [SE-14, "Component Inspection \(Climate Controlled Seat Blower Motor\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace climate controlled seat blower motor. Refer to [SE-65, "Exploded View"](#).

2. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR POWER SUPPLY


1. Turn ignition switch ON.
2. Check voltage between climate controlled seat blower motor connector B220 terminal 2 and ground.

Climate controlled seat blower motor		Ground	Voltage (Approx.)
Connector	Terminal		
B220	2	—	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.


NO >> GO TO 3.



3. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat blower motor connector and climate controlled seat control unit connector B212.
3. Check continuity between climate controlled seat blower motor connector B220 (A) terminal 2 and climate controlled seat control unit connector B212 (B) terminal 7.

Climate controlled seat blower motor		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B220 (A)	2	B212 (B)	7	Yes



4. Check continuity between climate controlled seat blower motor connector B220 (A) terminal 2 and ground.

CLIMATE CONTROLLED SEAT BLOWER MOTOR

[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

Climate controlled seat blower motor		Ground	Continuity
Connector	Terminal		
B220 (A)	2	—	No

Is the inspection result normal?

YES >> Replace climate controlled seat control unit. Refer to [SE-65, "Exploded View"](#).

NO >> Repair harness or connectors.

4. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR SPEED CONTROL SIGNAL


Check voltage between climate controlled seat blower motor connector B220 terminal 3 and ground.

Climate controlled seat blower motor		Ground	Condition	Voltage (Approx.)
Connector	Terminal		Climate controlled seat switch	
B220	3	—	HEAT or COOL	4.5V – 8.0V

Is the inspection result normal?

YES >> GO TO 6.


NO >> GO TO 5.



5. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR SPEED CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat blower motor connector and climate controlled seat control unit connector B212.
3. Check continuity between climate controlled seat blower motor connector B220 (A) terminal 3 and climate controlled seat control unit connector B212 (B) terminal 4.

Climate controlled seat blower motor		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B220 (A)	3	B212 (B)	4	Yes



4. Check continuity between climate controlled seat blower motor connector B220 (A) terminal 3 and ground.

Climate controlled seat blower motor		Ground	Continuity
Connector	Terminal		
B220 (A)	3	—	No

Is the inspection result normal?

YES >> Replace climate controlled seat control unit. Refer to [SE-65, "Exploded View"](#).

NO >> Repair harness or connectors.

6. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR GROUND CIRCUIT


1. Turn ignition switch OFF.

CLIMATE CONTROLLED SEAT BLOWER MOTOR

[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

- Disconnect climate controlled seat blower motor connector and climate controlled seat control unit connector B212.
- Check continuity between climate controlled seat blower motor connector B220 (A) terminal 4 and climate controlled seat control unit connector B212 (B) terminal 6.



Climate controlled seat blower motor		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B220 (A)	4	B212 (B)	6	Yes

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-65, "Exploded View"](#).
 NO >> Repair harness or connectors.

Component Inspection (Climate Controlled Seat Blower Motor)

INFOID:000000010049468

1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR PART 1

- Turn ignition switch OFF.
- Disconnect climate controlled seat blower motor connector.
- Measure the resistance of the climate controlled seat blower motor between terminals 2 and 4.

Climate Controlled Seat Blower Motor Terminals		Resistance
2	4	600 – 800 Ω

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace climate controlled seat blower motor. Refer to [SE-65, "Exploded View"](#).

2. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR PART 2

Measure the resistance of the climate controlled seat blower motor between terminals 3 and 4.

Climate Controlled Seat Blower Motor Terminals		Resistance
3	4	2.5 – 2.8 MΩ

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace climate controlled seat blower motor. Refer to [SE-65, "Exploded View"](#).

SEAT CUSHION THERMAL ELECTRIC DEVICE

< DTC/CIRCUIT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SEAT CUSHION THERMAL ELECTRIC DEVICE

Description

INFOID:000000010049469

Provides cooling and heat for the seat cushion.

Component Function Check

INFOID:000000010049470

1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE FUNCTION

1. Turn the climate controlled seat switch to the H (Heat) HI position and check that the seat cushion thermal electric device operates correctly.
2. Turn the climate controlled seat switch to the C (Cool) HI position and check that the seat cushion thermal electric device operates correctly.

Is the inspection result normal?

- YES >> Seat cushion thermal electric device is OK.
 NO >> Refer to [SE-15, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010049471

Regarding Wiring Diagram information, refer to [SE-44, "Wiring Diagram"](#).

1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE


Perform thermal electric device component inspection for the seat cushion. Refer to [SE-16, "Component Inspection \(Thermal Electric Device\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace seat cushion thermal electric device. Refer to [SE-65, "Exploded View"](#).

2. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect seat cushion thermal electric device connector and climate controlled seat control unit connector B217.
3. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 1, 2 and climate controlled seat control unit connector B217 (B) terminals 26, 27.



Seat cushion thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B219 (A)	1	B217 (B)	27	Yes
	2		26	

4. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 1, 2 and ground.

Seat cushion thermal electric device		Ground	Continuity
Connector	Terminal		
B219 (A)	1		No
	2		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair harness or connectors.

SEAT CUSHION THERMAL ELECTRIC DEVICE


[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR CIRCUITS

1. Disconnect climate controlled seat control unit connector B212.
2. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 3, 4 and climate controlled seat control unit connector B212 (B) terminals 13, 14.

Seat cushion thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B219 (A)	3	B212 (B)	14	Yes
	4		13	



3. Check continuity between seat cushion thermal electric device connector B219 (A) terminals 3, 4 and ground.

Seat cushion thermal electric device		Ground	Continuity
Connector	Terminal		
B219 (A)	3		No
	4		

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-65, "Exploded View"](#).
 NO >> Repair harness or connectors.

Component Inspection (Thermal Electric Device)

INFOID:0000000010049472

1. CHECK THERMAL ELECTRIC DEVICE

1. Turn ignition switch OFF.
2. Disconnect thermal electric device connector.
3. Measure the resistance of the thermal electric device between terminals 1 and 2.

NOTE:

The resistance value in the table below will change under any of the following conditions:

- air blowing across the thermal electric device
- changing the surrounding temperature of the thermal electric device
- measuring at other than 23°C (73°F)

Thermal electric device terminals		Temperature	Resistance
1	2	23°C (73°F)	0.9 – 10 Ω

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace thermal electric device. Refer to [SE-65, "Exploded View"](#).

2. CHECK THERMAL ELECTRIC DEVICE SENSOR

Measure the resistance of the thermal electric device sensor between terminals 3 and 4.

Thermal electric device terminals		Temperature	Resistance
3	4	0 – 10° C (32 – 50° F)	2785 – 1660 Ω
		10 – 20° C (50 – 68° F)	1840 – 1135 Ω
		20 – 30° C (68 – 86° F)	1265 – 800 Ω
		30 – 40° C (86 – 104° F)	895 – 565 Ω
		40 – 50° C (104 – 122° F)	635 – 425 Ω

Is the inspection result normal?

SEAT CUSHION THERMAL ELECTRIC DEVICE

[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Inspection End.
- NO >> Replace thermal electric device. Refer to [SE-65, "Exploded View"](#).

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SEATBACK THERMAL ELECTRIC DEVICE

< DTC/CIRCUIT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SEATBACK THERMAL ELECTRIC DEVICE

Description

INFOID:000000010049473

Provides cooling and heat for the seatback.

Component Function Check

INFOID:000000010049474

1. CHECK SEATBACK THERMAL ELECTRIC DEVICE FUNCTION

1. Turn the climate controlled seat switch to the H (Heat) HI position and check that the seatback thermal electric device operates correctly.
2. Turn the climate controlled seat switch to the C (Cool) HI position and check that the seatback thermal electric device operates correctly.

Is the inspection result normal?

- YES >> Seatback thermal electric device is OK.
 NO >> Refer to [SE-18, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010049475

Regarding Wiring Diagram information, refer to [SE-44, "Wiring Diagram"](#).

1. CHECK SEATBACK THERMAL ELECTRIC DEVICE


Perform thermal electric device component inspection for the seatback. Refer to [SE-19, "Component Inspection \(Thermal Electric Device\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace seatback thermal electric device. Refer to [SE-65, "Exploded View"](#).

2. CHECK SEATBACK THERMAL ELECTRIC DEVICE CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect seatback thermal electric device connector and climate controlled seat control unit connector B217.
3. Check continuity between seatback thermal electric device connector B218 (A) terminals 1, 2 and climate controlled seat control unit connector B217 (B) terminals 25, 28.



Seatback thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B218 (A)	1	B217 (B)	28	Yes
	2		25	

4. Check continuity between seatback thermal electric device connector B218 (A) terminals 1, 2 and ground.

Seatback thermal electric device		Ground	Continuity
Connector	Terminal		
B218 (A)	1		No
	2		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair harness or connectors.


3. CHECK SEATBACK THERMAL ELECTRIC DEVICE SENSOR CIRCUITS

SEATBACK THERMAL ELECTRIC DEVICE

[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect climate controlled seat control unit connector B212.
2. Check continuity between seatback thermal electric device connector B218 (A) terminals 3, 4 and climate controlled seat control unit connector B212 (B) terminals 15, 16.



Seatback thermal electric device		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
B218 (A)	3	B212 (B)	16	Yes
	4		15	

3. Check continuity between seatback thermal electric device connector B218 (A) terminals 3, 4 and ground.

Seatback thermal electric device		Ground	Continuity
Connector	Terminal		
B218 (A)	3		No
	4		

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-65. "Exploded View"](#).
 NO >> Repair harness or connectors.

Component Inspection (Thermal Electric Device)

INFOID:0000000010049476

1. CHECK THERMAL ELECTRIC DEVICE

1. Turn ignition switch OFF.
2. Disconnect thermal electric device connector.
3. Measure the resistance of the thermal electric device between terminals 1 and 2.

NOTE:

The resistance value in the table below will change under any of the following conditions:

- air blowing across the thermal electric device
- changing the surrounding temperature of the thermal electric device
- measuring at other than 23°C (73°F)

Thermal electric device terminals		Temperature	Resistance
1	2	23°C (73°F)	0.9 – 10 Ω

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace thermal electric device. Refer to [SE-65. "Exploded View"](#).

2. CHECK THERMAL ELECTRIC DEVICE SENSOR

Measure the resistance of the thermal electric device sensor between terminals 3 and 4.

Thermal electric device terminals		Temperature	Resistance
3	4	0 – 10° C (32 – 50° F)	2785– 1660 Ω
		10 – 20° C (50 – 68° F)	1840 – 1135 Ω
		20 – 30° C (68 – 86° F)	1265 – 800 Ω
		30 – 40° C (86 – 104° F)	895 – 565 Ω
		40 – 50° C (104 – 122° F)	635 – 425 Ω

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace thermal electric device. Refer to [SE-65. "Exploded View"](#).

CLIMATE CONTROLLED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

CLIMATE CONTROLLED SEAT SWITCH

Description

INFOID:000000010049477

Provides inputs to the climate controlled seat control unit for climate controlled seat operation.

Component Function Check

INFOID:000000010049478

1. CHECK CLIMATE CONTROLLED SEAT SWITCH FUNCTION

Turn the climate controlled seat switch to the H (Heat) LO, MED, and HI positions and the C (Cool) LO, MED, and HI positions. Check that the climate controlled seat operates at low, medium and high heat, and low, medium and high cool.

Is the inspection result normal?

YES >> Climate controlled seat switch function is OK.

NO >> Refer to [SE-20, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010049479

Regarding Wiring Diagram information, refer to [SE-44, "Wiring Diagram"](#).

1. CHECK CLIMATE CONTROLLED SEAT SWITCH

Perform climate controlled seat switch component inspection. Refer to [SE-21, "Component Inspection \(Climate Controlled Seat Switch\)"](#).


Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace climate controlled seat switch.

2. CHECK CLIMATE CONTROLLED SEAT SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat switch connector and climate controlled seat control unit connector B216.
3. Check continuity between climate controlled seat switch connector M302 (A) terminal 1 and climate controlled seat control unit connector B216 (B) terminal 24.



Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	1	B216 (B)	24	Yes

4. Check continuity between climate controlled seat switch connector M302 (A) terminal 1 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	1		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connectors.

3. CHECK CLIMATE CONTROLLED SEAT SWITCH COOL CIRCUIT


CLIMATE CONTROLLED SEAT SWITCH

[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect climate controlled seat control unit connector B212.
2. Check continuity between climate controlled seat switch connector M302 (A) terminal 2 and climate controlled seat control unit connector B212 (B) terminal 9.

Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	2	B212 (B)	9	Yes



3. Check continuity between climate controlled seat switch connector M302 (A) terminal 2 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	2		No


Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connectors.

4. CHECK CLIMATE CONTROLLED SEAT SWITCH HEAT CIRCUIT

1. Check continuity between climate controlled seat switch connector M302 (A) terminal 3 and climate controlled seat control unit connector B212 (B) terminal 1.

Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	3	B212 (B)	1	Yes



2. Check continuity between climate controlled seat switch connector M302 (A) terminal 3 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	3		No

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-65, "Exploded View"](#).
 NO >> Repair harness or connectors.

Component Inspection (Climate Controlled Seat Switch)

INFOID:000000010049480

1. CHECK CLIMATE CONTROLLED SEAT SWITCH

1. Disconnect climate controlled seat switch connector.
2. Check continuity between climate controlled seat switch terminals.

Terminals	Condition	Continuity

CLIMATE CONTROLLED SEAT SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

1	3	Climate controlled seat switch	HEAT mode	OFF position	Continuity does not exist
				Rotate knob to LO	Continuity exists
				Rotate knob to MED	Resistance value decreases
				Rotate knob to HI	Resistance value decreases further
	2	Climate controlled seat switch	COOL mode	OFF position	Continuity does not exist
				Rotate knob to LO	Continuity exists
				Rotate knob to MED	Resistance value decreases
			Rotate knob to HI	Resistance value decreases further	

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace climate controlled seat switch.

CLIMATE CONTROLLED SEAT SWITCH INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

CLIMATE CONTROLLED SEAT SWITCH INDICATOR

Description

INFOID:000000010049481

Illuminates the climate controlled seat switch to indicate operating status.

Component Function Check

INFOID:000000010049482

1. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR FUNCTION

Check that the indicators for the climate controlled seat switch operate in both COOL and HEAT modes.

Is the inspection result normal?

- YES >> Climate controlled seat switch indicator function is OK.
- NO >> Refer to [SE-23, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010049483

Regarding Wiring Diagram information, refer to [SE-44, "Wiring Diagram"](#).

1. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR


Perform climate controlled seat switch indicator component inspection. Refer to [SE-24, "Component Inspection \(Climate Controlled Seat Switch Indicator\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace climate controlled seat switch.

2. CHECK CLIMATE CONTROLLED SEAT SWITCH COOL INDICATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat switch connector and climate controlled seat control unit connector B216.
3. Check continuity between climate controlled seat switch connector M302 (A) terminal 4 and climate controlled seat control unit connector B216 (B) terminal 19.



Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	4	B216 (B)	19	Yes

4. Check continuity between climate controlled seat switch connector M302 (A) terminal 4 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	4		No

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connectors.

3. CHECK CLIMATE CONTROLLED SEAT SWITCH HEAT INDICATOR CIRCUIT


CLIMATE CONTROLLED SEAT SWITCH INDICATOR

[WITH CLIMATE CONTROLLED SEATS]

< DTC/CIRCUIT DIAGNOSIS >

1. Check continuity between climate controlled seat switch connector M302 (A) terminal 5 and climate controlled seat control unit connector B216 (B) terminal 20.

Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
M302 (A)	5	B216 (B)	20	Yes



2. Check continuity between climate controlled seat switch connector M302 (A) terminal 5 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302 (A)	5		No

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair harness or connectors.


4. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR GROUND CIRCUIT

Check continuity between climate controlled seat switch connector M302 terminal 6 and ground.

Climate controlled seat switch		Ground	Continuity
Connector	Terminal		
M302	6		Yes

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-65, "Exploded View"](#).
 NO >> Repair harness or connectors.



Component Inspection (Climate Controlled Seat Switch Indicator)

INFOID:0000000110049484

1. CHECK CLIMATE CONTROLLED SEAT SWITCH

1. Disconnect climate controlled seat switch connector.
2. Check continuity between climate controlled seat switch terminals.

Terminals		Continuity
(+)	(-)	
4	6	Continuity exists
5		
6	4	Continuity does not exist
	5	

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Replace climate controlled seat switch.

CLIMATE CONTROLLED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH CLIMATE CONTROLLED SEATS]


ECU DIAGNOSIS INFORMATION

CLIMATE CONTROLLED SEAT CONTROL UNIT

Reference Value

INFOID:0000000010049485

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal	Wire color	Item	Signal Input/ Output	Condition		Voltage (Approx.)	
1	O	HEAT switch signal	Input	Ignition switch ON or START	Climate controlled seat switch select	HI HEAT	2.6V – 3.5V
						MED HEAT	1.6V – 2.5V
						LO HEAT	0.5V – 1.5V
						OFF	0V
4	V	Blower motor speed control signal	Input	Ignition switch ON or START	Climate controlled seat switch select	HEAT or COOL	4.5V – 8.0V
						OFF	0V
6	B	Blower motor ground	—	—		0V	
7	R	Blower motor power supply	Input	Ignition switch ON or START		Battery voltage	
9	L	COOL switch signal	Input	Ignition switch ON or START	Climate controlled seat switch select	HI COOL	2.6V – 3.5V
						MED COOL	1.6V – 2.5V
						LO COOL	0.5V – 1.5V
						OFF	0V
13	G/B	Seat cushion thermal electric device sensor ground	—	Ignition switch ON		0V	
14	G/R	Seat cushion thermal electric device sensor signal	Input	Blower motor operated		0.5V – 4.0V	
				Ignition switch OFF		0V	
15	G/Y	Seatback thermal electric device sensor ground	—	Ignition switch ON		0V	
16	G	Seatback thermal electric device sensor signal	Input	Blower motor operated		0.5V – 4.0V	
				Ignition switch OFF		0V	
19	V	COOL switch indicator signal	Output	Ignition switch ON or START	Climate controlled seat switch select	COOL	Battery voltage
						OFF	0V
20	BR	HEAT switch indicator signal	Output	Ignition switch ON or START	Climate controlled seat switch select	HEAT	Battery voltage
						OFF	0V
21	GR/W	Ignition switch power supply	Input	Ignition switch ON or START		Battery voltage	
24	GR	Climate controlled seat switch power supply	Input	Ignition switch ON or START		Battery voltage	

CLIMATE CONTROLLED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH CLIMATE CONTROLLED SEATS]

Terminal	Wire color	Item	Signal Input/ Output	Condition		Voltage (Approx.)	
25	Y	Seatback thermal electric device power supply (COOL)	Output	Ignition switch ON or START	Climate controlled seat switch select	COOL	Battery voltage
						HEAT	0V
						OFF	0V
26	Y/B	Seat cushion thermal electric device power supply (COOL)	Output	Ignition switch ON or START	Climate controlled seat switch select	COOL	Battery voltage
						HEAT	0V
						OFF	0V
27	L/O	Seat cushion thermal electric device power supply (HEAT)	Output	Ignition switch ON or START	Climate controlled seat switch select	HEAT	Battery voltage
						COOL	0V
						OFF	0V
28	L	Seatback thermal electric device power supply (HEAT)	Output	Ignition switch ON or START	Climate controlled seat switch select	HEAT	Battery voltage
						COOL	0V
						OFF	0V
29	GR/W	Battery power supply	Input	Ignition switch ON or OFF		Battery voltage	
30	GR/B	Ground	—	—		0V	

Fail-safe

INFOID:000000010049486

- Climate controlled seat control unit equips fail-safe function.
- When a malfunction occurs in the systems shown as per the following, climate controlled seat control unit stops output.

Malfunction	Malfunctioning condition
The temperature difference between the seatback thermal electric device and seat cushion thermal electric device is 30°C (86°F) or more	<ul style="list-style-type: none"> • When it detects for 4 seconds that the temperature difference between the seatback thermal electric device and seat cushion thermal electric device is 30°C (86°F) or more, stops the output to the thermal electric device, activates the climate controlled seat blower motor in the maximum position, and sends the external airflow for 30 seconds • If the temperature difference is still 30°C (86°F) or more after 30 seconds pass, it stops all output and enters the system OFF condition • When the temperature difference between seatback thermal electric device and seat cushion thermal electric device becomes 20°C (68°F) or less, the system recovers automatically • If it detects that the temperature difference is 30°C (86°F) or more after the automatic system recovery, it immediately stops all output and enters the system OFF condition <p>NOTE: When the switch operation is performed before entering the system OFF condition, the fail-safe mode is reset.</p>
The temperature of thermal electric device is 110°C (230°F) or more in the HEAT mode (any thermal electric device in the seatback or seat cushion)	<ul style="list-style-type: none"> • When it detects for 4 seconds that the temperature of the thermal electric device is 110°C (230°F) or more, stops the output to the thermal electric device, activates the climate controlled seat blower motor in the maximum position, and sends the external airflow for 30 seconds • If the temperature does not become 105°C (221°F) or less after 30 seconds pass, it stops all output and enters the system OFF condition • When the temperature of the thermal electric device becomes 105°C (221°F) or less, the system recovers automatically • If it detects that the temperature of the thermal electric device is 110°C (230°F) or more after the automatic system recovery, it immediately stops all output and enters the system OFF condition

CLIMATE CONTROLLED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH CLIMATE CONTROLLED SEATS]

Malfunction	Malfunctioning condition
The temperature of the thermal electric device is 45°C (113°F) or more in the COOL mode (any thermal electric device in the seatback or seat cushion)	<ul style="list-style-type: none"> When it detects for 4 seconds that the temperature of the thermal electric device is between 45°C (113°F) and 70°C (158°F), it starts the temperature monitoring of the thermal electric device at 3 second intervals While monitoring, if it detects that the temperature raises 2°C (36°F) or more 4 times continuously or reaches 70°C (158°F) or more, it stops all output and enters the system OFF condition If it detects other results of monitoring, it continues activating in the COOL mode
Thermal electric device sensor system open circuit	<ul style="list-style-type: none"> When it detects for 4 seconds that the thermal electric device sensor system is an open circuit
Climate controlled seat blower motor system open circuit	<ul style="list-style-type: none"> When it detects for 2 seconds that climate controlled seat blower motor system is an open circuit while the climate controlled seat is being activated, it stops output to the thermal electric device When it detects for 10 seconds that the climate controlled seat blower motor system is an open circuit while the climate controlled seat is being activated, it stops all output and enters the system OFF condition <p>NOTE: After detecting the climate seat blower motor system open circuit for 2 seconds, the system recovers automatically if the activation of the climate controlled seat blower motor is detected for 1 second or more.</p>
Switch input out of the specified range	<ul style="list-style-type: none"> When it detects for 4 seconds that the rotary switch input is 30% or less of the vehicle battery voltage, it stops all output and enters the system OFF condition When the switch input returns to a value within the specified range, the system recovers automatically
HEAT or COOL switch input out of the specified range	<ul style="list-style-type: none"> When it detects for 4 seconds that rotary switch input is 6% or less of the vehicle battery voltage, it stops all output and enters the system OFF condition When the switch input returns to a value within the specified range, the system recovers automatically
System voltage out of range	<ul style="list-style-type: none"> System voltage* of the climate controlled seat control unit is out of the operation range (8.5 V – 16.5 V)

*: System voltage is the voltage between climate controlled seat control unit power source and the ground.

NOTE:

When the system enters in the fail-safe mode again after performing resetting procedure, perform diagnosis.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT FOR DRIVER SIDE


[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER

Terminal No.	Color of Wire	Signal Name
20J	R/Y	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	B	GND1

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

ABJIA0241GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


POWER SEAT FOR DRIVER SIDE

[WITH CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-(WITHOUT AUTOMATIC DRIVE POSITIONER)


ABJIA0493GB

POWER SEAT FOR DRIVER SIDE

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

Connector No.	B209
Connector Name	POWER SEAT SWITCH LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
2	O	-
3	R/Y	-
4	B	-
5	GR	-
6	V	-
7	Y	-
8	B	-
9	R	-
10	V	-

Connector No.	B207
Connector Name	RECLINING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	O	-
2	GR	-

Connector No.	B204
Connector Name	FRONT POWER SEAT LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	R	-
3	V	-
4	GR	-
5	O	-
6	B/W	-

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

ABJIA0644GB

POWER SEAT FOR PASSENGER SIDE

[WITH CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

POWER SEAT FOR PASSENGER SIDE

Wiring Diagram

INFOID:000000010049488

POWER SEAT FOR PASSENGER SIDE



ABJWA0137GB


POWER SEAT FOR PASSENGER SIDE

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


POWER SEAT FOR PASSENGER SIDE CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	82G	Color of Wire	W/B	Signal Name	-
--------------	-----	---------------	-----	-------------	---

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	6	Color of Wire	R/Y	Signal Name	-
--------------	---	---------------	-----	-------------	---

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	1	Color of Wire	W/B	Signal Name	BATT (F/L)
Terminal No.	2	Color of Wire	R/Y	Signal Name	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	13	Color of Wire	B	Signal Name	GND1
--------------	----	---------------	---	-------------	------

ABJIA0242GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

POWER SEAT FOR PASSENGER SIDE

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	6	Color of Wire	SB	Signal Name	-
--------------	---	---------------	----	-------------	---

Terminal No.	82G	Color of Wire	LG	Signal Name	-
--------------	-----	---------------	----	-------------	---

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B307
Connector Name	RECLINING MOTOR RH
Connector Color	BLACK




Terminal No.	1	Color of Wire	W	Signal Name	-
Terminal No.	2	Color of Wire	GR	Signal Name	-

Connector No.	B306
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	1	Color of Wire	V	Signal Name	-
Terminal No.	2	Color of Wire	Y	Signal Name	-

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	4	Color of Wire	B	Signal Name	-
Terminal No.	7	Color of Wire	SB	Signal Name	-

ABJIA0385GB


POWER SEAT FOR PASSENGER SIDE

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

Connector No.	B309
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-
5	W	-
6	V	-
7	Y	-
10	GR	-

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
7	R/Y	-

AAJIA0404GB

HEATED SEAT


[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

HEATED SEAT

Wiring Diagram

INFOID:000000010049489



ABJWA0138GB


HEATED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


HEATED SEAT CONNECTORS

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	8M	Color of Wire	G/R	Signal Name	-
--------------	----	---------------	-----	-------------	---

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	18J	Color of Wire	GR	Signal Name	-
	19J	Color of Wire	GR/R	Signal Name	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	3	Color of Wire	GR/L	Signal Name	-
	4	Color of Wire	GR/B	Signal Name	-

Connector No.	M87
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	1	Color of Wire	G/R	Signal Name	-
	3	Color of Wire	GR/B	Signal Name	-
	6	Color of Wire	GR	Signal Name	-
	9	Color of Wire	GR/L	Signal Name	-
	14	Color of Wire	GR/R	Signal Name	-
	15	Color of Wire	B	Signal Name	-
	16	Color of Wire	G/R	Signal Name	-

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	1	Color of Wire	G/R	Signal Name	-
	3	Color of Wire	GR/B	Signal Name	-
	6	Color of Wire	GR	Signal Name	-
	9	Color of Wire	GR/L	Signal Name	-
	14	Color of Wire	GR/R	Signal Name	-
	15	Color of Wire	B	Signal Name	-
	16	Color of Wire	G/R	Signal Name	-

AAJIA0025GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

Connector No.	M301
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	W	-
3	O	-
4	B	-

Connector No.	M300
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	SB	-
2	G	-
3	GR	-
4	B	-

Connector No.	M208
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
5	GR/R	-
6	B	-
7	G/R	-
9	GR/L	-
15	GR	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18J	W	-
19J	O	-

Connector No.	M305
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
3	GR	-
5	O	-
6	B	-
7	P	-
9	G	-
15	W	-




AAJIA0026GB

HEATED SEAT

[WITH CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G	-
4	B	-
6	GR	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
4	GR	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	W	-
4	B/R	-(WITHOUT AUTOMATIC DRIVE POSITIONER)
6	O	-
7	B/W	-(WITHOUT CLIMATE CONTROLLED SEAT)

Connector No.	B304
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR/G	-
2	GR/R	-
3	B	-

Connector No.	B210
Connector Name	FRONT SEAT HEATER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR/W	-
3	W/B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
4	B	-
6	GR/W	-
7	GR/B	-

ABJIA0494GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT

< WIRING DIAGRAM >

[WITH CLIMATE CONTROLLED SEATS]

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR/G	-
4	B	-
6	GR/R	-

AAJIA0028GB

LUMBAR SUPPORT SYSTEM

[WITH CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

LUMBAR SUPPORT SYSTEM

Wiring Diagram

INFOID:000000010049490

LUMBAR SUPPORT SYSTEM



AAJWA0013GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


LUMBAR SUPPORT SYSTEM

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


LUMBAR SUPPORT SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	B	GND1

LUMBAR SUPPORT SYSTEM

[WITH CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-(WITHOUT AUTOMATIC DRIVE POSITIONER)

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	LG	-
83G		

Connector No.	B221
Connector Name	LUMBAR SUPPORT MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-

Connector No.	B214
Connector Name	LUMBAR SUPPORT SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-
3	B	-
4	R/Y	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

ABJIA0495GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SE

CLIMATE CONTROLLED SEAT


[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

CLIMATE CONTROLLED SEAT

Wiring Diagram

INFOID:0000000010049491



ABJWA0135GB


CLIMATE CONTROLLED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


CLIMATE CONTROLLED SEAT CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
81G	R/W	-
82G	W/B	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2N	G	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20J	R/Y	-
58J	G	-
59J	R/G	-
60J	BR/Y	-
61J	G/R	-
98J	W	-
99J	GR	-


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIMATE CONTROLLED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

Connector No.	M85
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G	-
8	R/G	-
18	GR	-
19	BR/Y	-
20	G/R	-

Connector No.	M84
Connector Name	CIRCUIT BREAKER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	R/Y	-

Connector No.	M88
Connector Name	CLIMATE CONTROLLED SEAT RELAY
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	R/W	-
5	W	-

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
15	B	-

Connector No.	M200
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G	-
8	R/G	-
18	GR	-
19	BR/Y	-
20	G/R	-

Connector No.	M87
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
15	B	-


ABJIA0164GB

CLIMATE CONTROLLED SEAT

[WITH CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

Connector No.	M305
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	V	-
6	B	-
10	O	-
11	BR	-
12	W	-
13	LG	-

Connector No.	M302
Connector Name	CLIMATE CONTROLLED SEAT SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	LG	-
3	V	-
4	BR	-
5	O	-
6	B	-


Connector No.	M208
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R/G	-
6	B	-
10	G/R	-
11	BR/Y	-
12	GR	-
13	G	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABJIA0387GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIMATE CONTROLLED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BR	-
5	W	-
6	O	-
7	B/Y	- (WITH CLIMATE CONTROLLED SEAT)

Terminal No.	Color of Wire	Signal Name
20J	BR	-
58J	GR	-
59J	L	-
60J	G	-
61J	O	-
98J	O	-
99J	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B208
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	BR	-
12	V	-
13	L	-
14	O	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
5	GR	-
6	GR/W	-
7	GR/B	-

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	GR	-
12	L	-
13	G	-
14	O	-


ABJIA0496GB

CLIMATE CONTROLLED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


Connector No.	B216
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
17	-	-
18	-	-
19	V	COOL ON INDICATOR
20	BR	HEAT ON INDICATOR
21	GR/W	IGN
22	-	-
23	-	-
24	GR	HEAT/COOL SW RESISTOR PWR


Terminal No.	Color of Wire	Signal Name
10	-	-
11	-	-
12	-	-
13	G/B	CUSHION SENSOR GND
14	G/R	CUSHION SENSOR SIGNAL
15	G/Y	BACK SENSOR GND
16	G	BACK SENSOR SIGNAL

Connector No.	B212
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	O	HEAT SWITCH INPUT
2	-	-
3	-	-
4	V	BLOWER MOTOR SPEED CONTROL
5	-	-
6	B	BLOWER GND
7	R	BLOWER POWER
8	-	-
9	L	COOL SWITCH INPUT

Connector No.	B219
Connector Name	SEAT CUSHION THERMAL ELECTRIC DEVICE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/O	-
2	Y/B	-
3	G/R	-
4	G/B	-

Connector No.	B218
Connector Name	SEAT BACK THERMAL ELECTRIC DEVICE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	Y	-
3	G	-
4	G/Y	-

Connector No.	B217
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
25	Y	BACK TED 1
26	Y/B	CUSHION TED 1
27	L/O	CUSHION TED 2
28	L	BACK TED 2
29	GR/W	BAT (PTC)
30	GR/B	GND

ABJIA0650GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIMATE CONTROLLED SEAT

[WITH CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

Connector No.	B220
Connector Name	CLIMATE CONTROLLED SEAT BLOWER MOTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	R	-
3	V	-
4	B	-

AAJIA0403GB

CLIMATE CONTROLLED SEAT SYSTEM

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SYMPTOM DIAGNOSIS

CLIMATE CONTROLLED SEAT SYSTEM

Symptom Table

INFOID:000000010049492

Symptom		Inspection item
Climate controlled seat inoperative.		Power supply and ground circuit Refer to SE-8, "CLIMATE CONTROLLED SEAT CONTROL UNIT : Diagnosis Procedure" .
Climate controlled seat blower motor inoperative.		Climate controlled seat blower motor Refer to SE-12, "Diagnosis Procedure" .
Seat cushion thermal electric device inoperative.		Seat cushion thermal electric device Refer to SE-15, "Diagnosis Procedure" .
Seatback thermal electric device inoperative.		Seatback thermal electric device Refer to SE-18, "Diagnosis Procedure" .
Climate controlled seat switch LO, MED or HI inoperative.		Climate controlled seat switch Refer to SE-20, "Diagnosis Procedure" .
Climate controlled seat switch indicator inoperative.		Climate controlled seat switch indicator Refer to SE-23, "Diagnosis Procedure" .
Climate controlled seat turns off too soon.	Climate controlled seat switch indicator turns off within 10 seconds of turning on.	Malfunction caused by electrical issue. Check the following: <ul style="list-style-type: none"> • Connectors for physical damage or loose terminals. • Seat cushion thermal electric device. Refer to SE-15, "Diagnosis Procedure". • Seatback thermal electric device. Refer to SE-18, "Diagnosis Procedure". • Climate controlled seat blower motor. Refer to SE-12, "Diagnosis Procedure".
	Climate controlled seat switch indicator turns off 30 seconds or more after turning on.	Malfunction caused by mechanical issue. Check the following: <ul style="list-style-type: none"> • Foam seat pads not aligned for thermal electric device outlet. • Thermal electric device ducting restricted or disconnected. • Climate controlled seat blower motor inlet restricted.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000010049493



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-56, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

[WITH CLIMATE CONTROLLED SEATS]

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.Refer to [SE-53. "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-50397) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

- Always check with the Parts Department for the latest parts information.
- The materials contained in the NISSAN Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.
- The following materials not found in the kit can also be used to repair squeaks and rattles.
 - SILICONE GREASE: Use instead of UHMW tape that will be visible or does not fit. The silicone grease will only last a few months.
 - SILICONE SPRAY: Use when grease cannot be applied.
 - DUCT TAPE: Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000010049494

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-50397) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

Diagnostic Worksheet

INFOID:000000010049495





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[WITH CLIMATE CONTROLLED SEATS]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAIA0071E

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009468138

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- **When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.**

Service Notice

INFOID:000000009468139

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Precaution for Work

INFOID:000000009468140

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:

PRECAUTIONS

< PRECAUTION >

[WITH CLIMATE CONTROLLED SEATS]

- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

PREPARATION

[WITH CLIMATE CONTROLLED SEATS]

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tools


INFOID:000000009895344

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-39570) Chassis Ear	Locating the noise
— (J-46534) Trim Tool Set	Removing trim components
— (J-50397) NISSAN Squeak and Rattle Kit	Repairing the cause of noise



SIIA0993E



AWJIA0483ZZ




ALJIA1232ZZ


Commercial Service Tools

INFOID:000000009468142

(TechMate No.) Tool name	Description
(J-39565) Engine Ear	Locating the noise
Hook and pick tool	Remove the snap pins



SIIA0995E



JMJIA0490ZZ

CLIP LIST

< PREPARATION >

















[WITH CLIMATE CONTROLLED SEATS]

CLIP LIST

Descriptions for Clips

INFOID:000000009468143

Replace any clips which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
<p>C101</p> 		<p>Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.</p> 
<p>C103</p> 		 <p>Removal: Remove with a clip remover.</p>
<p>C203</p> 		<p>Removal: Push center pin to catching position. (Do not remove center pin by hitting it.)</p> <p>Push</p>  <p>Installation:</p> <p>Push</p> 
<p>C205</p> 		<p>Removal: Flat-bladed screwdriver</p>  <p>Clip</p> <p>Finisher</p>
<p>C206</p> 		<p>Removal:</p> 
















SIIA0315E

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIP LIST

< PREPARATION >

[WITH CLIMATE CONTROLLED SEATS]














Symbol No.	Shapes	Removal & Installation
<p>CE103</p> 		<p>Removal:</p> 
<p>CF110</p> 		<p>Removal:</p> 
<p>CF118</p> 		<p>Removal:</p> 
<p>CR103</p> 		<p>Removal: Holder portion of clip must be spread out to remove rod.</p> 
<p>CS101</p> 		<p>Removal:</p> <ol style="list-style-type: none"> 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver. 

SIIA0316E

CLIP LIST

< PREPARATION >

[WITH CLIMATE CONTROLLED SEATS]

Symbol No.	Shapes	Removal & Installation	
CG101 		Removal:  Rotate 45° to remove	Installation: 
CS102 			
CS113 		Removal: Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip. 	
C111 			










SIIA0317E

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIP LIST

< PREPARATION >

[WITH CLIMATE CONTROLLED SEATS]

Symbol No.	Shapes	Removal & Installation
<p>CG104</p> 		<p>Removal: Remove by bending up with flat-bladed screwdrivers.</p> 
<p>CE114</p> 		
<p>CF118</p> 		<p>Removal: Flat-bladed screwdrivers Finisher</p> 

ALJIA0564GB

FRONT SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

REMOVAL AND INSTALLATION


FRONT SEAT

Exploded View

DRIVER

INFOID:000000009468144

Driver Seat - With Climate Controlled Seats



- | | | |
|-------------------------------------|--|-------------------------------------|
| 1. Seatback board | 2. Seatback board clip | 3. Seat cushion lower rear finisher |
| 4. Seat harness | 5. Seat cushion inner finisher inside (RH) | 6. Recline mechanism inner cover |
| 7. Seat cushion outer finisher (RH) | 8. Seat belt buckle | 9. Seat cushion assembly |

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

-
- | | | |
|---|--|---|
| 10. Seat cushion trim | 11. Seat cushion pad | 12. Thigh extension tether |
| 13. Thigh extension assembly | 14. Climate controlled seat control unit | 15. Seat cushion front finisher |
| 16. Front slide cover | 17. Clip | 18. Power seat control unit |
| 19. Seat cushion thermal electric device (TED) | 20. Lower seat duct | 21. Climate controlled seat blower filter |
| 22. Climate controlled seat blower motor assembly | 23. Seat frame assembly | 24. Rear slide cover |
| 25. Power seat switch | 26. Seat slide and lifter switch knob | 27. Seat recline knob |
| 28. Lumbar support switch | 29. Seat cushion outer finisher (LH) | 30. Recline device outer cover |
| 31. Seat cushion inner finisher inside (LH) | 32. Seatback assembly | 33. Side air bag module |
| 34. Seatback thermal electric device (TED) | 35. Upper seat duct | 36. Headrest holder (locked) |
| 37. Headrest holder (free) | 38. Seatback frame | 39. Seatback trim |
| 40. Seatback pad | 41. Headrest | 42. Chute rod |


PASSENGER

FRONT SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

Passenger Seat



- | | | |
|-------------------------------------|---|--------------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Headrest |
| 4. Seat harness | 5. Seat cushion inner finisher inside (RH) | 6. Recline device inner cover |
| 7. Seat cushion outer finisher (RH) | 8. Seat recline knob | 9. Seat slide and lifter switch knob |
| 10. Power seat switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Seat frame assembly | 15. Seat cushion outer finisher (LH) |
| 16. Recline mechanism inner cover | 17. Seat cushion inner finisher inside (LH) | 18. Seat belt buckle |
| 19. Seatback assembly | 20. Seatback pad | 21. Seatback trim |
| 22. Seatback frame | 23. Chute rod | 24. Side air bag module |
| 25. Rear slide cover | 26. Headrest holder (locked) | 27. Headrest holder (free) |

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

Removal and Installation

INFOID:00000009468145

REMOVAL


WARNING:

Do not leave any objects (screwdrivers, tools, etc.) on the seat during seat repair. It can lead to personal injury if the side air bag module should accidentally deploy.


CAUTION:

- When removing or installing the seat trim, handle it carefully to keep dirt out and to avoid damage.
- When checking the power seat circuit for continuity using a circuit tester, do not confuse its connector with the side air bag module connector. Such an error may cause the air bag module to deploy.
- Do not drop, tilt, or bump the side air bag module while installing the seat. Always handle it with care.
- After the front side air bag module inflates, the front seatback assembly must be replaced.
- When removing and installing the seat, use shop cloths to protect components from damage.
- Before removing the front seat, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.


1. Slide the seat to the full forward position.
2. Remove the rear slide covers.
 - a. Release the pawls (A).



- b. Remove the rear slide covers.
3. Remove the rear mount bolts.



4. Slide the seat to the full rearward position.
5. Remove the front slide covers.
6. Remove the front mount bolts.



7. Disconnect the negative and positive battery terminals and wait at least three minutes. Refer to [PG-67](#), "[Removal and Installation \(Battery\)](#)".

FRONT SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

8. Disconnect the harness connector under the seat and remove harness clips.
9. Remove seat from the vehicle.

INSTALLATION

Installation is in the reverse order of removal.


CAUTION:

Make sure that the seat harness or the floor trim is not damaged during installation.

NOTE:


- When installing the LH front seat, tighten the bolts in the order shown.

LH front seat bolt torque : 49 Nm (5.0 kg-m, 36 ft-lb)



- When installing the RH front seat, tighten the bolts in the order shown.

RH front seat bolt torque : 49 Nm (5.0 kg-m, 36 ft-lb)



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT


< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Fixed Seatback

INFOID:000000009468146



- | | | |
|-----------------------------|---------------------------|-----------------------------|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Bumper | 5. Seatback assembly | 6. Seatback trim |
| 7. Seatback pad | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seat cushion assembly |

Removal and Installation

INFOID:000000009468147

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

SEAT CUSHION ASSEMBLY


Removal

REAR SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

1. Locate the seat cushion lock (2) at the front bottom of the seat cushion assembly (one for each side). Pull the release lever (A) forward and lift the seat cushion assembly upward to release the seat cushion wire (1) from the seat cushion lock (2).
⇐: Front
2. Then pull the seat cushion assembly forward to remove.




Installation

Installation is in the reverse order of removal.

SEATBACK

Removal

1. Remove the seat cushion assembly.
2. Remove the headrests (LH/RH).
3. Remove the seatback assembly bolts and nut.



4. Lift the seatback to disengage seat hook wires from the hangers.

Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


REAR SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

Exploded View - 60:40 Split Seatback

INFOID:000000009468148



- | | | |
|--------------------------------|-------------------------------|-------------------------------|
| 1. Seatback latch striker (RH) | 2. Seatback trim (RH) | 3. Seatback pad (RH) |
| 4. Armrest assembly | 5. Inner armrest bracket (RH) | 6. Inner armrest bracket (LH) |
| 7. Seat cushion assembly | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seatback hinge assembly |

REAR SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

- | | | |
|------------------------------|---------------------------------|----------------------------|
| 13. Seatback assembly (LH) | 14. Seatback latch striker (LH) | 15. Seatback frame (LH) |
| 16. Seatback pad (LH) | 17. Seatback trim (LH) | 18. Seatback frame (RH) |
| 19. Side bolster pad (LH) | 20. Side bolster trim (LH) | 21. Seat belt guide (LH) |
| 22. Seatback latch assembly | 23. Seatback latch cover | 24. Side bolster pad (RH) |
| 25. Side bolster trim (RH) | 26. Seat belt guide (RH) | 27. Seatback assembly (RH) |
| 28. Headrest holder (locked) | 29. Headrest holder (free) | 30. Headrest |

Removal and Installation

INFOID:000000009468149

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.


SEAT CUSHION ASSEMBLY

Removal

1. Locate the seat cushion lock (2) at the front bottom of the seat cushion assembly (one for each side). Pull the release lever (A) forward and lift the seat cushion assembly upward to release the seat cushion wire (1) from the seat cushion lock (2).

↔: Front

2. Then pull the seat cushion assembly forward to remove.



ALJIA0949ZZ


Installation

Installation is in the reverse order of removal.

SEATBACK


Removal

1. Lock seatback (LH/RH) in upright position.
2. Remove the seatback hinge assembly bolts and nut.
3. Fold seatback (LH/RH) forward.



ALJIA0328ZZ

4. Remove seatback latch covers (A).
5. Remove the halo upper frame assembly bolts (B).
6. Remove the seatback assembly.



ALJIA0329ZZ

Installation

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

REAR SEAT

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

Installation is in the reverse order of removal.

CLIMATE CONTROLLED SEAT BLOWER FILTER

< REMOVAL AND INSTALLATION >

[WITH CLIMATE CONTROLLED SEATS]

CLIMATE CONTROLLED SEAT BLOWER FILTER

Removal and Installation

INFOID:000000009468150

REMOVAL

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

1. Remove front seat. Refer to [SE-68. "Removal and Installation"](#).
2. Turn blower filter counter clockwise and remove it from climate controlled seat blower motor.

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

UNIT DISASSEMBLY AND ASSEMBLY


FRONT SEAT

DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:000000009468151

Driver Seat - With Climate Controlled Seats



- | | | |
|-------------------------------------|--|-------------------------------------|
| 1. Seatback board | 2. Seatback board clip | 3. Seat cushion lower rear finisher |
| 4. Seat harness | 5. Seat cushion inner finisher inside (RH) | 6. Recline mechanism inner cover |
| 7. Seat cushion outer finisher (RH) | 8. Seat belt buckle | 9. Seat cushion assembly |

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

- | | | |
|---|--|---|
| 10. Seat cushion trim | 11. Seat cushion pad | 12. Thigh extension tether |
| 13. Thigh extension assembly | 14. Climate controlled seat control unit | 15. Seat cushion front finisher |
| 16. Front slide cover | 17. Clip | 18. Power seat control unit |
| 19. Seat cushion thermal electric device (TED) | 20. Lower seat duct | 21. Climate controlled seat blower filter |
| 22. Climate controlled seat blower motor assembly | 23. Seat frame assembly | 24. Rear slide cover |
| 25. Power seat switch | 26. Seat slide and lifter switch knob | 27. Seat recline knob |
| 28. Lumbar support switch | 29. Seat cushion outer finisher (LH) | 30. Recline device outer cover |
| 31. Seat cushion inner finisher inside (LH) | 32. Seatback assembly | 33. Side air bag module |
| 34. Seatback thermal electric device (TED) | 35. Upper seat duct | 36. Headrest holder (locked) |
| 37. Headrest holder (free) | 38. Seatback frame | 39. Seatback trim |
| 40. Seatback pad | 41. Headrest | 42. Chute rod |

A
B
C
D
E

DRIVER SIDE : Disassembly and Assembly

INFOID:000000009468152

SEAT ASSEMBLY WITH SIDE AIR BAG MODULE

WARNING:

Do not leave any objects (screwdriver, tools, etc.) on the seat during seatback repair. It can lead to personal injury if the side air bag should accidentally deploy.

CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
- Handle the side air bag module carefully. During disassembly, always hold the side air bag module, do not let it hang by the wire harness.
- Always place side air bag module with the stud bolt side facing downward.
- Always work from the side or back of the seatback assembly, do not work in front of the seat.
- Do not use air tools or electric tools when servicing the seat assembly.
- Replace the side air bag module if it has been dropped or sustained an impact.
- Do not insert any objects into the side air bag module.
- Do not disassemble the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 93°C (200°F).
- Do not expose the side air bag module to any oil, grease or water.
- During disassembly, do not damage the trim cover, chutes, connectors, retainers, clips, module harness or the side air bag module.

NOTE:

- If the vehicle has been involved in a collision and the side air bag has deployed, the front seatback assembly must be replaced.
- For side air bag module removal and installation, refer to [SR-21, "Removal and Installation"](#).


Disassembly

1. Remove the front seat assembly. Refer to [SE-68, "Removal and Installation"](#).
2. Remove the seatback board as follows:

NOTE:

The seatback board is attached to the seat frame with the following:

- Two top hooks (A)
- Two side hooks (B)
- Two bottom retainers (C)




F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

- a. From the bottom of the seat, unhook the two seat skirt hooks as shown.




- b. Carefully pull upward on the lower seatback board to release the two bottom retainers (C).

CAUTION:

Do not pull outward at two top hooks (A)


- c. Hold the seatback board at the side hook locations (B) and push in the side hooks to release them from the seatback frame, then pull it rearward.



- d. Carefully pull the seatback board downward to disengage the top hooks as shown.

CAUTION:

Use care not to break the seatback board hooks and retainers. Replace seatback board if any hooks or retainers are damaged.




3. Disconnect the upper seat duct.

4. Remove and discard the two chute rod bolts (A), then remove the chute rod (1).

CAUTION:

Do not reuse the chute rod bolts.

Chute rod bolts (A) : 8.2 N·m (0.84 kg-m, 73 in-lb)




FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]


5. Release the seven seatback retainers from the seatback frame as shown.



6. Reach in from the bottom of the seatback to release the guide clips on the headrest holder. Squeeze the clips at the bottom and push upward to remove as shown.



7. Push the seatback trim and seatback pad forward at the bottom (1), then holding the seatback assembly on both sides, lift upward (2). Remove the seatback trim and seatback pad as an assembly from the seatback frame.



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]


8. If required, separate the seatback trim from the seatback pad as follows:

NOTE:

The seatback trim is attached to the seatback pad with the following:

- Five top hog rings (A)
- Four side hog rings (B)
- Three middle hog rings (C)
- Three bottom velcro fasteners (D)


- a. Pull the seatback trim from the seatback pad to detach the velcro fasteners.
- b. Position the seatback trim to access the middle hog rings. Remove the middle and side hog rings.
- c. Remove the top hog rings, then separate the seatback trim from the seatback pad.



Assembly


Assembly is in the reverse order of disassembly. During assembly, note the following.

- When installing the seatback trim, firmly push down while sliding your hand along the seams as shown (arrow) to ensure the velcro fasteners are fastened properly.



- Make sure the chute rod is properly positioned and installed as shown.

⇐: Front




FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

- Make sure the side air bag outer chute (7) is pulled over the side air bag module (3) and the side air bag inner chute (4) is pulled around the frame (2). Make sure there are no wrinkles and the chutes are not folded, twisted or pinched.

- (1) Seatback pad
 - (5) Chute rod
 - (6) Seatback board
- ⇐: Front



CAUTION:

- If a malfunction was detected by the air bag warning lamp, after repair or replacement of the malfunction parts, reset the memory using self-diagnosis or CONSULT.
- After work is completed, check that no system malfunction is detected by air bag warning lamp.
- Make sure side air bag module shell is closed at all tabs and cushion of module is not exposed. Do not reuse if the tab of shell is not secured.
- Always install new side air bag module attaching nuts and side air bag chute rod bolts.
- Always route side air bag module harness in original location. Replace any deformed or damaged clips with the same type and color. Always install clips in the original location on the harness.
- Smooth out all wrinkles during assembly.
- Inspect seatback pad, trim cover and trim cover chutes. Replace if damaged.
- Replace any deformed or damaged parts.
- Replace any deformed or damaged hog rings. Ensure any old hog ring pieces are removed from the seat.
- Use only one hog ring in each designated location.
- Ensure hog rings are correctly fastened around both the seatback trim and seatback pad trim wires.

NOTE:


Use NISSAN standard hog rings and tools to assemble.

SEAT CUSHION THERMAL ELECTRIC DEVICE AND LOWER SEAT DUCT

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]



- | | | |
|---|---|----------------------|
| 1. Seat control unit | 2. Lower seat duct | 3. Seat wire harness |
| 4. Climate controlled seat blower motor | 5. Seat cushion thermal electric device | 6. Upper seat duct |

Disassembly

1. Remove the seat from the vehicle. Refer to [SE-68, "Removal and Installation"](#).
2. Remove seatback board.
3. Remove seat cushion rear finisher.
4. Disconnect the harness connectors from the driver seat control unit.
5. Remove driver seat control unit from seat.
6. Remove seat cushion thermal electric device bolts.
7. Remove climate controlled seat blower motor bolts.
8. Disconnect climate controlled seat blower motor from upper seat duct.
9. Remove climate controlled seat blower motor, lower seat duct and seat cushion thermal electric device from seat.

Assembly

Assembly is in the reverse order of disassembly.

THIGH EXTENSION ASSEMBLY


Disassembly

FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]


1. Move the thigh extension assembly to the front most position and release the trim cover clips (A).
2. Remove the trim cover and pad (B).



3. Cut the thigh extension tethers and drill out the upper rivets (A) that connect the thigh extension tethers (B) to the thigh extension assembly (C).




4. Insert suitable tool into the thigh extension assembly top panel and release the clip (A).
5. Pull the thigh extension handle and remove the thigh extension assembly.



6. Drill out the lower rivets that connect the thigh extension tethers to the seat frame assembly.

Assembly

1. Replace the pad, trim and clips to the thigh extension assembly.
2. Rivet the thigh extension tethers to the seat frame assembly mounting hole (A).




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

3. Align the thigh extension assembly on the top rail.
4. Lift the thigh extension handle and slide the thigh extension assembly onto the seat.



5. Rivet the thigh extension tethers to the thigh extension assembly mounting hole (A).



PASSENGER SIDE

FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

PASSENGER SIDE : Exploded View

INFOID:00000009468153

Passenger Seat



- | | | |
|-------------------------------------|---|--------------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Headrest |
| 4. Seat harness | 5. Seat cushion inner finisher inside (RH) | 6. Recline device inner cover |
| 7. Seat cushion outer finisher (RH) | 8. Seat recline knob | 9. Seat slide and lifter switch knob |
| 10. Power seat switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Seat frame assembly | 15. Seat cushion outer finisher (LH) |
| 16. Recline mechanism inner cover | 17. Seat cushion inner finisher inside (LH) | 18. Seat belt buckle |
| 19. Seatback assembly | 20. Seatback pad | 21. Seatback trim |

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

22. Seatback frame

23. Chute rod

24. Side air bag module

25. Rear slide cover

26. Headrest holder (locked)

27. Headrest holder (free)

PASSENGER SIDE : Disassembly and Assembly

INFOID:000000009468154

SEAT ASSEMBLY WITH SIDE AIR BAG MODULE

WARNING:

Do not leave any objects (screwdriver, tools, etc.) on the seat during seatback repair. It can lead to personal injury if the side air bag should accidentally deploy.

CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least 3 minutes.
- Handle the side air bag module carefully. During disassembly, always hold the side air bag module, do not let it hang by the wire harness.
- Always place side air bag module with the stud bolt side facing downward.
- Always work from the side or back of the seatback assembly, do not work in front of seat.
- Do not use air tools or electric tools when servicing the seat assembly.
- Replace the side air bag module if it has been dropped or sustained an impact.
- Do not insert any objects into the side air bag module.
- Do not disassemble the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 93°C (200°F).
- Do not expose the side air bag module to any oil, grease or water.
- During disassembly, do not damage the trim cover, chutes, connectors, retainers, clips, module harness or the side air bag module.

NOTE:

- If the vehicle has been involved in a collision and the side air bag has deployed, the front seatback assembly must be replaced.
- For side air bag module removal and installation, refer to [SR-21, "Removal and Installation"](#).

Disassembly


1. Remove the front seat assembly. Refer to [SE-68, "Removal and Installation"](#).

2. Remove the seatback board as follows:


NOTE:

The seatback board is attached to the seat frame with the following:

- Two top hooks (A)
- Two side hooks (B)
- Two bottom retainers (C)



- a. From the bottom of the seat, unhook the two seat skirt hooks as shown.



FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >


[WITH CLIMATE CONTROLLED SEATS]

- b. Carefully pull upward on the lower seatback board to release the two bottom retainers (C).

CAUTION:

Do not pull outward at two top hooks (A).


- c. Hold the seatback board at the side hook locations (B) and push in the side hooks to release them from the seatback frame, then pull it rearward.



- d. Carefully pull the seatback board downward to disengage the top hooks as shown.

CAUTION:

Use care not to break the seatback board hooks and retainers. Replace seatback board if any hooks or retainers are damaged.




3. Remove and discard the two chute rod bolts (A), then remove the chute rod (1).


CAUTION:

Do not reuse the chute rod bolts.


Chute rod bolts (A) : 8.2 N·m (0.84 kg-m, 73 in-lb)



4. Release the seven seatback retainers from the seatback frame as shown.



5. Reach in from the bottom of the seatback to release the guide clips on the headrest holder. Squeeze the clips at the bottom and push upward to remove as shown.




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

6. Disconnect the harness connector for the seatback heater.
7. Push the seatback trim and seatback pad forward at the bottom (1), then holding the seatback assembly on both sides, lift upward (2). Remove the seatback trim and seatback pad as an assembly from the seatback frame.




8. If required, separate the seatback trim from the seatback pad as follows:

NOTE:

The seatback trim is attached to the seatback pad with the following:

- Five top hog rings (A)
- Three side hog rings (B)
- Three middle hog rings (C)
- Three bottom velcro fasteners (D)

- a. Pull the seatback trim cover from the seatback pad to detach the velcro fasteners.
- b. Position the seatback trim to access the middle hog rings. Remove the middle and side hog rings.
- c. Remove the top hog rings, then separate the seatback trim from the seatback pad.



Assembly


Assembly is in the reverse order of disassembly. During assembly, note the following.

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >


[WITH CLIMATE CONTROLLED SEATS]

- When installing the seatback trim, firmly push down while sliding your hand along the seams as shown (arrow) to ensure the velcro fasteners are fastened properly.




- Make sure the chute rod is properly positioned and installed as shown.

⇐: Front



- Make sure the side air bag outer chute (7) is pulled over the side air bag module (3) and the side air bag inner chute (4) is pulled around the frame (2). Make sure there are no wrinkles and the chutes are not folded, twisted or pinched.

- (1) Seatback pad
 - (5) Chute rod
 - (6) Seatback board
- ⇐: Front



CAUTION:

- If a malfunction was detected by the air bag warning lamp, after repair or replacement of the malfunction parts, reset the memory using self-diagnosis or CONSULT.
- After work is completed, check that no system malfunction is detected by air bag warning lamp.
- Make sure side air bag module shell is closed at all tabs and cushion of module is not exposed. Do not reuse if the tab of shell is not secured.
- Always install new side air bag module attaching nuts and side air bag chute rod bolts.
- Always route side air bag module harness in original location. Replace any deformed or damaged clips with the same type and color. Always install clips in the original location on the harness.
- Smooth out all wrinkles during assembly.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

- **Inspect seatback pad, trim cover and trim cover chutes. Replace if damaged.**
- **Replace any deformed or damaged parts.**
- **Replace any deformed or damaged hog rings. Ensure any old hog ring pieces are removed from seat.**
- **Use only one hog ring in each designated location.**
- **Ensure hog rings are correctly fastened around both the seatback trim and seatback pad trim wires.**

NOTE:

Use NISSAN standard hog rings and tools to assemble.

REAR SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Fixed Seatback

INFOID:000000009468155



- | | | |
|-----------------------------|---------------------------|-----------------------------|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Bumper | 5. Seatback assembly | 6. Seatback trim |
| 7. Seatback pad | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seat cushion assembly |

Exploded View - 60:40 Split Seatback


INFOID:000000009468156

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]



- | | | |
|--------------------------------|---------------------------------|-------------------------------|
| 1. Seatback latch striker (RH) | 2. Seatback trim (RH) | 3. Seatback pad (RH) |
| 4. Armrest assembly | 5. Inner armrest bracket (RH) | 6. Inner armrest bracket (LH) |
| 7. Seat cushion assembly | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seatback hinge assembly |
| 13. Seatback assembly (LH) | 14. Seatback latch striker (LH) | 15. Seatback frame (LH) |
| 16. Seatback pad (LH) | 17. Seatback trim (LH) | 18. Seatback frame (RH) |

REAR SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[WITH CLIMATE CONTROLLED SEATS]

- | | | |
|------------------------------|----------------------------|----------------------------|
| 19. Side bolster pad (LH) | 20. Side bolster trim (LH) | 21. Seat belt guide (LH) |
| 22. Seatback latch assembly | 23. Seatback latch cover | 24. Side bolster pad (RH) |
| 25. Side bolster trim (RH) | 26. Seat belt guide (RH) | 27. Seatback assembly (RH) |
| 28. Headrest holder (locked) | 29. Headrest holder (free) | 30. Headrest |

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

POWER SEAT FOR DRIVER SIDE

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


WIRING DIAGRAM

POWER SEAT FOR DRIVER SIDE

Wiring Diagram - Without Automatic Drive Positioner

INFOID:000000009468157

POWER SEAT FOR DRIVER SIDE - WITHOUT AUTOMATIC DRIVE POSITIONER



ABJWA0372GB

POWER SEAT FOR DRIVER SIDE


[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER

Terminal No.	Color of Wire	Signal Name
20J	R/Y	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	B	GND1

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

ABJIA0241GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


POWER SEAT FOR DRIVER SIDE

[W/O CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	LG	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-(WITHOUT AUTOMATIC DRIVE POSITIONER)


ABJIA0493GB

POWER SEAT FOR DRIVER SIDE

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

Connector No.	B209
Connector Name	POWER SEAT SWITCH LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	O	-
3	R/Y	-
4	B	-
5	GR	-
6	V	-
7	Y	-
8	B	-
9	R	-
10	V	-

Connector No.	B207
Connector Name	RECLINING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	O	-
2	GR	-

Connector No.	B204
Connector Name	FRONT POWER SEAT LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	R	-
3	V	-
4	GR	-
5	O	-
6	B/W	-

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

ABJIA0644GB

POWER SEAT FOR PASSENGER SIDE

[W/O CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

POWER SEAT FOR PASSENGER SIDE

Wiring Diagram

INFOID:000000009468158

POWER SEAT FOR PASSENGER SIDE



ABJWA0137GB


POWER SEAT FOR PASSENGER SIDE

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


POWER SEAT FOR PASSENGER SIDE CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	82G	Color of Wire	W/B	Signal Name	-
--------------	-----	---------------	-----	-------------	---

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	6	Color of Wire	R/Y	Signal Name	-
--------------	---	---------------	-----	-------------	---

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	1	Color of Wire	W/B	Signal Name	BATT (F/L)
Terminal No.	2	Color of Wire	R/Y	Signal Name	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	13	Color of Wire	B	Signal Name	GND1
--------------	----	---------------	---	-------------	------

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


ABJIA0242GB

POWER SEAT FOR PASSENGER SIDE

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	6	Color of Wire	SB	Signal Name	-
--------------	---	---------------	----	-------------	---

Terminal No.	82G	Color of Wire	LG	Signal Name	-
--------------	-----	---------------	----	-------------	---

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B307
Connector Name	RECLINING MOTOR RH
Connector Color	BLACK




Terminal No.	1	Color of Wire	W	Signal Name	-
Terminal No.	2	Color of Wire	GR	Signal Name	-

Connector No.	B306
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	1	Color of Wire	V	Signal Name	-
Terminal No.	2	Color of Wire	Y	Signal Name	-

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	4	Color of Wire	B	Signal Name	-
Terminal No.	7	Color of Wire	SB	Signal Name	-

ABJIA0385GB


POWER SEAT FOR PASSENGER SIDE

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

Connector No.	B309
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-
5	W	-
6	V	-
7	Y	-
10	GR	-

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
7	R/Y	-

AAJIA0404GB

HEATED SEAT


[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

HEATED SEAT

Wiring Diagram

INFOID:00000009468159



ABJWA0138GB


HEATED SEAT

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


HEATED SEAT CONNECTORS

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	8M	Color of Wire	G/R	Signal Name	-
--------------	----	---------------	-----	-------------	---

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	18J	Color of Wire	GR	Signal Name	-
	19J	Color of Wire	GR/R	Signal Name	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	3	Color of Wire	GR/L	Signal Name	-
	4	Color of Wire	GR/B	Signal Name	-

Connector No.	M87
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	1	Color of Wire	G/R	Signal Name	-
	3	Color of Wire	GR/B	Signal Name	-
	6	Color of Wire	GR	Signal Name	-
	9	Color of Wire	GR/L	Signal Name	-
	14	Color of Wire	GR/R	Signal Name	-
	15	Color of Wire	B	Signal Name	-
	16	Color of Wire	G/R	Signal Name	-

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	1	Color of Wire	G/R	Signal Name	-
	3	Color of Wire	GR/B	Signal Name	-
	6	Color of Wire	GR	Signal Name	-
	9	Color of Wire	GR/L	Signal Name	-
	14	Color of Wire	GR/R	Signal Name	-
	15	Color of Wire	B	Signal Name	-
	16	Color of Wire	G/R	Signal Name	-

AAJIA0025GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >

Connector No.	M301
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	W	-
3	O	-
4	B	-

Connector No.	M300
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	SB	-
2	G	-
3	GR	-
4	B	-

Connector No.	M208
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G/R	-
3	GR/B	-
5	GR/R	-
6	B	-
7	G/R	-
9	GR/L	-
15	GR	-


Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M305
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
3	GR	-
5	O	-
6	B	-
7	P	-
9	G	-
15	W	-




AAJIA0026GB

HEATED SEAT

< WIRING DIAGRAM >


[W/O CLIMATE CONTROLLED SEATS]

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	G	-
4	B	-
6	GR	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
4	GR	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	W	-
4	B/R	-(WITHOUT AUTOMATIC DRIVE POSITIONER)
6	O	-
7	B/W	-(WITHOUT CLIMATE CONTROLLED SEAT)

Connector No.	B304
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR/G	-
2	GR/R	-
3	B	-

Connector No.	B210
Connector Name	FRONT SEAT HEATER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	GR/W	-
3	W/B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
4	B	-
6	GR/W	-
7	GR/B	-

ABJIA0494GB


A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

HEATED SEAT

< WIRING DIAGRAM >

[W/O CLIMATE CONTROLLED SEATS]

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR/G	-
4	B	-
6	GR/R	-

AAJIA0028GB

LUMBAR SUPPORT SYSTEM

< WIRING DIAGRAM >


[W/O CLIMATE CONTROLLED SEATS]

LUMBAR SUPPORT SYSTEM

Wiring Diagram

INFOID:000000009468160

LUMBAR SUPPORT SYSTEM



AAJWA0013GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


LUMBAR SUPPORT SYSTEM

[W/O CLIMATE CONTROLLED SEATS]

< WIRING DIAGRAM >


LUMBAR SUPPORT SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
82G	W/B	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W/B	BATT (F/L)
2	R/Y	P/W POWER SUPPLY PERM

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	B	GND1

LUMBAR SUPPORT SYSTEM

[W/O CLIMATE CONTROLLED SEATS]


< WIRING DIAGRAM >

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BR	-
4	B/R	-(WITHOUT AUTOMATIC DRIVE POSITIONER)

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20J	BR	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
82G	LG	-
83G		

Connector No.	B221
Connector Name	LUMBAR SUPPORT MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-

Connector No.	B214
Connector Name	LUMBAR SUPPORT SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/L	-
2	R/W	-
3	B	-
4	R/Y	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R/Y	-
4	B	-

ABJIA0495GB

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >


[W/O CLIMATE CONTROLLED SEATS]

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000009895340



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-114, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.Refer to [SE-112. "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000009895341

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.
3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

Diagnostic Worksheet

INFOID:000000009895342





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

[W/O CLIMATE CONTROLLED SEATS]

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about ____ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: _____
- After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LAIA0071E

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009468164

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Service Notice

INFOID:000000009468165

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Precaution for Work

INFOID:000000009468166

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:

PRECAUTIONS

< PRECAUTION >

[W/O CLIMATE CONTROLLED SEATS]

- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

PREPARATION

[W/O CLIMATE CONTROLLED SEATS]

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tools


INFOID:000000009895343

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis Ear	Locating the noise
— (J-46534) Trim Tool Set	Removing trim components
— (J-50397) NISSAN Squeak and Rattle Kit	Repairing the cause of noise



SIIA0993E



AWJIA0483ZZ




ALJIA1232ZZ


Commercial Service Tool

INFOID:000000009468168

(Kent-Moore No.) Tool name	Description
(J-39565) Engine Ear	Locating the noise
Hook and pick tool	Remove the snap pins



SIIA0995E



JMJIA0490ZZ

CLIP LIST

< PREPARATION >

















[W/O CLIMATE CONTROLLED SEATS]

CLIP LIST

Descriptions for Clips

INFOID:000000009468169

Replace any clips which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
C101 		<p>Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.</p> 
C103 		 <p>Removal: Remove with a clip remover.</p>
C203 		<p>Removal: Push center pin to catching position. (Do not remove center pin by hitting it.)</p> <p>Push</p>  <p>Installation:</p> <p>Push</p> 
C205 		<p>Removal:</p> <p>Flat-bladed screwdriver</p>  <p>Clip</p> <p>Finisher</p>
C206 		<p>Removal:</p> 
















SIIA0315E

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIP LIST

< PREPARATION >

[W/O CLIMATE CONTROLLED SEATS]














Symbol No.	Shapes	Removal & Installation
<p>CE103</p> 		<p>Removal:</p> 
<p>CF110</p> 		<p>Removal:</p> 
<p>CF118</p> 		<p>Removal:</p> 
<p>CR103</p> 		<p>Removal: Holder portion of clip must be spread out to remove rod.</p> 
<p>CS101</p> 		<p>Removal:</p> <ol style="list-style-type: none"> 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver. 

SIIA0316E

CLIP LIST

< PREPARATION >

[W/O CLIMATE CONTROLLED SEATS]

Symbol No.	Shapes	Removal & Installation	
CG101 		Removal:  Rotate 45° to remove	Installation: 
CS102 			
CS113 		Removal: Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip. 	
C111 			










SIIA0317E

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIP LIST

< PREPARATION >

[W/O CLIMATE CONTROLLED SEATS]

Symbol No.	Shapes	Removal & Installation
<p>CG104</p> 		<p>Removal: Remove by bending up with flat-bladed screwdrivers.</p>  <p>Radiator grille Body panel</p>
<p>CE114</p> 		
<p>CF118</p> 	 <p>Clip A Clip B (Grommet)</p>	<p>Removal: Flat-bladed screwdrivers Finisher</p>  <p>Body panel Clip A Clip B (Grommet)</p>

ALJIA0564GB

FRONT SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

REMOVAL AND INSTALLATION


FRONT SEAT

Exploded View

DRIVER

INFOID:000000009468170

Driver Seat - Without Climate Controlled Seats



- | | | |
|----------------------------------|-------------------------------------|--|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Seatback board | 5. Seatback board clip | 6. Seat cushion inner finisher inside (RH) |
| 7. Recline mechanism inner cover | 8. Seat cushion outer finisher (RH) | 9. Seat belt buckle |

FRONT SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

-
- | | | |
|---|--|---|
| 10. Seat cushion trim | 11. Seat cushion pad | 12. Seat cushion assembly |
| 13. Thigh extension tether | 14. Thigh extension assembly | 15. Seat harness |
| 16. Seat cushion trim (w/o thigh extension) | 17. Seat cushion pad (w/o thigh extension) | 18. Seat cushion assembly (w/o thigh extension) |
| 19. Seat cushion front finisher | 20. Front slide cover | 21. Seat frame assembly |
| 22. Power seat control unit | 23. Actuator bracket | 24. Rear slide cover |
| 25. Power seat switch | 26. Seat slide and lifter switch knob | 27. Seat recline knob |
| 28. Lumbar support switch (if equipped) | 29. Lumbar lever (if equipped) | 30. Seat cushion outer finisher (LH) |
| 31. Recline device outer cover | 32. Seat cushion inner finisher (LH) | 33. Side air bag module |
| 34. Seatback frame | 35. Seatback pad | 36. Seatback trim |
| 37. Seatback assembly | 38. Chute rod | |


PASSENGER

FRONT SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

Passenger Seat



- | | | |
|-------------------------------------|---|--------------------------------------|
| 1. Seatback board | 2. Seatback board clip | 3. Headrest |
| 4. Seat harness | 5. Seat cushion inner finisher inside (RH) | 6. Recline device inner cover |
| 7. Seat cushion outer finisher (RH) | 8. Seat recline knob | 9. Seat slide and lifter switch knob |
| 10. Power seat switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Seat frame assembly | 15. Seat cushion outer finisher (LH) |
| 16. Recline mechanism inner cover | 17. Seat cushion inner finisher inside (LH) | 18. Seat belt buckle |
| 19. Seatback assembly | 20. Seatback pad | 21. Seatback trim |
| 22. Seatback frame | 23. Chute rod | 24. Side air bag module |
| 25. Rear slide cover | 26. Headrest holder (locked) | 27. Headrest holder (free) |

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

Removal and Installation

INFOID:00000009468171

REMOVAL


WARNING:

Do not leave any objects (screwdrivers, tools, etc.) on the seat during seat repair. It can lead to personal injury if the side air bag module should accidentally deploy.


CAUTION:

- When removing or installing the seat trim, handle it carefully to keep dirt out and to avoid damage.
- When checking the power seat circuit for continuity using a circuit tester, do not confuse its connector with the side air bag module connector. Such an error may cause the air bag module to deploy.
- Do not drop, tilt, or bump the side air bag module while installing the seat. Always handle it with care.
- After the front side air bag module inflates, the front seatback assembly must be replaced.
- When removing and installing the seat, use shop cloths to protect components from damage.
- Before removing the front seat, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.


1. Slide the seat to the full forward position.
2. Remove the rear slide covers.
 - a. Release the pawls (A).



- b. Remove the rear slide covers.
3. Remove the rear mount bolts.



4. Slide the seat to the full rearward position.
5. Remove the front slide covers.
6. Remove the front mount bolts.



7. Disconnect the negative and positive battery terminals and wait at least three minutes. Refer to [PG-67](#), "[Removal and Installation \(Battery\)](#)".

FRONT SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

8. Disconnect the harness connector under the seat and remove harness clips.
9. Remove seat from the vehicle.

INSTALLATION

Installation is in the reverse order of removal.


CAUTION:

Make sure that the seat harness or the floor trim is not damaged during installation.

NOTE:


- When installing the LH front seat, tighten the bolts in the order shown.

LH front seat bolt torque : 49 Nm (5.0 kg-m, 36 ft-lb)



- When installing the RH front seat, tighten the bolts in the order shown.

RH front seat bolt torque : 49 Nm (5.0 kg-m, 36 ft-lb)



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT


< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Fixed Seatback

INFOID:000000009468172



- | | | |
|-----------------------------|---------------------------|-----------------------------|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Bumper | 5. Seatback assembly | 6. Seatback trim |
| 7. Seatback pad | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seat cushion assembly |

Removal and Installation

INFOID:000000009468173

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

SEAT CUSHION ASSEMBLY


Removal

REAR SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

1. Locate the seat cushion lock (2) at the front bottom of the seat cushion assembly (one for each side). Pull the release lever (A) forward and lift the seat cushion assembly upward to release the seat cushion wire (1) from the seat cushion lock (2).
⇐: Front
2. Then pull the seat cushion assembly forward to remove.




Installation

Installation is in the reverse order of removal.

SEATBACK

Removal

1. Remove the seat cushion assembly.
2. Remove the headrests (LH/RH).
3. Remove the seatback frame bolts and nut.



4. Lift the seatback to disengage seat hook wires from the hangers.

Installation

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


REAR SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

Exploded View - 60:40 Split Seatback

INFOID:000000009468174



- | | | |
|--------------------------------|-------------------------------|-------------------------------|
| 1. Seatback latch striker (RH) | 2. Seatback trim (RH) | 3. Seatback pad (RH) |
| 4. Armrest assembly | 5. Inner armrest bracket (RH) | 6. Inner armrest bracket (LH) |
| 7. Seat cushion assembly | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seatback hinge assembly |

REAR SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|------------------------------|---------------------------------|----------------------------|
| 13. Seatback assembly (LH) | 14. Seatback latch striker (LH) | 15. Seatback frame (LH) |
| 16. Seatback pad (LH) | 17. Seatback trim (LH) | 18. Seatback frame (RH) |
| 19. Side bolster pad (LH) | 20. Side bolster trim (LH) | 21. Seat belt guide (LH) |
| 22. Seatback latch assembly | 23. Seatback latch cover | 24. Side bolster pad (RH) |
| 25. Side bolster trim (RH) | 26. Seat belt guide (RH) | 27. Seatback assembly (RH) |
| 28. Headrest holder (locked) | 29. Headrest holder (free) | 30. Headrest |

Removal and Installation

INFOID:000000009468175

CAUTION:

When removing and installing, use shop cloths to protect parts from damage.


SEAT CUSHION ASSEMBLY

Removal

1. Locate the seat cushion lock (2) at the front bottom of the seat cushion assembly (one for each side). Pull the release lever (A) forward and lift the seat cushion assembly upward to release the seat cushion wire (1) from the seat cushion lock (2).

↔: Front

2. Then pull the seat cushion assembly forward to remove.




Installation

Installation is in the reverse order of removal.


SEATBACK

Removal

1. Lock seatback (LH/RH) in upright position.
2. Remove the seatback hinge assembly bolts and nut.
3. Fold seatback (LH/RH) forward.



4. Remove seatback latch covers (A).
5. Remove the halo upper frame assembly bolts (B).
6. Remove the seatback assembly.



Installation

A
B
C
D
E
F
G
H
I
K
L
M
N
O
P

SE

REAR SEAT

< REMOVAL AND INSTALLATION >

[W/O CLIMATE CONTROLLED SEATS]

Installation is in the reverse order of removal.

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

UNIT DISASSEMBLY AND ASSEMBLY


FRONT SEAT

DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:000000009468176

Driver Seat - Without Climate Controlled Seats



- | | | |
|----------------------------------|-------------------------------------|--|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Seatback board | 5. Seatback board clip | 6. Seat cushion inner finisher inside (RH) |
| 7. Recline mechanism inner cover | 8. Seat cushion outer finisher (RH) | 9. Seat belt buckle |

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|---|--|---|
| 10. Seat cushion trim | 11. Seat cushion pad | 12. Seat cushion assembly |
| 13. Thigh extension tether | 14. Thigh extension assembly | 15. Seat harness |
| 16. Seat cushion trim (w/o thigh extension) | 17. Seat cushion pad (w/o thigh extension) | 18. Seat cushion assembly (w/o thigh extension) |
| 19. Seat cushion front finisher | 20. Front slide cover | 21. Seat frame assembly |
| 22. Power seat control unit | 23. Actuator bracket | 24. Rear slide cover |
| 25. Power seat switch | 26. Seat slide and lifter switch knob | 27. Seat recline knob |
| 28. Lumbar support switch (if equipped) | 29. Lumbar lever (if equipped) | 30. Seat cushion outer finisher (LH) |
| 31. Recline device outer cover | 32. Seat cushion inner finisher (LH) | 33. Side air bag module |
| 34. Seatback frame | 35. Seatback pad | 36. Seatback trim |
| 37. Seatback assembly | 38. Chute rod | |

DRIVER SIDE : Disassembly and Assembly

INFOID:000000009468177

SEAT ASSEMBLY WITH SIDE AIR BAG MODULE

WARNING:

Do not leave any objects (screwdriver, tools, etc.) on the seat during seatback repair. It can lead to personal injury if the side air bag should accidentally deploy.

CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
- Handle the side air bag module carefully. During disassembly, always hold the side air bag module, do not let it hang by the wire harness.
- Always place side air bag module with the stud bolt side facing downward.
- Always work from the side or back of the seatback assembly, do not work in front of the seat.
- Do not use air tools or electric tools when servicing the seat assembly.
- Replace the side air bag module if it has been dropped or sustained an impact.
- Do not insert any objects into the side air bag module.
- Do not disassemble the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 93°C (200°F).
- Do not expose the side air bag module to any oil, grease or water.
- During disassembly, do not damage the trim cover, chutes, connectors, retainers, clips, module harness or the side air bag module.

NOTE:

- If the vehicle has been involved in a collision and the side air bag has deployed, the front seatback assembly must be replaced.
- For side air bag module removal and installation, refer to [SR-21, "Removal and Installation"](#).


Disassembly

1. Remove the front seat assembly. Refer to [SE-126, "Removal and Installation"](#).
2. Remove the seatback board as follows:

NOTE:

The seatback board is attached to the seat frame with the following:

- Two top hooks (A)
- Two side hooks (B)
- Two bottom retainers (C)




ALJIA0587ZZ

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- a. From the bottom of the seat, unhook the two seat skirt hooks as shown.




- b. Carefully pull upward on the lower seatback board to release the two bottom retainers (C).

CAUTION:

Do not pull outward at two top hooks (A)


- c. Hold the seatback board at the side hook locations (B) and push in the side hooks to release them from the seatback frame, then pull it rearward.



- d. Carefully pull the seatback board downward to disengage the top hooks as shown.

CAUTION:

Use care not to break the seatback board hooks and retainers. Replace seatback board if any hooks or retainers are damaged.




3. Remove and discard the two chute rod bolts (A), then remove the chute rod (1).


CAUTION:

Do not reuse the chute rod bolts.

Chute rod bolts (A) : 8.2 N·m (0.84 kg-m, 73 in-lb)



4. Release the seven seatback retainers from the seatback frame as shown.




A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

5. Reach in from the bottom of the seatback to release the guide clips on the headrest holder. Squeeze the clips at the bottom and push upward to remove as shown.



6. Disconnect the harness connector for the seatback heater (if equipped).
7. Push the seatback trim and seatback pad forward at the bottom (1), then holding the seatback assembly on both sides, lift upward (2). Remove the seatback trim and seatback pad as an assembly from the seatback frame.




8. If required, separate the seatback trim from the seatback pad as follows:

NOTE:

The seatback trim is attached to the seatback pad with the following:

- Five top hog rings (A)
- Four side hog rings (B)
- Three middle hog rings (C)
- Three bottom velcro fasteners (D)

- a. Pull the seatback trim cover from the seatback pad to detach the velcro fasteners.
- b. Position the seatback trim to access the middle hog rings. Remove the middle and side hog rings.
- c. Remove the top hog rings, then separate the seatback trim from the seatback pad.



FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

Assembly


Assembly is in the reverse order of disassembly.

- When installing the seatback trim, firmly push down while sliding your hand along the seams as shown (arrow) to ensure the velcro fasteners are fastened properly.



- Make sure the chute rod is properly positioned and installed as shown.


⇐: Front



- Make sure the side air bag outer chute (7) is pulled over the side air bag module (3) and the side air bag inner chute (4) is pulled around the frame (2). Make sure there are no wrinkles and the chutes are not folded, twisted or pinched.

- (1) Seatback pad
- (2) Frame
- (3) Side air bag module
- (4) Inner side air bag chute
- (5) Chute rod
- (6) Seatback board
- (7) Outer chute

⇐: Front



CAUTION:

- If a malfunction was detected by the air bag warning lamp, after repair or replacement of the malfunction parts, reset the memory using self-diagnosis or CONSULT.
- After work is completed, check that no system malfunction is detected by air bag warning lamp.
- Make sure side air bag module shell is closed at all tabs and cushion of module is not exposed. Do not reuse if the tab of shell is not secured.
- Always install new side air bag module attaching nuts and side air bag chute rod bolts.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- Always route side air bag module harness in original location. Replace any deformed or damaged clips with the same type and color. Always install clips in the original location on the harness.
- Smooth out all wrinkles during assembly.
- Inspect seatback pad, trim cover and trim cover chutes. Replace if damaged.
- Replace any deformed or damaged parts.
- Replace any deformed or damaged hog rings. Ensure any old hog ring pieces are removed from the seat.
- Use only one hog ring in each designated location.
- Ensure hog rings are correctly fastened around both the seatback trim and seatback pad trim wires.


NOTE:

Use NISSAN standard hog rings and tools to assemble.


THIGH EXTENSION ASSEMBLY

Disassembly


1. Move the thigh extension assembly to the front most position and release the trim cover clips (A).
2. Remove the trim and pad (B).



3. Cut the thigh extension tethers and drill out the upper rivets (A) that connect the thigh extension tethers (B) to the thigh extension assembly (C).



4. Insert suitable tool into the thigh extension assembly top panel and release the clip (A).
5. Pull the thigh extension handle and remove the thigh extension assembly.



6. Drill out the lower rivets that connect the thigh extension tethers to the seat frame assembly.

Assembly


1. Replace the pad, trim and clips and to the thigh extension assembly.

FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]


2. Rivet the thigh extension tethers to the seat frame assembly mounting hole (A).



3. Align the thigh extension assembly on the top rail.
4. Lift the thigh extension handle and slide the thigh extension assembly onto the seat.



5. Rivet the thigh extension tethers to the thigh extension assembly mounting hole (A).



PASSENGER SIDE

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

PASSENGER SIDE : Exploded View

INFOID:00000009468178

Passenger Seat



- | | | |
|-------------------------------------|---|--------------------------------------|
| 1. Seatback board | 2. Seatback board clips | 3. Headrest |
| 4. Seat harness | 5. Seat cushion inner finisher inside (RH) | 6. Recline device inner cover |
| 7. Seat cushion outer finisher (RH) | 8. Seat recline knob | 9. Seat slide and lifter switch knob |
| 10. Power seat switch | 11. Seat cushion assembly | 12. Seat cushion front finisher |
| 13. Front slide cover | 14. Seat frame assembly | 15. Seat cushion outer finisher (LH) |
| 16. Recline mechanism inner cover | 17. Seat cushion inner finisher inside (LH) | 18. Seat belt buckle |
| 19. Seatback assembly | 20. Seatback pad | 21. Seatback trim |

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- | | | |
|----------------------|------------------------------|----------------------------|
| 22. Seatback frame | 23. Chute rod | 24. Side air bag module |
| 25. Rear slide cover | 26. Headrest holder (locked) | 27. Headrest holder (free) |

PASSENGER SIDE : Disassembly and Assembly

INFOID:000000009468179

SEAT ASSEMBLY WITH SIDE AIR BAG MODULE

WARNING:

Do not leave any objects (screwdriver, tools, etc.) on the seat during seatback repair. It can lead to personal injury if the side air bag should accidentally deploy.

CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
- Handle the side air bag module carefully. During disassembly, always hold the side air bag module, do not let it hang by the wire harness.
- Always place side air bag module with the stud bolt side facing downward.
- Always work from the side or back of the seatback assembly, do not work in front of seat.
- Do not use air tools or electric tools when servicing the seat assembly.
- Replace the side air bag module if it has been dropped or sustained an impact.
- Do not insert any objects into the side air bag module.
- Do not disassemble the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 93°C (200°F).
- Do not expose the side air bag module to any oil, grease or water.
- During disassembly, do not damage the trim cover, chutes, connectors, retainers, clips, module harness or the side air bag module.

NOTE:

- If the vehicle has been involved in a collision and the side air bag has deployed, the front seatback assembly must be replaced.
- For side air bag module removal and installation, refer to [SR-21, "Removal and Installation"](#).


Disassembly

1. Remove the front seat assembly. Refer to [SE-126, "Removal and Installation"](#).
2. Remove the seatback board as follows:


NOTE:

The seatback board is attached to the seat frame with the following:

- Two top hooks (A)
- Two side hooks (B)
- Two bottom retainers (C)



- a. From the bottom of the seat, unhook the two seat skirt hooks as shown.



FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >


[W/O CLIMATE CONTROLLED SEATS]

- b. Carefully pull upward on the lower seatback board to release the two bottom retainers (C).

CAUTION:

Do not pull outward at two top hooks (A)


- c. Hold the seatback board at the side hook locations (B) and push in the side hooks to release them from the seatback frame, then pull it rearward.



- d. Carefully pull the seatback board downward to disengage the top hooks as shown.

CAUTION:

Use care not to break the seatback board hooks and retainers. Replace seatback board if any hooks or retainers are damaged.




3. Remove and discard the two chute rod bolts (A), then remove the chute rod (1).


CAUTION:

Do not reuse the chute rod bolts.


Chute rod bolts (A) : 8.2 N·m (0.84 kg-m, 73 in-lb)



4. Release the seven seatback retainers from the seatback frame as shown.



5. Reach in from the bottom of the seatback to release the guide clips on the headrest holder. Squeeze the clips at the bottom and push upward to remove as shown.




FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

6. Disconnect the harness connector for the seatback heater (if equipped).
7. Push the seatback trim and seatback pad forward at the bottom (1), then holding the seatback assembly on both sides, lift upward (2). Remove the seatback trim and seatback pad as an assembly from the seatback frame.




8. If required, separate the seatback trim from the seatback pad as follows:

NOTE:

The seatback trim is attached to the seatback pad with the following:

- Five top hog rings (A)
- Four side hog rings (B)
- Three middle hog rings (C)
- Three bottom velcro fasteners (D)

- a. Pull the seatback trim cover from the seatback pad to detach the velcro fasteners.
- b. Position the seatback trim to access the middle hog rings. Remove the middle and side hog rings.
- c. Remove the top hog rings, then separate the seatback trim from the seatback pad.



Assembly


Assembly is in the reverse order of disassembly. During assembly, note the following.

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >


[W/O CLIMATE CONTROLLED SEATS]

- When installing the seatback trim, firmly push down while sliding your hand along the seams as shown (arrow) to ensure the velcro fasteners are fastened properly.




- Make sure the chute rod is properly positioned and installed as shown.

↔: Front



- Make sure the side air bag outer chute (7) is pulled over the side air bag module (3) and the side air bag inner chute (4) is pulled around the frame (2). Make sure there are no wrinkles and the chutes are not folded, twisted or pinched.

(1) Seatback pad
(5) Chute rod
(6) Seatback board
↔: Front



CAUTION:

- If a malfunction was detected by the air bag warning lamp, after repair or replacement of the malfunction parts, reset the memory using self-diagnosis or CONSULT.
- After work is completed, check that no system malfunction is detected by air bag warning lamp.
- Make sure side air bag module shell is closed at all tabs and cushion of module is not exposed. Do not reuse if the tab of shell is not secured.
- Always install new side air bag module attaching nuts and side air bag chute rod bolts.
- Always route side air bag module harness in original location. Replace any deformed or damaged clips with the same type and color. Always install clips in the original location on the harness.
- Smooth out all wrinkles during assembly.

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

- Inspect seatback pad, trim cover and trim cover chutes. Replace if damaged.
- Replace any deformed or damaged parts.
- Replace any deformed or damaged hog rings. Ensure any old hog ring pieces are removed from seat.
- Use only one hog ring in each designated location.
- Ensure hog rings are correctly fastened around both the seatback trim and pad trim wires.

NOTE:

Use NISSAN standard hog rings and tools to assemble.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

REAR SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

REAR SEAT

Exploded View - Fixed Seatback

INFOID:000000009468180



- | | | |
|-----------------------------|---------------------------|-----------------------------|
| 1. Headrest | 2. Headrest holder (free) | 3. Headrest holder (locked) |
| 4. Bumper | 5. Seatback assembly | 6. Seatback trim |
| 7. Seatback pad | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seat cushion assembly |


Exploded View - 60:40 Split Seatback

INFOID:000000009468181

REAR SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]



- | | | |
|--------------------------------|---------------------------------|-------------------------------|
| 1. Seatback latch striker (RH) | 2. Seatback trim (RH) | 3. Seatback pad (RH) |
| 4. Armrest assembly | 5. Inner armrest bracket (RH) | 6. Inner armrest bracket (LH) |
| 7. Seat cushion assembly | 8. Seat cushion trim | 9. Seat cushion pad |
| 10. Seat cushion wire cover | 11. Seat cushion lock | 12. Seatback hinge assembly |
| 13. Seatback assembly (LH) | 14. Seatback latch striker (LH) | 15. Seatback frame (LH) |
| 16. Seatback pad (LH) | 17. Seatback trim (LH) | 18. Seatback frame (RH) |

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

REAR SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

[W/O CLIMATE CONTROLLED SEATS]

-
- | | | |
|------------------------------|----------------------------|----------------------------|
| 19. Side bolster pad (LH) | 20. Side bolster trim (LH) | 21. Seat belt guide (LH) |
| 22. Seatback latch assembly | 23. Seatback latch cover | 24. Side bolster pad (RH) |
| 25. Side bolster trim (RH) | 26. Seat belt guide (RH) | 27. Seatback assembly (RH) |
| 28. Headrest holder (locked) | 29. Headrest holder (free) | 30. Headrest |