

SECTION **SE**  
SEAT

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

CONTENTS

<b>PRECAUTION</b> .....	3	LUMBAR SUPPORT SYSTEM : Component Parts Location .....	13
<b>PRECAUTIONS</b> .....	3	LUMBAR SUPPORT SYSTEM : Lumbar Support Switch .....	14
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	LUMBAR SUPPORT SYSTEM : Lumbar Support Motor .....	14
Precaution for Work .....	3	<b>HEATED SEAT SYSTEM</b> .....	14
<b>PREPARATION</b> .....	4	HEATED SEAT SYSTEM : Component Parts Location .....	15
<b>PREPARATION</b> .....	4	HEATED SEAT SYSTEM : Front Heated Seat Switch .....	16
Special Service Tools .....	4	HEATED SEAT SYSTEM : Front Seat Heater .....	16
Commercial Service Tools .....	4	<b>SYSTEM</b> .....	17
<b>CLIP LIST</b> .....	5	<b>CLIMATE CONTROLLED SEAT SYSTEM</b> .....	17
Descriptions for Clips .....	5	CLIMATE CONTROLLED SEAT SYSTEM : System Description .....	17
<b>SYSTEM DESCRIPTION</b> .....	9	<b>POWER SEAT SYSTEM</b> .....	17
<b>COMPONENT PARTS</b> .....	9	POWER SEAT SYSTEM : System Description .....	18
<b>CLIMATE CONTROLLED SEAT SYSTEM</b> .....	9	<b>LUMBAR SUPPORT SYSTEM</b> .....	18
CLIMATE CONTROLLED SEAT SYSTEM : Component Parts Location .....	9	LUMBAR SUPPORT SYSTEM : System Description .....	18
CLIMATE CONTROLLED SEAT SYSTEM : Climate Controlled Seat Switch .....	10	<b>HEATED SEAT SYSTEM</b> .....	18
CLIMATE CONTROLLED SEAT SYSTEM : Climate controlled seat blower motor assembly .....	10	HEATED SEAT SYSTEM : System Description .....	18
CLIMATE CONTROLLED SEAT SYSTEM : Seat Back Thermal Electric Device .....	10	<b>ECU DIAGNOSIS INFORMATION</b> .....	19
CLIMATE CONTROLLED SEAT SYSTEM : Climate Controlled Seat Control Unit .....	11	<b>CLIMATE CONTROLLED SEAT CONTROL UNIT</b> .....	19
<b>POWER SEAT SYSTEM</b> .....	11	Reference Value .....	19
POWER SEAT SYSTEM : Component Parts Location .....	11	Fail-safe .....	20
POWER SEAT SYSTEM : Power Seat Switch .....	12	<b>WIRING DIAGRAM</b> .....	22
POWER SEAT SYSTEM : Sliding Motor .....	12	<b>POWER SEAT FOR DRIVER SIDE</b> .....	22
POWER SEAT SYSTEM : Lifting Motor .....	13	Wiring Diagram - Without Automatic Drive Positioner .....	22
POWER SEAT SYSTEM : Reclining Motor .....	13		
<b>LUMBAR SUPPORT SYSTEM</b> .....	13		

<b>POWER SEAT FOR PASSENGER SIDE</b> .....	26	Diagnosis Procedure .....	63
Wiring Diagram .....	26	<b>SYMPTOM DIAGNOSIS</b> .....	64
<b>HEATED SEAT</b> .....	29	<b>CLIMATE CONTROLLED SEAT SYSTEM</b> .....	64
Wiring Diagram .....	29	Symptom Table .....	64
<b>LUMBAR SUPPORT SYSTEM</b> .....	33	<b>SQUEAK AND RATTLE TROUBLE DIAG- NOSES</b> .....	65
Wiring Diagram .....	33	Work Flow .....	65
<b>CLIMATE CONTROLLED SEAT</b> .....	36	Generic Squeak and Rattle Troubleshooting .....	66
Wiring Diagram .....	36	Diagnostic Worksheet .....	69
<b>BASIC INSPECTION</b> .....	44	<b>REMOVAL AND INSTALLATION</b> .....	71
<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	44	<b>FRONT SEAT</b> .....	71
Work Flow .....	44	Exploded View .....	71
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	46	Removal and Installation .....	79
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	46	Seatback Thermal Electric Device .....	80
<b>CLIMATE CONTROLLED SEAT CONTROL UNIT...</b>	46	Climate Controlled Seat Blower Assembly .....	81
CLIMATE CONTROLLED SEAT CONTROL UNIT		Climate Controlled Seat Switch .....	82
: Diagnosis Procedure .....	46	Front Heated Seat Switch .....	83
CLIMATE CONTROLLED SEAT CONTROL UNIT		Front Seat Heater .....	83
: Component Inspection .....	49	Climate Controlled Seat Control Unit .....	83
<b>SEATBACK THERMAL ELECTRIC DEVICE</b> ...	50	Power Seat Switch .....	84
Component Function Check .....	50	Lumbar Support Switch .....	86
Diagnosis Procedure .....	50	<b>REAR SEAT</b> .....	88
<b>SEATBACK THERMAL ELECTRIC DEVICE SENSOR</b> .....	52	Exploded View .....	88
Component Function Check .....	52	Removal and Installation .....	89
Diagnosis Procedure .....	52	Removal and Installation - Seatback Latch As- sembly .....	90
Component Inspection .....	53	Removal and Installation - Seatback Hinge .....	91
<b>SEAT CUSHION THERMAL ELECTRIC DE- VICE</b> .....	54	Removal and Installation - Armrest Assembly .....	92
Component Function Check .....	54	Removal and Installation - Rear Seat Bolster .....	93
Diagnosis Procedure .....	54	<b>UNIT DISASSEMBLY AND ASSEMBLY</b> ...	94
<b>SEAT CUSHION THERMAL ELECTRIC DE- VICE SENSOR</b> .....	56	<b>FRONT SEAT</b> .....	94
Component Function Check .....	56	<b>DRIVER SIDE</b> .....	94
Diagnosis Procedure .....	56	DRIVER SIDE : Exploded View .....	94
Component Inspection .....	57	DRIVER SIDE : Seatback .....	98
<b>CLIMATE CONTROLLED SEAT BLOWER MOTOR</b> .....	58	DRIVER SIDE : Seat Cushion .....	99
Component Function Check .....	58	<b>PASSENGER SIDE</b> .....	103
Diagnosis Procedure .....	58	PASSENGER SIDE : Exploded View .....	103
<b>CLIMATE CONTROLLED SEAT SWITCH IN- DICATOR</b> .....	61	PASSENGER SIDE : Seatback .....	107
Component Function Check .....	61	PASSENGER SIDE : Seat Cushion .....	108
Diagnosis Procedure .....	61	<b>REAR SEAT</b> .....	112
<b>CLIMATE CONTROLLED SEAT BLOWER FILTER</b> .....	63	Exploded View .....	112
		<b>SEATBACK</b> .....	113
		SEATBACK : Disassembly and Assembly .....	113
		<b>SEAT CUSHION</b> .....	119
		SEAT CUSHION : Disassembly and Assembly ...	119

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012326471

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Work

INFOID:000000011932926

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

# PREPARATION

< PREPARATION >

## PREPARATION


### PREPARATION

#### Special Service Tools


INFOID:000000011932927

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-39570) Chassis Ear	Locating the noise
— (J-46534) Trim Tool Set	Removing trim components
— (J-50397) NISSAN Squeak and Rattle Kit	Repairing the cause of noise



SIIA0993E



AWJIA0483ZZ




ALJIA1232ZZ

#### Commercial Service Tools

INFOID:000000011932928

(TechMate No.) Tool name	Description
(J-39565) Engine Ear	Locating the noise



SIIA0995E

# CLIP LIST

















< PREPARATION >

## CLIP LIST

Descriptions for Clips

INFOID:000000011932929

Replace any clips which are damaged during removal or installation.
















Symbol No.	Shapes	Removal & Installation
C101 		<p><b>Removal:</b> Remove by bending up with flat-bladed screwdrivers or clip remover.</p> 
C103 		 <p><b>Removal:</b> Remove with a clip remover.</p>
C203 		<p><b>Removal:</b> Push center pin to catching position. (Do not remove center pin by hitting it.)</p> <p>Push</p>  <p><b>Installation:</b></p> <p>Push</p> 
C205 		<p><b>Removal:</b> Flat-bladed screwdriver</p>  <p>Clip Finisher</p>
C206 		<p><b>Removal:</b></p> 

SIIA0315E

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# CLIP LIST














## < PREPARATION >

Symbol No.	Shapes	Removal & Installation
<p>CE103</p> 		<p><b>Removal:</b></p> 
<p>CF110</p> 		<p><b>Removal:</b></p> 
<p>CF118</p> 		<p><b>Removal:</b></p> 
<p>CR103</p> 		<p><b>Removal:</b> Holder portion of clip must be spread out to remove rod.</p> 
<p>CS101</p> 		<p><b>Removal:</b></p> <ol style="list-style-type: none"> <li>1. Screw out with a Phillips screwdriver.</li> <li>2. Remove female portion with flat-bladed screwdriver.</li> </ol> 

SIIA0316E

# CLIP LIST

< PREPARATION >










Symbol No.	Shapes	Removal & Installation	
CG101 		<b>Removal:</b>  Rotate 45° to remove	<b>Installation:</b> 
CS102 			
CS113 		<b>Removal:</b> Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip. 	
C111 			

SIIA0317E

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# CLIP LIST

< PREPARATION >

Symbol No.	Shapes	Removal & Installation
<p>CG104</p> 		<p><b>Removal:</b> Remove by bending up with flat-bladed screwdrivers.</p>  <p>Radiator grille Body panel</p>
<p>CE114</p> 		
<p>CF118</p> 	 <p>Clip A Clip B (Grommet)</p>	<p><b>Removal:</b> Flat-bladed screwdrivers Finisher</p>  <p>Body panel Clip A Clip B (Grommet)</p>

ALJIA0564GB



# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### CLIMATE CONTROLLED SEAT SYSTEM

#### CLIMATE CONTROLLED SEAT SYSTEM : Component Parts Location

INFOID:000000012372709



- A. Front of center console
- B. Instrument panel LH (view with instrument panel removed)
- C. Driver seat bottom (view with seat removed)
- D. Driver seat back (view with seat and seat back finisher removed)

No.	Component	Function
1.	Climate controlled seat switch (driver seat)	Refer to <a href="#">SE-10, "CLIMATE CONTROLLED SEAT SYSTEM : Climate Controlled Seat Switch"</a> .
2.	Climate controlled seat switch (passenger seat)	Refer to <a href="#">SE-10, "CLIMATE CONTROLLED SEAT SYSTEM : Climate Controlled Seat Switch"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# COMPONENT PARTS


## < SYSTEM DESCRIPTION >

No.	Component	Function
3.	Climate controlled seat relay	Supplies power to the climate controlled seat control unit in accordance with the key switch position that is ON or OFF
4.	Climate controlled seat control unit	Refer to <a href="#">SE-11, "CLIMATE CONTROLLED SEAT SYSTEM : Climate Controlled Seat Control Unit"</a> .
5.	Climate controlled seat blower motor assembly	Refer to <a href="#">SE-10, "CLIMATE CONTROLLED SEAT SYSTEM : Climate controlled seat blower motor assembly"</a> .
6.	Seatback thermal electric device	Refer to <a href="#">SE-10, "CLIMATE CONTROLLED SEAT SYSTEM : Seat Back Thermal Electric Device"</a> .

### CLIMATE CONTROLLED SEAT SYSTEM : Climate Controlled Seat Switch

INFOID:000000012372710

Installed in the center console and transmits signals to climate controlled seat control unit in accordance with the HEAT (heated airflow) or COOL (cooled airflow) switch operation and the temperature switch operation.




ALJIA1586ZZ

### CLIMATE CONTROLLED SEAT SYSTEM : Climate controlled seat blower motor assembly

INFOID:000000012372711

The thermal electric device (1) is installed in the seat cushion and heats or cools the airflow from the climate controlled seat blower motor (2) in accordance with the control from the climate controlled seat control unit.




ALJIA1841ZZ

### CLIMATE CONTROLLED SEAT SYSTEM : Seat Back Thermal Electric Device

INFOID:000000012372712

Installed in the seatback and heats or cools the airflow from the climate controlled seat blower motor in accordance with the control from the climate controlled seat control unit.



ALJIA1813ZZ


# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## CLIMATE CONTROLLED SEAT SYSTEM : Climate Controlled Seat Control Unit

INFOID:0000000012372714


Installed in the seat cushion and controls the climate controlled seat blower motor, seatback thermal electric device, and seat cushion thermal electric device in accordance with the input signal.



## POWER SEAT SYSTEM

### POWER SEAT SYSTEM : Component Parts Location

INFOID:0000000012372715



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >


- A. Passenger seat (view with seat and seat back finisher removed)    B. RH side of passenger seat    C. LH side of driver seat
- D. Driver seat (view with seat and seat back finisher removed)

No.	Component	Function
1.	BCM	Supplies the power received from battery to power seat switch.
2.	Reclining motor (RH)	Refer to <a href="#">SE-13. "POWER SEAT SYSTEM : Reclining Motor"</a> .
3.	Sliding motor (RH)	Refer to <a href="#">SE-12. "POWER SEAT SYSTEM : Sliding Motor"</a> .
4.	Power seat switch (RH)	Refer to <a href="#">SE-12. "POWER SEAT SYSTEM : Power Seat Switch"</a> .
5.	Power seat switch (LH)	Refer to <a href="#">SE-12. "POWER SEAT SYSTEM : Power Seat Switch"</a> .
6.	Reclining motor (LH)	Refer to <a href="#">SE-13. "POWER SEAT SYSTEM : Reclining Motor"</a> .
7.	Sliding motor (LH)	Refer to <a href="#">SE-12. "POWER SEAT SYSTEM : Sliding Motor"</a> .
8.	Lifting motor (rear) (LH)	Refer to <a href="#">SE-13. "POWER SEAT SYSTEM : Lifting Motor"</a> .
9.	Lifting motor (front) (LH)	Refer to <a href="#">SE-13. "POWER SEAT SYSTEM : Lifting Motor"</a> .

### POWER SEAT SYSTEM : Power Seat Switch

INFOID:000000012372716


- Built-in reclining switch, sliding switch and lifting switch, controls the power supplied to each motor.
- Installed on seat cushion outer finisher.



### POWER SEAT SYSTEM : Sliding Motor

INFOID:000000012372717

- Sliding motor is installed to the seat frame assembly.
- Slides the seat forward/backward by changing the rotation direction of sliding motor.




# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

### POWER SEAT SYSTEM : Lifting Motor

INFOID:000000012372718

- Lifting motor is installed to seat frame assembly.
- Lifting motor is moved upward/downward by changing the rotation direction of lifting motor (front).




ALJIA1605ZZ

### POWER SEAT SYSTEM : Reclining Motor

INFOID:000000012372719

- Reclining motor is installed to seat frame assembly.
- Seatback is reclined forward/backward by changing the rotation direction of reclining motor.




ALJIA1606ZZ

## LUMBAR SUPPORT SYSTEM

### LUMBAR SUPPORT SYSTEM : Component Parts Location

INFOID:000000012372720



ALJIA1810ZZ

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

A. LH side of driver seat


B. Back side of driver seat (view with seat and seat back finisher removed)

No.	Component	Function
1.	BCM	Supplies power from battery to lumbar support switch.
2.	Lumbar support switch	Refer to <a href="#">SE-14, "LUMBAR SUPPORT SYSTEM : Lumbar Support Switch"</a> .
3.	Lumbar support motor	Refer to <a href="#">SE-14, "LUMBAR SUPPORT SYSTEM : Lumbar Support Motor"</a> .

## LUMBAR SUPPORT SYSTEM : Lumbar Support Switch

INFOID:000000012372721


- Controls the power supplied to lumbar support motor.
- Installed on seat cushion outer finisher (driver side).



## LUMBAR SUPPORT SYSTEM : Lumbar Support Motor

INFOID:000000012372722

With power supplied to lumbar support switch, the lumbar support motor operates the forward and backward movement of seatback support.




## HEATED SEAT SYSTEM

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## HEATED SEAT SYSTEM : Component Parts Location

INFOID:000000012372723



A. Front of center console

B. Front seat (view with seat trim and cushion removed)

No.	Component	Function
1.	Front heated seat switch LH	Refer to <a href="#">SE-16, "HEATED SEAT SYSTEM : Front Heated Seat Switch"</a> .
2.	Front heated seat switch RH	
3.	Seat heater (back)	Refer to <a href="#">SE-16, "HEATED SEAT SYSTEM : Front Seat Heater"</a> .
4.	Seat heater (cushion)	


## COMPONENT PARTS

< SYSTEM DESCRIPTION >

### HEATED SEAT SYSTEM : Front Heated Seat Switch

INFOID:00000001237274


Front heated seat switch changes ON/OFF operation and HIGH/LOW operation, and supplies power source to front heated seats.



### HEATED SEAT SYSTEM : Front Seat Heater

INFOID:00000001237276

Front seat heater is located inside front heated seat cushion and seat back, and operates with power source provided via front heated seat switch.





# SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM

### CLIMATE CONTROLLED SEAT SYSTEM

#### CLIMATE CONTROLLED SEAT SYSTEM : System Description

INFOID:0000000012372834

#### SYSTEM DIAGRAM



#### DESCRIPTION

- The climate controlled seat system is controlled by the climate controlled seat control unit.
- Operation of the climate controlled seat switch sends heated or cooled airflow and adjusts the seat temperature.

#### SEAT CUSHION AND SEATBACK TEMPERATURE ADJUSTMENT FUNCTION

- A thermal electric device (TED) is installed in the seat cushion and seatback. The device heats or cools, sends airflow to the seat surface, and adjusts the seat temperature.
- The thermal electric device (TED) is a heat exchanger that has a function to heat or cool the airflow from the climate controlled seat blower motor. By changing the direction of the current from the power supply, the device takes or gives heat, and adjusts the heat exchange process depending on voltage.

#### NOTE:

The climate controlled seat blower motor maintains low speed for approximately 60 seconds after turning the climate controlled seat switch off.

#### CAUTION:

- **The thermal electric device has a dual-climate function that allows one side to operate at a high temperature and the other to operate at a low temperature simultaneously.**
- **Before starting work, always turn OFF the switch and check that the thermal electric device is cold.**

#### FAIL-SAFE

The fail-safe function is adopted for the climate controlled seat control unit. Refer to [SE-20. "Fail-safe"](#).

#### POWER SEAT SYSTEM

# SYSTEM

## < SYSTEM DESCRIPTION >

---

### POWER SEAT SYSTEM : System Description

INFOID:000000012372835

#### DESCRIPTION

Power seat can be operated regardless of the ignition switch position, because power supply is always supplied to power seat switch.

#### Sliding Operation

While operating the sliding switch located in power seat switch, sliding motor operates and makes possible the seat front and back position adjustment.

#### Reclining Operation

While operating the reclining switch located in power seat switch, reclining motor operates and makes possible the seat back forward and backward position adjustment.

#### Lifting Operation

While operating the lifting switch located in power seat switch, lifting motor operates and makes possible the seat cushion up and down position adjustment.

### LUMBAR SUPPORT SYSTEM

### LUMBAR SUPPORT SYSTEM : System Description

INFOID:000000012372836

#### DESCRIPTION

- Lumbar support can operate regardless of the ignition switch position, because power supply is always supplied to lumbar support switch.
- While operating the lumbar support switch, lumbar support motor operates which allows forward and backward operation of seatback support.

### HEATED SEAT SYSTEM

### HEATED SEAT SYSTEM : System Description

INFOID:000000012372837

#### DESCRIPTION

- Heated seat system is activated by heated seat switch while ignition switch is ON, and has the function to warm seat cushion and seatback.

# CLIMATE CONTROLLED SEAT CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


## ECU DIAGNOSIS INFORMATION

### CLIMATE CONTROLLED SEAT CONTROL UNIT

Reference Value

INFOID:0000000012372844

#### TERMINAL LAYOUT



#### PHYSICAL VALUES

Terminal (Wire color)	Item	Signal Input/ Output	Condition			Voltage (Approx.)
2 (G/R)	Seat cushion thermal electric device sensor ground	—	Ignition switch ON			0 V
3 (G)	Seatback thermal electric device sensor signal	Input	Blower motor operated			0.5V – 4.0V
			Ignition switch OFF			0 V
4 (Y)	Blower motor speed control signal	Input	Ignition switch ON or START	Climate controlled seat switch selected	HEAT or COOL	4.5V – 8.0V
					OFF	0 V
6 (V)	HEAT switch signal	Input	Ignition switch ON or START	Climate controlled seat switch selected	HI HEAT	2.6V – 3.5V
					MED HEAT	1.6V – 2.5V
					LO HEAT	0.5V – 1.5V
					OFF	0 V
7 (BR)	COOL switch signal	Input	Ignition switch ON or START	Climate controlled seat switch selected	HI COOL	2.6V – 3.5V
					MED COOL	1.6V – 2.5V
					LO COOL	0.5V – 1.5V
					OFF	0 V
8 (GR)	Climate controlled seat switch power supply	Input	Ignition switch ON			Battery voltage
9 (O)	COOL switch indicator signal	Input	Ignition switch ON or START	Climate controlled seat switch selected	COOL	Battery voltage
					OFF	0 V
10 (L)	HEAT switch indicator signal	Input	Ignition switch ON or START	Climate controlled seat switch selected	HEAT	Battery voltage
					OFF	0 V
12 (P)	Blower motor power supply	Input	Ignition switch ON or START			Battery voltage
17 (G/B)	Seat cushion thermal electric device sensor signal	Input	Blower motor operated			0.5V – 4.0V
			Ignition switch OFF			0 V
18 (G/Y)	Seatback thermal electric device sensor ground	—	Ignition switch ON			0 V
20 (G)	Blower motor ground	—	—			0 V

# CLIMATE CONTROLLED SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal (Wire color)	Item	Signal Input/ Output	Condition			Voltage (Approx.)
25 (Y/B)	Seat cushion thermal electric device power supply (HEAT)	Output	Ignition switch ON or START	Climate controlled seat switch selected	HEAT	Battery voltage
					COOL	0 V
					OFF	0 V
26 (R)	Seatback thermal electric device power supply (HEAT)	Output	Ignition switch ON or START	Climate controlled seat switch selected	HEAT	Battery voltage
					COOL	0 V
					OFF	0 V
27 (Y)	Ground	—	—			0 V
28 (B)	Seatback thermal electric device power supply (COOL)	Output	Ignition switch ON or START	Climate controlled seat switch selected	COOL	Battery voltage
					HEAT	0 V
					OFF	0 V
29 (L)	Battery power supply	Input	Ignition switch ON			Battery voltage
30 (L/O)	Seat cushion thermal electric device power supply (COOL)	Output	Ignition switch ON or START	Climate controlled seat switch selected	COOL	Battery voltage
					HEAT	0 V
					OFF	0 V

### Fail-safe

INFOID:0000000011932914

- Climate controlled seat control unit is equipped with a fail-safe function.
- When a malfunction occurs in the systems shown as per the following, climate controlled seat control unit stops output.

Malfunction	Malfunctioning condition
The temperature difference between the seatback thermal electric device and seat cushion thermal electric device is 30°C (86°F) or more	<ul style="list-style-type: none"> <li>• When it detects for 4 seconds that the temperature difference between the seatback thermal electric device and seat cushion thermal electric device is 30°C (86°F) or more, stops the output to the thermal electric device, activates the climate controlled seat blower motor in the maximum position, and sends the external airflow for 30 seconds</li> <li>• If the temperature difference is still 30°C (86°F) or more after 30 seconds pass, it stops all output and enters the system OFF condition</li> <li>• When the temperature difference between seatback thermal electric device and seat cushion thermal electric device becomes 20°C (68°F) or less, the system recovers automatically</li> <li>• If it detects that the temperature difference is 30°C (86°F) or more after the automatic system recovery, it immediately stops all output and enters the system OFF condition</li> </ul> <p><b>NOTE:</b> When the switch operation is performed before entering the system OFF condition, the fail-safe mode is reset.</p>
The temperature of thermal electric device is 110°C (230°F) or more in the HEAT mode (any thermal electric device in the seatback or seat cushion)	<ul style="list-style-type: none"> <li>• When it detects for 4 seconds that the temperature of the thermal electric device is 110°C (230°F) or more, stops the output to the thermal electric device, activates the climate controlled seat blower motor in the maximum position, and sends the external airflow for 30 seconds</li> <li>• If the temperature does not become 105°C (221°F) or less after 30 seconds pass, it stops all output and enters the system OFF condition</li> <li>• When the temperature of the thermal electric device becomes 105°C (221°F) or less, the system recovers automatically</li> <li>• If it detects that the temperature of the thermal electric device is 110°C (230°F) or more after the automatic system recovery, it immediately stops all output and enters the system OFF condition</li> </ul>

# CLIMATE CONTROLLED SEAT CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Malfunction	Malfunctioning condition	
The temperature of the thermal electric device is 45°C (113°F) or more in the COOL mode (any thermal electric device in the seatback or seat cushion)	<ul style="list-style-type: none"> <li>When it detects for 4 seconds that the temperature of the thermal electric device is between 45°C (113°F) and 70°C (158°F), it starts the temperature monitoring of the thermal electric device at 3 second intervals</li> <li>While monitoring, if it detects that the temperature raises 2°C (36°F) or more 4 times continuously or reaches 70°C (158°F) or more, it stops all output and enters the system OFF condition</li> <li>If it detects other results of monitoring, it continues activating in the COOL mode</li> </ul>	A B C
Thermal electric device sensor system open circuit	<ul style="list-style-type: none"> <li>When it detects for 4 seconds that the thermal electric device sensor system is an open circuit</li> </ul>	D
Climate controlled seat blower motor system open circuit	<ul style="list-style-type: none"> <li>When it detects for 2 seconds that climate controlled seat blower motor system is an open circuit while the climate controlled seat is being activated, it stops output to the thermal electric device</li> <li>When it detects for 10 seconds that the climate controlled seat blower motor system is an open circuit while the climate controlled seat is being activated, it stops all output and enters the system OFF condition</li> </ul> <p><b>NOTE:</b> After detecting the climate seat blower motor system open circuit for 2 seconds, the system recovers automatically if the activation of the climate controlled seat blower motor is detected for 1 second or more.</p>	E F
Switch input out of the specified range	<ul style="list-style-type: none"> <li>When it detects for 4 seconds that the rotary switch input is 30% or less of the vehicle battery voltage, it stops all output and enters the system OFF condition</li> <li>When the switch input returns to a value within the specified range, the system recovers automatically</li> </ul>	G
HEAT or COOL switch input out of the specified range	<ul style="list-style-type: none"> <li>When it detects for 4 seconds that rotary switch input is 6% or less of the vehicle battery voltage, it stops all output and enters the system OFF condition</li> <li>When the switch input returns to a value within the specified range, the system recovers automatically</li> </ul>	H I
System voltage out of range	<ul style="list-style-type: none"> <li>System voltage* of the climate controlled seat control unit is out of the operation range (8.5 V – 16.5 V)</li> </ul>	SE

\*: System voltage is the voltage between climate controlled seat control unit power source and the ground.

**NOTE:**

When the system enters in the fail-safe mode again after performing resetting procedure, perform diagnosis.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P




# POWER SEAT FOR DRIVER SIDE

< WIRING DIAGRAM >


## POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER

Connector No.	M1
Connector Name	WIPE TO WIPE
Connector Type	TH80FW-CS16-TM4
Connector Color	WHITE




Terminal No.	5G	W	Signal Name	-
--------------	----	---	-------------	---

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	CS06FW-M2
Connector Color	WHITE




Terminal No.	6N	LG	Signal Name	-
--------------	----	----	-------------	---

Connector No.	M6
Connector Name	WIPE TO WIPE
Connector Type	TH80FDGY-CS16-TM4
Connector Color	GRAY




Terminal No.	6J	V	Signal Name	- (WITHOUT AUTOMATIC DRIVE POSITIONER)
Terminal No.	6J	L	Signal Name	- (WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-SA
Connector Color	WHITE



Terminal No.	132	B	Signal Name	GND2
Terminal No.	135	LG	Signal Name	BAT BCM FUSE
Terminal No.	138	B	Signal Name	GND1
Terminal No.	140	V	Signal Name	P/W POWER SUPPLY BAT
Terminal No.	142	W	Signal Name	BAT-POWER F/L

Connector No.	E30
Connector Name	WIPE TO WIPE
Connector Type	TH80MM-CS16-TM4
Connector Color	WHITE



Terminal No.	5G	P	Signal Name	-
--------------	----	---	-------------	---


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT FOR DRIVER SIDE

< WIRING DIAGRAM >

3	B	-
4	R	-
5	W	-
6	V	-
7	L	-
8	G	-
9	O	-
10	W	-

Connector No.	B221
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	R	-
11	B	-

Connector No.	B225
Connector Name	RECLINING MOTOR LH
Connector Type	7123-1460-30
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
4	Y	-
6	W	-

Connector No.	B90
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	V	-WITHOUT AUTOMATIC DRIVE POSITIONER)
4	L	-(WITH AUTOMATIC DRIVE POSITIONER)
11	B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	R	-
11	B	-

Connector No.	B213
Connector Name	POWER SEAT SWITCH LH
Connector Type	NS10FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	O	-
2	G	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MDGY-CS16-TM4
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
6J	V	-WITHOUT AUTOMATIC DRIVE POSITIONER)
6J	L	-(WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	V	-WITHOUT AUTOMATIC DRIVE POSITIONER)
4	L	-(WITH AUTOMATIC DRIVE POSITIONER)
11	B	-



# POWER SEAT FOR DRIVER SIDE

< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

Connector No.	B226
Connector Name	SLIDING MOTOR LH
Connector Type	7123-1460-30
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	V	-
6	P	-

Connector No.	B227
Connector Name	LIFTING MOTOR LH (FRONT)
Connector Type	7123-1460-30
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	O	-
6	GR	-

Connector No.	B228
Connector Name	LIFTING MOTOR LH (REAR)
Connector Type	7123-1460-30
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	G	-
6	L	-

AAJIA0902GB


# POWER SEAT FOR PASSENGER SIDE

< WIRING DIAGRAM >

## POWER SEAT FOR PASSENGER SIDE

Wiring Diagram

INFOID:000000011932916




AAJWA0357GB

# POWER SEAT FOR PASSENGER SIDE

< WIRING DIAGRAM >


## POWER SEAT FOR PASSENGER SIDE CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CST16-TM4
Connector Color	WHITE




Terminal No.	5G	W	Signal Name	-
--------------	----	---	-------------	---

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	CS06FW-M2
Connector Color	WHITE




Terminal No.	6N	LG	Signal Name	-
--------------	----	----	-------------	---

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS
Connector Color	WHITE




Terminal No.	4	V	Signal Name	-
--------------	---	---	-------------	---

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-SA
Connector Color	WHITE




Terminal No.	132	B	Signal Name	GND2
135	LG	BAT BCM FUSE		
138	B	GND1		
140	V	PWM POWER SUPPLY BAT		
142	W	BAT-POWER F/L		

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CST16-TM4
Connector Color	WHITE



Terminal No.	5G	P	Signal Name	-
--------------	----	---	-------------	---

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE



Terminal No.	4	V	Signal Name	-
--------------	---	---	-------------	---

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

AAJIA0905GB


# POWER SEAT FOR PASSENGER SIDE

< WIRING DIAGRAM >

6	V	-
7	L	-
10	Y	-


  

Connector No.	B319
Connector Name	RECLINING MOTOR RH
Connector Type	7123-1460-30
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
4	Y	-
6	W	-

Connector No.	B306
Connector Name	SLIDING MOTOR RH
Connector Type	7123-1460-30
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	L	-
6	V	-

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	R	-
13	B	-

Connector No.	B309
Connector Name	POWER SEAT SWITCH RH
Connector Type	NS10FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-
5	W	-

Connector No.	B123
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	-	-
13	B	-

Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	V	-
13	B	-

Connector No.	B300
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
13	B	-

AAJIA0906GB


# HEATED SEAT

< WIRING DIAGRAM >

## HEATED SEAT

### Wiring Diagram

INFOID:000000011932917



\* THIS CONNECTOR IS NOT SHOWN IN "HARNISS LAYOUT" OF PG SECTION.

AAJWA0353GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# HEATED SEAT

< WIRING DIAGRAM >

## HEATED SEAT CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CST16-TM4
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1G	R	-
3G	P	-

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7P	BG	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80FY-CST16-TM4
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
7J	SB	-
8J	Y	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	V	-

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
5	GR	-
7	W	-
8	V	-
9	BR	-
10	SB	-
11	Y	-
12	G	-

Connector No.	M180
Connector Name	HEATED SEAT RELAY
Connector Type	M06FBR-R-LC
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	BG	-
3	G	-
5	R	-
6	W	-
7	P	-

# HEATED SEAT


< WIRING DIAGRAM >

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MDGY-CS16-TM4
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
7J	L	-
8J	SB	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	L	-
3	SB	-
11	B	-

Connector No.	M261
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Type	NS06FBR-CS
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	W	-
2	V	-
3	L	-
4	B	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1G	LG	-
3G	G	-

Connector No.	M251
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
5	B	-
7	W	-
8	V	-
9	L	-
10	L	-
11	V	-
12	W	-

Connector No.	M260
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Type	NS06FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	V	-
3	L	-
4	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# HEATED SEAT

< WIRING DIAGRAM >


1	L	-
2	B	-
3	R	-

Connector No.	B308
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

Terminal No.	Color of Wire	Signal Name
2	R	-
3	L	-
13	B	-



Connector No.	B318
Connector Name	FRONT SEAT HEATER (CUSHION) RH
Connector Type	-
Connector Color	BLACK

3	R	-
---	---	---



Connector No.	B211
Connector Name	FRONT SEAT HEATER (CUSHION) LH
Connector Type	-
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-


Connector No.	B221
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	R	-
3	L	-
11	B	-

Connector No.	B302
Connector Name	FRONT SEAT HEATER RH
Connector Type	M03MW-LC
Connector Color	WHITE




Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	V	-
2	Y	-


Connector No.	B148
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
2	V	-
3	Y	-
13	B	-

Connector No.	B210
Connector Name	FRONT SEAT HEATER LH
Connector Type	M03MW-LC
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

AAJIA0898GB



# LUMBAR SUPPORT SYSTEM

< WIRING DIAGRAM >


## LUMBAR SUPPORT SYSTEM

### Wiring Diagram

INFOID:000000011932918

- ◇AD : WITH AUTOMATIC DRIVE POSITIONER
- ◇CU : WITH CLIMATE CONTROLLED SEATS
- ◇CT : WITHOUT CLIMATE CONTROLLED SEATS
- ◇XA : WITHOUT AUTOMATIC DRIVE POSITIONER

### LUMBAR SUPPORT SYSTEM



AAJWA0356GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# LUMBAR SUPPORT SYSTEM

< WIRING DIAGRAM >


## LUMBAR SUPPORT SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4
Connector Color	WHITE




Terminal No.	5G	Color of Wire	W	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	CS06FW-M2
Connector Color	WHITE




Terminal No.	6N	Color of Wire	LG	Signal Name	-
--------------	----	---------------	----	-------------	---

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80FDGY-CS16-TM4
Connector Color	GRAY




Terminal No.	6J	Color of Wire	V	Signal Name	-
Terminal No.	6J	Color of Wire	L	Signal Name	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-SA
Connector Color	WHITE




Terminal No.	132	Color of Wire	B	Signal Name	GND2
Terminal No.	135	Color of Wire	LG	Signal Name	BAT BCM FUSE
Terminal No.	138	Color of Wire	B	Signal Name	GND1
Terminal No.	140	Color of Wire	V	Signal Name	P/W POWER SUPPLY /BAT
Terminal No.	142	Color of Wire	W	Signal Name	BAT-POWER /FL

Connector No.	M84
Connector Name	CIRCUIT BREAKER
Connector Type	M02FW-P-LC
Connector Color	WHITE



Terminal No.	1	Color of Wire	W	Signal Name	-
Terminal No.	2	Color of Wire	L	Signal Name	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4
Connector Color	WHITE



Terminal No.	5G	Color of Wire	P	Signal Name	-
--------------	----	---------------	---	-------------	---


# LUMBAR SUPPORT SYSTEM

< WIRING DIAGRAM >

3	Y	-
4	G	-

Connector No.	B221
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE



  

  

1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
4	R	-
11	B	-


  

Connector No.	B230
Connector Name	LUMBAR SUPPORT MOTOR
Connector Type	7119-1564-30
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	G	-

Connector No.	B90
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE


  

  

5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
4	V	-WITHOUT AUTOMATIC DRIVE POSITIONER)
11	B	-(WITH AUTOMATIC DRIVE POSITIONER)


Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE

1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
4	R	-
11	B	-



Connector No.	B214
Connector Name	LUMBAR SUPPORT SWITCH
Connector Type	NS04FW-CS
Connector Color	WHITE

1	2	3	4
---	---	---	---


Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MDGY-CS16-TM4
Connector Color	GRAY

Terminal No.	Color of Wire	Signal Name
6J	V	-WITHOUT AUTOMATIC DRIVE POSITIONER)
6J	L	-(WITH AUTOMATIC DRIVE POSITIONER)

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE

5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
4	V	-WITHOUT AUTOMATIC DRIVE POSITIONER)
4	L	-(WITH AUTOMATIC DRIVE POSITIONER)
11	B	-

AAJIA0904GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# CLIMATE CONTROLLED SEAT

< WIRING DIAGRAM >

## CLIMATE CONTROLLED SEAT

### Wiring Diagram

INFOID:000000011932919



AAJWA0351GB




# CLIMATE CONTROLLED SEAT

< WIRING DIAGRAM >


## CLIMATE CONTROLLED SEAT CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1G	R	-
3G	P	-

Connector No.	M5
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7P	BG	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80FDGY-CS16-TM4
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
7J	SB	-
8J	Y	-
9J	R	-
48J	BR	-
49J	V	-
50J	SB	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-NH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	L	-
13	Y	-
14	LG	-

Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	V	-
3	W	-

Connector No.	M5B
Connector Name	CLIMATE CONTROLLED SEAT RELAY
Connector Type	M06FBR-R-LC
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	BG	-
3	G	-
5	R	-
6	W	-
7	P	-

# CLIMATE CONTROLLED SEAT


< WIRING DIAGRAM >

Connector No.	M262
Connector Name	CLIMATE CONTROLLED SEAT SWITCH LH
Connector Type	TK10FW
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	V	-
3	L	-
7	B	-
8	Y	-
9	BR	-

Connector No.	M263
Connector Name	CLIMATE CONTROLLED SEAT SWITCH RH
Connector Type	TK08FBR
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	L	-
2	V	-
3	L	-
4	BR	-
5	Y	-
6	B	-

Connector No.	M250
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	Y	-
3	BR	-
4	L	-
14	Y	-
15	BR	-
16	L	-

Connector No.	M251
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	B	-
3	W	-
4	W	-
5	B	-
7	W	-
8	V	-
9	L	-
10	L	-
11	V	-
12	W	-

Connector No.	M95
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BR	-
3	V	-
4	SB	-
14	L	-
15	Y	-
16	LG	-

Connector No.	M112
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
3	W	-
4	R	-
5	GR	-
7	W	-
8	V	-
9	BR	-
10	SB	-
11	Y	-
12	G	-


AAJIA0891GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# CLIMATE CONTROLLED SEAT


< WIRING DIAGRAM >

Connector No.	B
Connector Name	B102
Connector Type	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	R	-
13	LG	-
14	SB	-

Connector No.	B104
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	-
2	Y	-
3	W	-

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MDGY-CS16-TM4
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
7J	L	-
8J	SB	-
9J	R	-
48J	Y	-
48J	V	-
50J	BR	-

Connector No.	B90
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	L	-
3	SB	-
6	BR	-
7	V	-
8	Y	-

Connector No.	E30
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1G	LG	-
3G	G	-

AAJIA0892GB



# CLIMATE CONTROLLED SEAT

< WIRING DIAGRAM >


15	-	-
16	-	-
17	G/B	RET CUSH SEN
18	G/Y	RET BACK SEN
19	-	-
20	G	GND BLOWER
21	-	-
22	-	-
23	-	-
24	-	-

Connector No.	B217
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT LH
Connector Type	7123-8766-30
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
25	Y/B	CUSH TED +HEAT
26	R	BACK TED +HEAT
27	Y	A/C CTRL GND
28	B	BACK TED -HEAT
29	L	A/C IGN
30	L/O	CUSH TED -HEAT

Connector No.	B206
Connector Name	CLIMATE CONTROLLED SEAT BLOWER ASSEMBLY LH
Connector Type	TK08F09
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	G/B	-
3	G/R	-
4	Y/B	-
5	L/O	-
6	G	-
7	Y	-
8	P	-

Connector No.	B216
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT LH
Connector Type	TH24FW-NH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	G/R	SENS CUSH
3	G	SENS BACK
4	Y	VSPI BLOW
5	-	-
6	V	A/C HEAT SW
7	BR	A/C COOL SW
8	GR	A/C SW UNIT
9	O	A/C COOL IND
10	L	A/C HEAT IND
11	-	-
12	P	VM1 BLOW
13	-	-
14	-	-

Connector No.	B123
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	V	-
3	Y	-
8	SB	-
9	LG	-
10	R	-
13	B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	V	-
3	BR	-
6	GR	-
7	L	-
8	O	-
11	B	-

AAJIA0893GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# CLIMATE CONTROLLED SEAT


< WIRING DIAGRAM >

Connector No.	B313
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT RH
Connector Type	7123-8766-30
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
25	Y/B	CUSH TED +HEAT
26	R	BACK TED +HEAT
27	Y	A/C CTRL GND
28	B	BACK TED -HEAT
29	L	A/C IGN
30	L/O	CUSH TED -HEAT

Connector No.	B316
Connector Name	SEAT BACK THERMAL ELECTRIC DEVICE RH
Connector Type	7283-8340
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	Y	-
3	G	-
4	G/Y	-

Connector No.	B312
Connector Name	CLIMATE CONTROLLED SEAT CONTROL UNIT RH
Connector Type	TH24FW-NH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	-	-
2	G/R	SENS CUSH
3	G	SENS BACK
4	Y	VSPT BLOW
5	-	-
6	V	A/C HEAT SW
7	BR	A/C COOL SW
8	GR	A/C SW UNIT
9	O	A/C COOL IND
10	L	A/C HEAT IND
11	-	-
12	P	VM1 BLOW
13	-	-
14	-	-
15	-	-
16	-	-
17	G/B	RET CUSH SEN
18	G/Y	RET BACK SEN
19	-	-
20	G	GND BLOWER
21	-	-
22	-	-
23	-	-
24	-	-

Connector No.	B218
Connector Name	SEAT BACK THERMAL ELECTRIC DEVICE LH
Connector Type	7283-8340
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	Y	-
3	G	-
4	G/Y	-

Connector No.	B300
Connector Name	WIRE TO WIRE
Connector Type	NST6MW-CS
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	V	-
3	BR	-
8	GR	-
9	L	-
10	O	-
13	B	-


AAJIA0894GB

# CLIMATE CONTROLLED SEAT

< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

Connector No.	B317
Connector Name	CLIMATE CONTROLLED SEAT BLOWER ASSEMBLY RH
Connector Type	TK08FGY
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	G/B	-
3	G/R	-
4	Y/B	-
5	L/O	-
6	G	-
7	Y	-
8	P	-

AAJIA0983GB

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000011932886

#### OVERALL SEQUENCE



#### DETAILED FLOW

##### 1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

##### 2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected. Refer to [SE-64, "Symptom Table"](#).

>> GO TO 3.

##### 3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

---

Is malfunctioning part detected?

YES >> GO TO 4.

NO >> GO TO 2.

## 4.REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5.

## 5.FINAL CHECK

---

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT CLIMATE CONTROLLED SEAT CONTROL UNIT

CLIMATE CONTROLLED SEAT CONTROL UNIT : Diagnosis Procedure INFOID:0000000012372845

Regarding Wiring Diagram information, refer to [SE-36, "Wiring Diagram"](#).

LH

#### 1. CHECK FUSE

Check if any of the following fuses are blown.

Signal name	Fuse No.
Battery power supply	61 (15A)
IGN power supply	30 (10A)

#### Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

#### 2. CHECK CLIMATE CONTROLLED SEAT CONTROL UNIT LH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit LH connector.
3. Turn ignition switch ON.
4. Check voltage between climate controlled seat control unit LH harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
B217	29	Ground	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 7.  
NO >> GO TO 3.

#### 3. CHECK CLIMATE CONTROLLED SEAT CONTROL UNIT LH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat relay.
3. Check continuity between climate controlled seat control unit LH harness connector and climate controlled seat relay harness connector.

Climate controlled seat control unit LH		Climate controlled seat relay		Continuity
Connector	Terminal	Connector	Terminal	
B217	29	M58	3	Yes

4. Check continuity between climate controlled seat control unit LH harness connector and ground.

Climate controlled seat control unit LH		Ground	Continuity
Connector	Terminal		
B217	29		No

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness or connector.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 4. CHECK CLIMATE CONTROLLED SEAT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between climate controlled seat relay harness connector and ground.

Climate controlled seat relay		(-)	Voltage (Approx.)
Connector	Terminal		
M58	2	Ground	Battery voltage
	5		

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace harness or connector.

## 5. CHECK CLIMATE CONTROLLED SEAT RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between climate controlled seat relay harness connector and ground.

Climate controlled seat relay		Ground	Continuity
Connector	Terminal		
M58	1		Yes

Is the inspection result normal?

- YES >> GO TO 6.  
 NO >> Repair or replace harness.

## 6. CHECK CLIMATE CONTROLLED SEAT RELAY

Check climate controlled seat relay.

Refer to [SE-49. "CLIMATE CONTROLLED SEAT CONTROL UNIT : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 7.  
 NO >> Replace climate controlled seat relay.

## 7. CHECK CLIMATE CONTROLLED SEAT CONTROL UNIT LH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between climate controlled seat control unit LH harness connector and ground.

Climate controlled seat control unit LH		Ground	Continuity
Connector	Terminal		
B217	27		Yes

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).  
 NO >> Repair or replace harness or connector.

RH

## 1. CHECK FUSE

Check if any of the following fuses are blown.

Signal name	Fuse No.
Battery power supply	57 (15A)
IGN power supply	30 (10A)

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
 NO >> GO TO 2.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 2. CHECK CLIMATE CONTROLLED SEAT CONTROL UNIT RH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit RH connector.
3. Turn ignition switch ON.
4. Check voltage between climate controlled seat control unit RH harness connector and ground.

(+)		(-)	Voltage (Approx.)
Climate controlled seat control unit RH			
Connector	Terminal		
B313	29	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 3.

## 3. CHECK CLIMATE CONTROLLED SEAT CONTROL UNIT RH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat relay.
3. Check continuity between climate controlled seat control unit RH harness connector and climate controlled seat relay harness connector.

Climate controlled seat control unit RH		Climate controlled seat relay		Continuity
Connector	Terminal	Connector	Terminal	
B313	29	M58	6	Yes

4. Check continuity between climate controlled seat control unit RH harness connector and ground.

Climate controlled seat control unit RH		Ground	Continuity
Connector	Terminal		
B313	29		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connector.

## 4. CHECK CLIMATE CONTROLLED SEAT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between climate controlled seat relay harness connector and ground.

(+)		(-)	Voltage (Approx.)
Climate controlled seat relay			
Connector	Terminal		
M58	2	Ground	Battery voltage
	7		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connector.

## 5. CHECK CLIMATE CONTROLLED SEAT RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between climate controlled seat relay harness connector and ground.

Climate controlled seat relay		Ground	Continuity
Connector	Terminal		
M58	1		Yes



# POWER SUPPLY AND GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace harness.

## 6.CHECK CLIMATE CONTROLLED SEAT RELAY

Check climate controlled seat relay.

Refer to [SE-49, "CLIMATE CONTROLLED SEAT CONTROL UNIT : Component Inspection"](#).

### Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Replace climate controlled seat relay.

## 7.CHECK CLIMATE CONTROLLED SEAT CONTROL UNIT RH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between harness connector and ground.

Climate controlled seat control unit RH		Ground	Continuity
Connector	Terminal		
B313	27		Yes

### Is the inspection result normal?


- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).
- NO >> Repair harness or connector.

## CLIMATE CONTROLLED SEAT CONTROL UNIT : Component Inspection INFOID:000000012385864

### 1.CHECK CLIMATE CONTROLLED SEAT RELAY

1. Turn ignition switch OFF.
2. Remove climate controlled seat relay.
3. Check the continuity between climate controlled seat relay terminals under the following conditions.

Terminals		Condition	Continuity
3	5	12 V direct current supply between terminals 1 and 2	Yes
		No current supply	No
6	7	12 V direct current supply between terminals 1 and 2	Yes
		No current supply	No



### Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace climate controlled seat relay.

# SEATBACK THERMAL ELECTRIC DEVICE

< DTC/CIRCUIT DIAGNOSIS >

## SEATBACK THERMAL ELECTRIC DEVICE

### Component Function Check

INFOID:000000012372846

#### 1. CHECK SEATBACK THERMAL ELECTRIC DEVICE FUNCTION

Check whether or not the temperature of the seatback thermal electric device changes in accordance with the HEAT or COOL switch operation of the climate controlled seat control switch.

Is the inspection result normal?

- YES >> Inspection End.  
 NO >> Refer to [SE-50, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000012372847

Regarding Wiring Diagram information, refer to [SE-36, "Wiring Diagram"](#).

#### 1. CHECK SEATBACK THERMAL ELECTRIC DEVICE INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between seatback thermal electric device harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
Seatback thermal electric device					
Connector	Terminal				
LH	B218	Ground	Climate controlled seat switch	HEAT or COOL	0 - 12*
				Other than above	0
	2		HEAT or COOL	0 - 12*	
			Other than above	0	
RH	B316	Ground	Climate controlled seat switch	HEAT or COOL	0 - 12*
				Other than above	0
	2		HEAT or COOL	0 - 12*	
			Other than above	0	

\*:It changes between 12 and 0 V.

**NOTE:**

Wait 1 minute or more after the activation start, and then start the measurement.

Is the inspection result normal?

- YES >> Replace seatback thermal electric device. Refer to [SE-80, "Seatback Thermal Electric Device"](#).  
 NO >> GO TO 2.

#### 2. CHECK SEATBACK THERMAL ELECTRIC DEVICE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit connector and seatback thermal electric device connector.
3. Check continuity between climate controlled seat control unit harness connector and seatback thermal electric device harness connector.

Climate controlled seat control unit		Seatback thermal electric device		Continuity
Connector	Terminal	Connector	Terminal	
LH	B217	B218	26	1
			28	2
RH	B313	B316	26	1
			28	2

4. Check continuity between climate controlled seat control unit harness connector and ground.

# SEATBACK THERMAL ELECTRIC DEVICE

## < DTC/CIRCUIT DIAGNOSIS >

Climate controlled seat control unit				Continuity
Connector	Terminal	Ground		
LH	B217		26	No
			28	
RH	B313		26	
		28		

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-83, "Climate Controlled Seat Control Unit"](#).
- NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# SEATBACK THERMAL ELECTRIC DEVICE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## SEATBACK THERMAL ELECTRIC DEVICE SENSOR

### Component Function Check

INFOID:000000012372848

#### 1. CHECK SEATBACK THERMAL ELECTRIC DEVICE SENSOR FUNCTION

Check whether or not the temperature of the seatback thermal electric device changes in accordance with the HEAT or COOL switch operation of the climate controlled seat control switch.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [SE-52, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012372849

Regarding Wiring Diagram information, refer to [SE-36, "Wiring Diagram"](#).

#### 1. CHECK SEATBACK THERMAL ELECTRIC DEVICE SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage between seatback thermal electric device harness connector and ground.

(+)		Terminal	(-)	Condition	Voltage (Approx.)
Seatback thermal electric device					
Connector					
LH	B218	3	Ground	Climate controlled seat operated	1 - 5
RH	B313				

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

#### 2. CHECK SEATBACK THERMAL ELECTRIC DEVICE SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit connector and seatback thermal electric device connector.
3. Check continuity between climate controlled seat control unit harness connector and seatback thermal electric device harness connector.

Climate controlled seat control unit		Terminal	Seatback thermal electric device		Continuity
Connector			Connector		
LH	B216	3	B218	3	Yes
RH	B312		B316		

4. Check continuity between climate controlled seat control unit harness connector and ground.

Climate controlled seat control unit		Terminal	Ground	Continuity
Connector				
LH	B216	3		No
RH	B312			

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-83, "Climate Controlled Seat Control Unit"](#).
- NO >> Repair or replace harness.

#### 3. CHECK SEATBACK THERMAL ELECTRIC DEVICE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.

# SEATBACK THERMAL ELECTRIC DEVICE SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect climate controlled seat control unit connector and seatback thermal electric device connector.
3. Check continuity between climate controlled seat control unit harness connector and seatback thermal electric device harness connector.

Climate controlled seat control unit		Seatback thermal electric device		Continuity
Connector	Terminal	Connector	Terminal	
LH	B216	18	B218	Yes
RH	B312		B316	

4. Check continuity between climate controlled seat control unit harness connector and ground.

Climate controlled seat control unit		Ground	Continuity
Connector	Terminal		
LH	B216	18	No
RH	B312		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

## 4.CHECK SEATBACK THERMAL ELECTRIC DEVICE SENSOR

Check seatback thermal electric device sensor.

Refer to [SE-53, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace seatback thermal electric device. Refer to [SE-80, "Seatback Thermal Electric Device"](#).

## Component Inspection

INFOID:000000012372850

## 1.CHECK SEATBACK THERMAL ELECTRIC DEVICE SENSOR

1. Turn ignition switch OFF.
2. Disconnect seatback thermal electric device connector.
3. Check resistance between seatback thermal electric device terminals.

Seatback thermal electric device		Resistance (Approx.)
Terminals		
3	4	1000Ω*

\* : When sensor temperature is 25°C (77°F)

Is the inspection result normal?

- YES >> Inspection End.  
 NO >> Replace seatback thermal electric device. Refer to [SE-80, "Seatback Thermal Electric Device"](#).

# SEAT CUSHION THERMAL ELECTRIC DEVICE

< DTC/CIRCUIT DIAGNOSIS >

## SEAT CUSHION THERMAL ELECTRIC DEVICE

### Component Function Check

INFOID:000000012372851

#### 1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE FUNCTION

Check whether or not the temperature of the seat cushion thermal electric device changes in accordance with the HEAT or COOL switch operation of the climate controlled seat control switch.

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [SE-54, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012372852

Regarding Wiring Diagram information, refer to [SE-36, "Wiring Diagram"](#).

#### 1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SIGNAL

1. Turn ignition switch ON.
2. Check voltage between climate controlled seat blower motor assembly harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
Climate controlled seat blower motor assembly					
Connector	Terminal				
LH	B206	Ground	Climate controlled seat switch	HEAT or COOL	0 - 12*
				Other than above	0
			Climate controlled seat switch	HEAT or COOL	0 - 12*
				Other than above	0
RH	B317	Ground	Climate controlled seat switch	HEAT or COOL	0 - 12*
				Other than above	0
			Climate controlled seat switch	HEAT or COOL	0 - 12*
				Other than above	0

\*:It changes between 12 and 0 V.

#### NOTE:

Wait 1 minute or more after the activation start, and then start the measurement.

Is the inspection result normal?

- YES >> Replace climate controlled seat blower motor assembly. Refer to [SE-81, "Climate Controlled Seat Blower Assembly"](#).  
NO >> GO TO 2.

#### 2. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit connector and climate controlled seat blower motor assembly connector.
3. Check continuity between climate controlled seat control unit harness connector and climate controlled seat blower motor assembly harness connector.

# SEAT CUSHION THERMAL ELECTRIC DEVICE

## < DTC/CIRCUIT DIAGNOSIS >

Climate controlled seat control unit		Climate controlled seat blower motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
LH	B216	25	B206	Yes
		30		
RH	B313	25	B317	
		30		

4. Check continuity between climate controlled seat control unit harness connector and ground.

Climate controlled seat control unit		Ground	Continuity
Connector	Terminal		
LH	B216	25	No
		30	
RH	B313	25	
		30	

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-83. "Climate Controlled Seat Control Unit"](#).
- NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR

### Component Function Check

INFOID:000000012372853

#### 1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR FUNCTION

Check whether or not the temperature of the seat cushion thermal electric device changes in accordance with the HEAT or COOL switch operation of the climate controlled seat control switch.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [SE-56, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012372854

Regarding Wiring Diagram information, refer to [SE-36, "Wiring Diagram"](#).

#### 1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage between climate controlled seat blower motor assembly harness connector and ground.

(+)		Terminal	(-)	Condition	Voltage (Approx.)
Climate controlled seat blower motor assembly					
Connector					
LH	B206	3	Ground	Climate controlled seat operated	1 - 5
RH	B317				

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

#### 2. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit connector and climate controlled seat blower motor assembly connector.
3. Check continuity between climate controlled seat control unit harness connector and climate controlled seat blower motor assembly harness connector.

Climate controlled seat control unit		Terminal	Climate controlled seat blower motor assembly		Continuity
Connector			Connector	Terminal	
LH	B216	2	B206	3	Yes
RH	B312		B317		

4. Check continuity between climate controlled seat control unit harness connector and ground.

Climate controlled seat control unit		Terminal	Ground	Continuity
Connector				
LH	B216	2		No
RH	B312			

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-83, "Climate Controlled Seat Control Unit"](#).
- NO >> Repair or replace harness.



# SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## 3. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat control unit connector and climate controlled seat blower motor assembly connector.
3. Check continuity between climate controlled seat control unit harness connector and climate controlled seat blower motor assembly harness connector.

Climate controlled seat control unit		Climate controlled seat blower motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
LH	B216	B206	2	Yes
RH	B312	B317		

4. Check continuity between climate controlled seat control unit harness connector and ground.

Climate controlled seat control unit		Ground	Continuity
Connector	Terminal		
LH	B216	17	No
RH	B312		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

## 4. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR

Check seat cushion thermal electric device sensor. Refer to [SE-57, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace climate controlled seat blower motor assembly. Refer to [SE-81, "Climate Controlled Seat Blower Assembly"](#).

## Component Inspection

INFOID:000000012372855

## 1. CHECK SEAT CUSHION THERMAL ELECTRIC DEVICE SENSOR

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat blower motor assembly connector.
3. Check resistance between seat cushion thermal electric device terminals.

Seat cushion thermal electric device		Resistance (Approx.)
Terminals		
2	3	1000Ω*

\* : When sensor temperature is 25°C (77°F).

Is the inspection result normal?

- YES >> Inspection End.  
 NO >> Replace climate controlled seat blower motor assembly. Refer to [SE-81, "Climate Controlled Seat Blower Assembly"](#).

# CLIMATE CONTROLLED SEAT BLOWER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

## CLIMATE CONTROLLED SEAT BLOWER MOTOR

### Component Function Check

INFOID:000000012372856

#### 1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR FUNCTION

When turning the climate controlled seat switch to the HEAT or COOL mode position, check that the climate controlled seat blower motor assembly is operated in each specific mode.

Is the inspection result normal?

- YES >> Inspection End.  
 NO >> Refer to [SE-58, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012372857

Regarding Wiring Diagram information, refer to [SE-36, "Wiring Diagram"](#).

#### 1. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR POWER SUPPLY

- Turn ignition switch ON.
- Check voltage between climate controlled seat blower motor assembly harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)			
Climate controlled seat blower motor assembly							
Connector	Terminal						
LH	B206	8	Ground	Climate controlled seat switch	HEAT mode	Battery voltage	
					COOL mode		
					Other than above		0
RH	B317				Climate controlled seat switch	HEAT mode	Battery voltage
					COOL mode		
					Other than above	0	

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

#### 2. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect climate controlled seat blower motor assembly connector and climate controlled seat control unit connector.
- Check continuity between climate controlled seat blower motor assembly harness connector and climate controlled seat control unit harness connector.

Climate controlled seat blower motor assembly			Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal		
LH	B206	B216	12	Yes	
RH	B317				

- Check continuity between climate controlled seat blower motor assembly harness connector and ground.

climate controlled seat blower motor assembly			Ground	Continuity
Connector	Terminal			
LH	B206	8		No
RH	B317			

Is the inspection result normal?

# CLIMATE CONTROLLED SEAT BLOWER MOTOR

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace climate controlled seat control unit. Refer to [SE-83. "Climate Controlled Seat Control Unit"](#).
- NO >> Repair or replace harness.

### 3. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR SPEED CONTROL SIGNAL

Check voltage between climate controlled seat blower motor assembly harness connector and ground.

(+)		Terminal	(-)	Condition	Voltage (Approx.)		
Climate controlled seat blower motor assembly							
Connector							
LH	B206	7	Ground	HEAT	5.5 - 8		
				Climate controlled seat switch	COOL	HI	11.2
						MID	8
						LO	6.5
Other than above	0						
RH	B317	7	Ground	HEAT	5.5 - 8		
				Climate controlled seat switch	COOL	HI	11.2
						MID	8
						LO	6.5
Other than above	0						

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> GO TO 4.

### 4. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR SPEED CONTROL SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect climate controlled seat blower motor assembly connector and climate controlled seat control unit connector.
- Check continuity between climate controlled seat blower motor assembly harness connector and climate controlled seat control unit harness connector.

Climate controlled seat blower motor assembly		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
LH	B206	B216	4	Yes
RH	B317	B312		

- Check continuity between climate controlled seatback blower motor harness connector and ground.

Climate controlled seat blower motor assembly		Ground	Continuity
Connector	Terminal		
LH	B206	7	No
RH	B317		

Is the inspection result normal?

- YES >> Replace climate controlled seat control unit. Refer to [SE-83. "Climate Controlled Seat Control Unit"](#).
- NO >> Repair or replace harness.

### 5. CHECK CLIMATE CONTROLLED SEAT BLOWER MOTOR GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect climate controlled seat blower motor assembly and climate controlled seat control unit connector.
- Check continuity between climate controlled seat blower motor assembly harness connector and climate controlled seat control unit harness connector.

# CLIMATE CONTROLLED SEAT BLOWER MOTOR

## < DTC/CIRCUIT DIAGNOSIS >

Climate controlled seat blower motor assembly		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
LH	B206	6	B216	Yes
RH	B317		B312	

4. Check continuity between climate controlled seatback blower motor harness connector and ground.

climate controlled seat blower motor assembly		Ground	Continuity
Connector	Terminal		
LH	B206	6	No
RH	B317		

Is the inspection result normal?

- YES >> Replace climate controlled seat blower motor assembly. Refer to [SE-81, "Climate Controlled Seat Blower Assembly"](#).
- NO >> Repair or replace harness.

# CLIMATE CONTROLLED SEAT SWITCH INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

## CLIMATE CONTROLLED SEAT SWITCH INDICATOR

### Component Function Check

INFOID:000000012372859

#### 1. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR FUNCTION

Check that the related indicator lamp illuminates when climate controlled seat switch is set to HEAT or COOL mode.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Refer to [SE-61. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012372859

Regarding Wiring Diagram information, refer to [SE-36. "Wiring Diagram"](#).

#### 1. CHECK CLIMATE CONTROLLED SEAT SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between climate controlled seat switch harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Climate controlled seat switch			Climate controlled seat switch		
Connector	Terminal	Ground			
LH	M262		8	HEAT mode	Battery voltage
				OFF	0
			9	COOL mode	Battery voltage
				OFF	0
RH	M263		5	HEAT mode	Battery voltage
				OFF	0
			4	COOL mode	Battery voltage
		OFF		0	

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

#### 2. CHECK CLIMATE CONTROLLED SEAT SWITCH INDICATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat switch connector and climate controlled seat control unit connector.
3. Check continuity between climate controlled seat switch harness connector and climate controlled seat control unit harness connector.

Climate controlled seat switch		Climate controlled seat control unit		Continuity
Connector	Terminal	Connector	Terminal	
LH	M262	B216	9	Yes
			8	
RH	M263	B312	9	
			5	

4. Check continuity between climate controlled seat switch harness connector and ground.

# CLIMATE CONTROLLED SEAT SWITCH INDICATOR

## < DTC/CIRCUIT DIAGNOSIS >

Climate controlled seat switch			Ground	Continuity
Connector		Terminal		No
LH	M262	9		
RH	M263	5		

Is the inspection result normal?

YES >> Replace climate controlled seat control unit. Refer to [SE-83, "Climate Controlled Seat Control Unit"](#).

NO >> Repair or replace harness.

### 3. CHECK CLIMATE CONTROLLED SEAT SWITCH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect climate controlled seat switch connector.
3. Check continuity between climate controlled seat switch harness connector and ground.

Climate controlled seat switch			Ground	Continuity
Connector		Terminal		Yes
LH	M262	7		
RH	M263			

Is the inspection result normal?

YES >> Replace climate controlled seat switch. Refer to [SE-82, "Climate Controlled Seat Switch"](#).

NO >> Repair or replace harness.

# CLIMATE CONTROLLED SEAT BLOWER FILTER

< DTC/CIRCUIT DIAGNOSIS >

---

## CLIMATE CONTROLLED SEAT BLOWER FILTER

### Diagnosis Procedure

INFOID:000000012372860

#### 1. CHECK CLIMATE CONTROLLED SEAT BLOWER FILTER

---

Remove climate controlled seat blower filter and check that there is no clogging by dirt or foreign matter.

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace climate controlled seat blower filter. Refer to [SE-81, "Climate Controlled Seat Blower Assembly"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# CLIMATE CONTROLLED SEAT SYSTEM

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### CLIMATE CONTROLLED SEAT SYSTEM

#### Symptom Table

INFOID:000000011932920

Symptom		Inspection item
Climate controlled seat inoperative.		Power supply and ground circuit Refer to <a href="#">SE-46, "CLIMATE CONTROLLED SEAT CONTROL UNIT : Diagnosis Procedure"</a> .
Climate controlled seat blower motor inoperative.		Climate controlled seat blower motor Refer to <a href="#">SE-58, "Diagnosis Procedure"</a> .
Seat cushion thermal electric device inoperative.		Seat cushion thermal electric device Refer to <a href="#">SE-50, "Diagnosis Procedure"</a> .
Seatback thermal electric device inoperative.		Seatback thermal electric device Refer to <a href="#">SE-50, "Diagnosis Procedure"</a> .
Climate controlled seat switch LO, MED or HI inoperative.		Climate controlled seat switch Refer to <a href="#">SE-61, "Diagnosis Procedure"</a> .
Climate controlled seat switch indicator inoperative.		Climate controlled seat switch indicator Refer to <a href="#">SE-61, "Diagnosis Procedure"</a> .
Climate controlled seat turns off too soon.	Climate controlled seat switch indicator turns off within 10 seconds of turning on.	Malfunction caused by electrical issue. Check the following: <ul style="list-style-type: none"> <li>• Connectors for physical damage or loose terminals.</li> <li>• Seat cushion thermal electric device. Refer to <a href="#">SE-54, "Diagnosis Procedure"</a>.</li> <li>• Seatback thermal electric device. Refer to <a href="#">SE-50, "Diagnosis Procedure"</a>.</li> <li>• Climate controlled seat blower motor. Refer to <a href="#">SE-58, "Diagnosis Procedure"</a>.</li> </ul>
	Climate controlled seat switch indicator turns off 30 seconds or more after turning on.	Malfunction caused by mechanical issue. Check the following: <ul style="list-style-type: none"> <li>• Foam seat pads not aligned for thermal electric device outlet.</li> <li>• Thermal electric device ducting restricted or disconnected.</li> <li>• Climate controlled seat blower motor inlet restricted.</li> </ul>




# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK AND RATTLE TROUBLE DIAGNOSES

### Work Flow

INFOID:000000011932921



SBT842

### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-69, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

### DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
  - 2) Tap or push/pull around the area where the noise appears to be coming from.
  - 3) Rev the engine.
  - 4) Use a floor jack to recreate vehicle "twist".
  - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
  - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
  - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - removing the components in the area that you suspect the noise is coming from.  
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
  - tapping or pushing/pulling the component that you suspect is causing the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
  - placing a piece of paper between components that you suspect are causing the noise.
  - looking for loose components and contact marks.Refer to [SE-66, "Generic Squeak and Rattle Troubleshooting"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - separate components by repositioning or loosening and retightening the component, if possible.
  - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-50397) is available through your authorized NISSAN Parts Department.

### **CAUTION:**

**Do not use excessive force as many components are constructed of plastic and may be damaged.**

### **NOTE:**

- Always check with the Parts Department for the latest parts information.
- The materials contained in the NISSAN Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.
- The following materials not found in the kit can also be used to repair squeaks and rattles.
  - SILICONE GREASE: Use instead of UHMW tape that will be visible or does not fit. The silicone grease will only last a few months.
  - SILICONE SPRAY: Use when grease cannot be applied.
  - DUCT TAPE: Use to eliminate movement.

## CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

## Generic Squeak and Rattle Troubleshooting

INFOID:000000011932922

Refer to Table of Contents for specific component removal and installation information.

## INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

### **CAUTION:**

**Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.**

## CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

## DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-50397) to repair the noise.

## TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

## SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

## OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

3. Loose screws at console attachment points.

### SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

### UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:000000011932923





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

\_\_\_\_\_

\_\_\_\_\_

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- |   |  |
|---|--|
| <input type="checkbox"/> Anytime                      | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning      | <input type="checkbox"/> When it is raining or wet     |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions       |
| <input type="checkbox"/> Only when it is hot outside  | <input type="checkbox"/> Other:                        |

### III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about \_\_\_\_ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: \_\_\_\_\_
- After driving \_\_\_\_ miles or \_\_\_\_ minutes

### IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

### TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: \_\_\_\_\_ Customer Name \_\_\_\_\_

W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

LAI0071E

# FRONT SEAT

< REMOVAL AND INSTALLATION >


## REMOVAL AND INSTALLATION

### FRONT SEAT

Exploded View

INFOID:000000011932930

Driver Seat - With Climate Controlled Seats



- |                                     |                                   |                                     |
|-------------------------------------|-----------------------------------|-------------------------------------|
| 1. Seatback thermal electric device | 2. Thermal electric device nozzle | 3. Headrest                         |
| 4. Seat cushion trim                | 5. Thigh extension pad            | 6. Seat cushion pad                 |
| 7. Headrest holder (free)           | 8. Seat frame assembly            | 9. Seat cushion inner finisher (RH) |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## FRONT SEAT

### < REMOVAL AND INSTALLATION >

---


- |   |  |   |
|---|--|---|
| 10. Seat cushion outer finisher (RH)        | 11. Seat cushion assembly                | 12. Front leg finisher (inner)                      |
| 13. Front leg finisher (outer)              | 14. Front seat leg finisher cover        | 15. Thigh extension bracket                         |
| 16. Seat cushion front finisher             | 17. Climate controlled seat control unit | 18. Driver seat control unit                        |
| 19. Climate controlled seat blower assembly | 20. Seat harness                         | 21. Climate controlled seat blower assembly bracket |
| 22. Power seat switch                       | 23. Seat cushion outer finisher (RH)     | 24. Seat slide knob                                 |
| 25. Seat recline knob                       | 26. Lumbar support switch                | 27. Seat cushion outer finisher assembly (LH)       |
| 28. Seat cushion inner finisher (LH)        | 29. Rear leg finisher (outer)            | 30. Slide finisher outer (LH)                       |
| 31. Seat finisher inner (RH)                | 32. Rear leg finisher (inner)            | 33. Headrest holder (locked)                        |
| 34. Blower duct                             | 35. Blower duct guide                    | A. Refer to INSTALLATION.                           |



# FRONT SEAT

< REMOVAL AND INSTALLATION >

Driver Seat - With Heated Seats



- |   |                                      |                                     |
|---|--------------------------------------|-------------------------------------|
| 1. Seat cushion trim                          | 2. Front seat heater                 | 3. Thigh extension pad              |
| 4. Seat cushion pad                           | 5. Seat cushion assembly             | 6. Headrest                         |
| 7. Headrest holder (free)                     | 8. Seat frame assembly               | 9. Seat cushion inner finisher (RH) |
| 10. Seat cushion outer finisher (RH)          | 11. Front leg finisher (inner)       | 12. Front seat leg finisher cover   |
| 13. Thigh extension bracket                   | 14. Seat cushion front finisher      | 15. Front leg finisher (outer)      |
| 16. Driver seat control unit                  | 17. Seat harness                     | 18. Power seat switch               |
| 19. Seat cushion outer finisher (LH)          | 20. Seat slide knob                  | 21. Seat recline knob               |
| 22. Seat cushion outer finisher assembly (LH) | 23. Seat cushion inner finisher (LH) | 24. Rear leg finisher (outer)       |

AWJIA1879ZZ


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- |                               |                               |                               |
|-------------------------------|-------------------------------|-------------------------------|
| 25. Slide finisher outer (LH) | 26. Rear leg finisher (inner) | 27. Slide finisher inner (RH) |
| 28. Headrest holder (locked)  | A. Refer to INSTALLATION.     |                               |

### Driver Seat - Without Heated Seats



AWJIA1880ZZ


- |                                      |                                     |                                |
|--------------------------------------|-------------------------------------|--------------------------------|
| 1. Headrest                          | 2. Headrest holder (free)           | 3. Seat frame assembly         |
| 4. Seat cushion inner finisher (RH)  | 5. Seat cushion outer finisher (RH) | 6. Seat cushion assembly       |
| 7. Seat cushion trim                 | 8. Seat cushion pad                 | 9. Front leg finisher (outer)  |
| 10. Front seat leg finisher cover    | 11. Seat cushion front finisher     | 12. Front leg finisher (inner) |
| 13. Driver seat control unit         | 14. Seat harness                    | 15. Power seat switch          |
| 16. Seat cushion outer finisher (LH) | 17. Seat slide knob                 | 18. Seat recline knob          |

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- |                               |                                      |                               |
|-------------------------------|--------------------------------------|-------------------------------|
| 19. Lumbar support switch     | 20. Seat cushion inner finisher (LH) | 21. Rear leg finisher (outer) |
| 22. Slide finisher outer (LH) | 23. Rear leg finisher (inner)        | 24. Slide finisher inner (RH) |
| 25. Headrest holder (locked)  | A. Refer to INSTALLATION.            |                               |

### Passenger Seat - With Climate Controlled Seat



- |  |                                     |                                      |
|--|-------------------------------------|--------------------------------------|
| 1. Seatback thermal electric device          | 2. Thermal electric device nozzle   | 3. Blower duct guide                 |
| 4. Headrest                                  | 5. Seat cushion outer finisher (RH) | 6. Seat recline knob                 |
| 7. Seat cushion outer finisher (RH) assembly | 8. Seat slide knob                  | 9. Power seat switch                 |
| 10. Headrest holder (free)                   | 11. Seat frame assembly             | 12. Seat cushion inner finisher (RH) |


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- |   |   |   |
|---|---|---|
| 13. Seat cushion trim                           | 14. Front leg finisher (outer)                      | 15. Seat cushion pad                            |
| 16. Front seat leg finisher cover               | 17. Seat cushion assembly                           | 18. Front leg finisher (inner)                  |
| 19. Climate controlled seat control unit        | 20. Seat cushion front finisher                     | 21. Occupant classification system seat harness |
| 22. Occupant classification system control unit | 23. Occupant classification system sensor           | 24. Seat harness                                |
| 25. Climate controlled seat blower assembly     | 26. Climate controlled seat blower assembly bracket | 27. Seat cushion outer finisher (LH)            |
| 28. Seat cushion inner finisher (LH)            | 29. Rear leg finisher (inner)                       | 30. Rear leg finisher (outer)                   |
| 31. Headrest holder (locked)                    | 32. Blower duct                                     | A. Refer to INSTALLATION.                       |

### Passenger Seat - With Heated Seats



# FRONT SEAT

## < REMOVAL AND INSTALLATION >

---

- |  |   |   |   |
|--|---|---|---|
| 1. Seat cushion outer finisher assembly    | 2. Seat cushion outer finisher (RH)             | 3. Seat recline knob                      | A |
| 4. Seat slide knob                         | 5. Power seat switch                            | 6. Seat cushion trim                      |   |
| 7. Front seat heater                       | 8. Seat cushion pad                             | 9. Seat cushion assembly                  | B |
| 10. Headrest holder (free)                 | 11. Seat cushion inner finisher (RH)            | 12. Front leg finisher (outer)            |   |
| 13. Front seat leg finisher cover          | 14. Front leg finisher (inner)                  | 15. Seat cushion front finisher           |   |
| 16. Occupant classification system harness | 17. Occupant classification system control unit | 18. Occupant classification system sensor | C |
| 19. Seat harness                           | 20. Seat cushion outer finisher (LH)            | 21. Seat cushion inner finisher (LH)      |   |
| 22. Seat frame assembly                    | 23. Rear leg finisher (inner)                   | 24. Rear leg finisher (outer)             | D |
| 25. Headrest holder (locked)               | 26. Headrest                                    | A. Refer to INSTALLATION.                 | E |

E

F

G

H

I

**SE**

K

L

M

N


O

P

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

### Passenger Seat - Without Heated Seats



- |   |  |   |
|---|--|---|
| 1. Seat cushion outer finisher assembly         | 2. Seat cushion outer finisher (RH)        | 3. Seat recline knob                      |
| 4. Seat slide knob                              | 5. Power seat switch                       | 6. Seat cushion trim                      |
| 7. Seat cushion pad                             | 8. Seat cushion assembly                   | 9. Headrest holder (free)                 |
| 10. Seat cushion outer finisher (RH)            | 11. Front leg finisher (outer)             | 12. Front seat leg finisher cover         |
| 13. Seat cushion front finisher                 | 14. Occupant classification system harness | 15. Front leg finisher (inner)            |
| 16. Occupant classification system control unit | 17. Seat harness                           | 18. Occupant classification system sensor |
| 19. Seat cushion outer finisher (LH)            | 20. Seat cushion inner finisher (LH)       | 21. Seat frame assembly                   |

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- 22. Rear leg finisher (inner)
- 25. Headrest

- 23. Rear leg finisher (outer)
- A. Refer to INSTALLATION.

- 24. Headrest holder (locked)

## Removal and Installation

INFOID:000000011932931

### REMOVAL


#### WARNING:

Do not leave any objects (screwdrivers, tools, etc.) on the seat during seat repair. It can lead to personal injury if the side air bag module should accidentally deploy.


#### CAUTION:

- When removing or installing seat trim, handle it carefully to keep dirt out and to avoid damage.
- When checking power seat circuit for continuity using a circuit tester, do not confuse its connector with side air bag module connector. Such an error may cause air bag module to deploy.
- Do not drop, tilt, or bump side air bag module while installing seat. Always handle it with care.
- After front side air bag module inflates, front seatback assembly must be replaced.
- When removing and installing seat, use shop cloths to protect components from damage.
- Before removing front seat, turn ignition switch OFF, disconnect both battery cables then wait at least three minutes.


1. Slide seat to the full rearward position.
2. Disconnect negative and positive battery terminals, then wait at least three minutes. Refer to [PG-101](#), "Exploded View".
3. Disconnect harness connectors from front seat assembly.
4. Remove front seat front bolts using the following procedure:
  - a. Release pawls and position front leg finisher covers (A) as shown.

 : Pawl


- b. Remove front seat front bolts (B).



- a. Release pawls and position rear leg finisher covers (A) as shown.
5. Connect negative and positive battery terminals, then slide seat to the full forward position. Refer to [PG-101](#), "Exploded View".
6. Disconnect negative and positive battery terminals, then wait at least three minutes. Refer to [PG-101](#), "Exploded View".
7. Remove front seat rear bolts using the following procedure:
  - a. Release pawls and position rear leg finisher covers (A) as shown.

 : Pawl

- b. Remove front seat rear bolts (B).



8. Remove front seat from the vehicle.

### INSTALLATION

Installation is in the reverse order of removal.

#### WARNING:

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- Perform additional services when installing front passenger seat. Refer to [SRC-39, "ZERO POINT RESET : Description"](#).
- Zero point reset must be performed every time front passenger seat is removed from vehicle.
- Zero point reset is done after front passenger seat is installed in vehicle and all bolts are tightened to specification.


### CAUTION:

Make sure that the seat harness or the floor carpet is not damaged during installation.

### NOTE:


- When installing front seat (LH), hand-tighten bolt (1), then bolt (2) and tighten in the order shown.
- Tighten bolts to specification.

LH front seat bolt torque : 49 Nm (5.0 kg-m, 36 ft-lb)



- When installing front seat (RH), hand-tighten bolt (1), then bolt (2) and tighten in the order shown.
- Tighten bolts to specification.

RH front seat bolt torque : 49 Nm (5.0 kg-m, 36 ft-lb)




## Seatback Thermal Electric Device

INFOID:000000012326206

### REMOVAL

1. Remove front seat. Refer to [SE-79, "Removal and Installation"](#) (driver side) or [SE-79, "Removal and Installation"](#) (passenger side).
2. From under the rear of the front passenger seat, release the seatback J-hooks (A) and position seatback flap (B) aside.

← : Front




3. Release seatback J-hooks, then release seatback zippers (RH/LH) and position seatback trim aside.
4. Remove seatback thermal electric device using the following procedure:



# FRONT SEAT

## < REMOVAL AND INSTALLATION >


- a. Disconnect harness connector (A) and release clip from seat frame.

 : Clip

- b. Remove screws (B) and tie strap (C), then remove seatback thermal electric device (1) from upper blower duct (2) and seat frame.

**CAUTION:**

**Do not reuse tie strap; new tie strap must be used for installation.**



## INSTALLATION

Installation is in the reverse order of removal.

**CAUTION:**


**Do not reuse tie strap; new tie strap must be used for installation.**


## Climate Controlled Seat Blower Assembly

INFOID:000000012326207


## REMOVAL


1. Remove front seat. Refer to [SE-79, "Removal and Installation"](#) (driver side) or [SE-79, "Removal and Installation"](#) (passenger side).
2. From under the rear of the front passenger seat, release the seatback J-hooks (A) and position seatback flap (B) aside.

 : Front





3. Release harness clips (A) from bracket.

 : Front



4. Disconnect harness connector (A) and release harness clip (B) from seat frame (1).

 : Front



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT


## < REMOVAL AND INSTALLATION >

5. Remove tie strap (A) from seatback angle duct.

**CAUTION:**


**Do not reuse tie strap; new tie strap must be used for installation.**

⇐ : Front



6. Release bracket pawls and remove bracket and climate controlled seat blower assembly from seat frame.
7. Remove screws (A) from climate controlled seat blower assembly (1) and screws (B) from bracket (2), then remove climate controlled seat blower assembly (1).

⇐ : Front



## INSTALLATION

Installation is in the reverse order of removal.

**CAUTION:**


**Do not reuse tie strap; new tie strap must be used for installation.**

- Tighten screws (A) from climate controlled seat blower assembly (1) and screws (B) from bracket (2), then remove climate controlled seat blower assembly (1).

(A) 8-32 x 5/8 Screw : 0.5 Nm (0.05 kg-m, 4 in-lb)

(B) M4x10mm Screw : Hand tighten

⇐ : Front




## Climate Controlled Seat Switch

INFOID:000000012326208

## REMOVAL

1. Remove shift selector knob. Refer to [TM-185, "Removal and Installation"](#).
2. Remove shift selector finisher. Refer to [IP-20, "Exploded View"](#).
3. Disconnect harness connectors (B) from climate controlled seat switch (1,2) then remove screws (A).
4. Remove switch carrier (C) then release pawls and remove climate controlled seat switch (1,2) from switch carrier (C).



# FRONT SEAT

## < REMOVAL AND INSTALLATION >

### INSTALLATION


Installation is in the reverse order of removal.

#### Front Heated Seat Switch

INFOID:000000012326210

### REMOVAL

1. Remove shift selector knob. Refer to [TM-185, "Removal and Installation"](#).
2. Remove shift selector finisher. Refer to [IP-20, "Exploded View"](#).
3. Disconnect harness connectors (B) from heated seat switch (1,2) then remove screws (A).
4. Remove switch carrier (C) then release pawls and remove heated seat switch (1,2) from switch carrier (C).



### INSTALLATION

Installation is in the reverse order of removal.

#### Front Seat Heater

INFOID:000000012326211

### REMOVAL

1. Remove seat cushion pad. Refer to [SE-99, "DRIVER SIDE : Seat Cushion"](#) (driver side) or [SE-108, "PASSENGER SIDE : Seat Cushion"](#) (passenger side).
2. Carefully remove front seat heater from seat cushion pad.  
**CAUTION:**
  - Carefully remove seat heater from seat cushion pad.
  - Do not damage seat cushion pad when removing seat heater, if damaged replace seat cushion pad.

### INSTALLATION

1. Peel protective backing from front seat heater and attach to seat cushion pad.
2. Secure front seat heater harness to seat cushion frame.
3. Install remaining seat cushion components. Refer to [SE-99, "DRIVER SIDE : Seat Cushion"](#) (driver side) or [SE-108, "PASSENGER SIDE : Seat Cushion"](#) (passenger side).

#### Climate Controlled Seat Control Unit

INFOID:000000012326209


### REMOVAL

1. Remove front seat. Refer to [SE-79, "Removal and Installation"](#) (driver side) or [SE-79, "Removal and Installation"](#) (passenger side).
2. Remove climate controlled seat control unit using the following procedure:
  - a. For driver seat, perform the following steps:


# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- i. Remove screws (A), then disconnect harness connectors (B) and remove driver seat control unit (1).




- ii. Remove screws (A), then disconnect harness connectors (B) and remove climate controlled seat control unit (1).



- b. For passenger seat, perform the following steps:

- i. Remove screws (A), then disconnect harness connectors (B) and remove climate controlled seat control unit (1).



## INSTALLATION

Installation is in the reverse order of removal.


## Power Seat Switch



INFOID:000000012326212

## EXPLODED VIEW

# FRONT SEAT

## < REMOVAL AND INSTALLATION >



- |                                |  |   |
|--------------------------------|--|---|
| 1. Seat cushion outer finisher | 2. Power seat switch   | 3. Slide knob   |
| 4. Recline knob                |  Pawl |  Front |


### REMOVAL


#### NOTE:

LH shown, RH similar.

- Remove front seat assembly. Refer to [SE-79, "Removal and Installation"](#).
- Remove front finisher screws (B), release pawls and remove seat front finisher (1).


(A) : Harness connector


 : Pawl




- Remove the seat cushion outer finisher (LH) using the following procedure:

- Using a suitable tool, remove seat slide knob (1) and seat recline knob (2).
- Remove screw (A), then release clips and pawls and remove seat cushion outer finisher [LH (3)].

 : Pawl


 : Clip




# FRONT SEAT

## < REMOVAL AND INSTALLATION >

4. Release pawls and remove power seat switch, then disconnect harness connector from power seat switch.

 : Pawls



## INSTALLATION

Installation is in the reverse order of removal.


### CAUTION:

- Visually check clips for deformation and damage during installation. Replace with new ones if necessary.
- When installing seat cushion outer finisher (LH) and seat front finisher, check that clips are securely placed into seat cushion frame holes.

## Lumbar Support Switch


INFOID:000000012326213

## EXPLODED VIEW



1. Seat cushion outer finisher

2. Lumbar support switch

 Pawl

 Clip

 Front

## REMOVAL

1. Remove front seat assembly. Refer to [SE-79, "Removal and Installation"](#).


# FRONT SEAT

## < REMOVAL AND INSTALLATION >

2. Remove front finisher screws (B), release pawls and remove seat front finisher (1).

(A) : Harness connector

○ : Pawl




3. Remove the seat cushion outer finisher (LH) from the front driver seat using the following procedure:

- a. Using a suitable tool remove seat slide knob (1) and seat recline knob (2).
- b. Remove screw (A), then release clips and pawls and remove seat cushion outer finisher [LH (4)].

(3) : Lumbar support switch

○ : Pawl


△ : Clip



4. Disconnect the harness connector (3) from the lumbar support switch (1).
5. Release the harness connector clip, then release pawls and remove lumbar support switch (1) through front of seat cushion outer finisher [LH(2)].

○ : Pawl

△ : Clip



## INSTALLATION

Installation is in the reverse order of removal.

### CAUTION:

- Visually check clips and pawls for deformation and damage during installation. Replace with new ones if necessary.
- When installing seat cushion outer finisher (LH) and seat front finisher, check that clips are securely placed into seat cushion frame holes.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# REAR SEAT

< REMOVAL AND INSTALLATION >

## REAR SEAT

Exploded View

INFOID:000000011932935




AWJIA2058ZZ



# REAR SEAT

## < REMOVAL AND INSTALLATION >

- |                           |                             |                             |   |
|---------------------------|-----------------------------|-----------------------------|---|
| 1. Headrest (RH)          | 2. Headrest holder (locked) | 3. Headrest holder (free)   | A |
| 4. Seatback latch strap   | 5. Seatback latch           | 6. Armrest                  |   |
| 7. Cup holder             | 8. Armrest finisher         | 9. Armrest assembly         |   |
| 10. Seat cushion lock     | 11. Seat cushion assembly   | 12. Seatback assembly       | B |
| 13. Headrest (center)     | 14. Seatback board (RH)     | 15. Seatback frame (RH)     |   |
| 16. Seatback trim (RH)    | 17. Seatback pad (RH)       | 18. Seat cushion pad        |   |
| 19. Seat cushion trim     | 20. Seat cushion wire cover | 21. Seatback hinge assembly | C |
| 22. Side bolster pad (LH) | 23. Side bolster trim (LH)  | 24. Seat belt guide (LH)    |   |
| 25. Seatback frame (LH)   | 26. Seatback trim (LH)      | 27. Headrest (LH)           |   |
| 28. Seatback trim (LH)    | 29. Seatback pad (LH)       | 30. Seatback (LH)           | D |
| 31. Seat belt guide (RH)  | 32. Seat bolster trim (RH)  | 33. Side bolster pad (RH)   |   |
| 34. Grommet               | A. Refer to INSTALLATION.   | Clip                        | E |

 Metal clip

## Removal and Installation

INFOID:000000011932936


### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.


### SEAT CUSHION ASSEMBLY

#### Removal

1. Locate the seat cushion lock (2) at the front bottom of the seat cushion assembly (one for each side). Pull the release lever (A) forward and lift the seat cushion assembly upward to release the seat cushion wire (1) from the seat cushion lock (2).

 : Front

2. Then pull the seat cushion assembly forward and up to remove.



ALJIA0949ZZ


#### Installation

Installation is in the reverse order of removal.


### SEATBACK

#### Removal

1. Locate the seat cushion lock (2) at the front bottom of the seat cushion assembly (one for each side). Pull the release lever (A) forward and lift the seat cushion assembly upward to release the seat cushion wire (1) from the seat cushion lock (2).

 : Front

2. Then pull the seat cushion assembly forward and up to remove.




ALJIA0949ZZ

3. With the seatbacks (LH/RH) locked in the upright position, perform the following step.


# REAR SEAT


## < REMOVAL AND INSTALLATION >

- a. Remove the seatback hinge assembly bolts and nut.



4. Fold seatbacks (LH/RH) forward.
5. Release clips and route seat belt buckle through the seatback assembly (1), then remove seatback assembly (1).

 : Clip




### Installation

Installation is in the reverse order of removal.

#### NOTE:

When installing seatback assembly, note the following installation sequence.

<b>Step 1</b>	<b>M10 nut</b>	<b>No. 1</b>	<b>Temporarily tighten</b>
<b>Step 2</b>	<b>M8 bolts</b>	<b>No. 2, 3</b>	<b>Temporarily tighten</b>
<b>Step 3</b>	<b>Clip</b>	<b>No. 4, 5, 6</b>	<b>Install</b>
<b>Step 4</b>	<b>M10 nut</b>	<b>No. 1</b>	<b>49 N·m (5.0 kg-m, 36 ft-lb)</b>
<b>Step 5</b>	<b>M8 bolts</b>	<b>No. 2, 3</b>	<b>21.05 N·m (2.1 kg-m, 16 ft-lb)</b>



## Removal and Installation - Seatback Latch Assembly

INFOID:000000012379171

### REMOVAL

1. Remove the rear parcel shelf finisher. Refer to [INT-40, "Removal and Installation"](#).

# REAR SEAT


## < REMOVAL AND INSTALLATION >

- From trunk area, release pawls (A) to open cable guide (1).
- Unclip latch cable (2) at location (B).

↔: Front

### NOTE:

LH shown; RH similar.



- Remove two seatback latch assembly bolts and the seatback latch assembly.

## INSTALLATION


Installation is in the reverse order of removal.

## Removal and Installation - Seatback Hinge


INFOID:000000012379174


## REMOVAL

- Remove the rear seatback assembly. Refer to [SE-89. "Removal and Installation"](#).
- Remove rear seatback hinge assembly bolts (A/B).




- Release rear RH seatback flap J-hooks, then release hook and loop fasteners (A) then place seatback flap aside.

 : J-hook




- Release J-hooks (A) from seatback board (1).




## REAR SEAT

### < REMOVAL AND INSTALLATION >

5. Release clips (A), then remove seatback board (1) from rear seatback frame (RH).



6. Remove nut (B), then separate rear seatbacks (LH/RH) from rear seat hinge.



### INSTALLATION


Installation is in the reverse order of removal.

### Removal and Installation - Armrest Assembly


INFOID:000000012379172

### REMOVAL

1. Place the rear seatback assembly (RH) in the folded-down position.
2. Remove center armrest using the following procedure:
  - a. Remove center armrest bolt (A).



- b. Remove the center armrest as shown.



### INSTALLATION

Installation is in the reverse order of removal.

# REAR SEAT

## < REMOVAL AND INSTALLATION >

### Removal and Installation - Rear Seat Bolster


INFOID:000000012379186

#### REMOVAL

1. Remove the rear seatback assembly. Refer to [SE-89. "Removal and Installation"](#).
2. Release clips (A), then remove rear seat bolster.

**NOTE:**

LH shown, RH similar.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I

SE

K  
L  
M  
N  
O  
P

# FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

## UNIT DISASSEMBLY AND ASSEMBLY


FRONT SEAT

DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:000000011932938

Driver Seat - With Climate Controlled Seats



ALJIA1797ZZ

- 1. Seatback thermal electric device
- 4. Seat cushion trim

- 2. Thermal electric device nozzle
- 5. Thigh extension pad

- 3. Headrest
- 6. Seat cushion pad

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >


7. Headrest holder (free)	8. Seat frame assembly	9. Seat cushion inner finisher (RH)	A
10. Seat cushion outer finisher (RH)	11. Seat cushion assembly	12. Front leg finisher (inner)	
13. Front leg finisher (outer)	14. Front seat leg finisher cover	15. Thigh extension bracket	
16. Seat cushion front finisher	17. Climate controlled seat control unit	18. Driver seat control unit	B
19. Climate controlled seat blower assembly	20. Seat harness	21. Climate controlled seat blower assembly bracket	
22. Power seat switch	23. Seat cushion outer finisher (RH)	24. Seat slide knob	C
25. Seat recline knob	26. Lumbar support switch	27. Seat cushion outer finisher assembly (LH)	
28. Seat cushion inner finisher (LH)	29. Rear leg finisher (outer)	30. Slide finisher outer (LH)	D
31. Seat finisher inner (RH)	32. Rear leg finisher (inner)	33. Headrest holder (locked)	
34. Blower duct	35. Blower duct guide	A. Refer to INSTALLATION.	E

**SE**

# FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

Driver Seat - With Heated Seats



AWJIA1879ZZ

- |   |                                      |                                     |
|---|--------------------------------------|-------------------------------------|
| 1. Seat cushion trim                          | 2. Front seat heater                 | 3. Thigh extension pad              |
| 4. Seat cushion pad                           | 5. Seat cushion assembly             | 6. Headrest                         |
| 7. Headrest holder (free)                     | 8. Seat frame assembly               | 9. Seat cushion inner finisher (RH) |
| 10. Seat cushion outer finisher (RH)          | 11. Front leg finisher (inner)       | 12. Front seat leg finisher cover   |
| 13. Thigh extension bracket                   | 14. Seat cushion front finisher      | 15. Front leg finisher (outer)      |
| 16. Driver seat control unit                  | 17. Seat harness                     | 18. Power seat switch               |
| 19. Seat cushion outer finisher (LH)          | 20. Seat slide knob                  | 21. Seat recline knob               |
| 22. Seat cushion outer finisher assembly (LH) | 23. Seat cushion inner finisher (LH) | 24. Rear leg finisher (outer)       |




# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |                               |                               |                               |
|-------------------------------|-------------------------------|-------------------------------|
| 25. Slide finisher outer (LH) | 26. Rear leg finisher (inner) | 27. Slide finisher inner (RH) |
| 28. Headrest holder (locked)  | A. Refer to INSTALLATION.     |                               |

### Driver Seat - Without Heated Seats



- |                                      |                                     |                                |
|--------------------------------------|-------------------------------------|--------------------------------|
| 1. Headrest                          | 2. Headrest holder (free)           | 3. Seat frame assembly         |
| 4. Seat cushion inner finisher (RH)  | 5. Seat cushion outer finisher (RH) | 6. Seat cushion assembly       |
| 7. Seat cushion trim                 | 8. Seat cushion pad                 | 9. Front leg finisher (outer)  |
| 10. Front seat leg finisher cover    | 11. Seat cushion front finisher     | 12. Front leg finisher (inner) |
| 13. Driver seat control unit         | 14. Seat harness                    | 15. Power seat switch          |
| 16. Seat cushion outer finisher (LH) | 17. Seat slide knob                 | 18. Seat recline knob          |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |                               |                                      |                               |
|-------------------------------|--------------------------------------|-------------------------------|
| 19. Lumbar support switch     | 20. Seat cushion inner finisher (LH) | 21. Rear leg finisher (outer) |
| 22. Slide finisher outer (LH) | 23. Rear leg finisher (inner)        | 24. Slide finisher inner (RH) |
| 25. Headrest holder (locked)  | A. Refer to INSTALLATION.            |                               |

### DRIVER SIDE : Seatback

INFOID:000000011932939

#### DISASSEMBLY

##### **WARNING:**

Do not leave any objects (screwdrivers, tools, etc.) on the seat during seatback repair. It can lead to personal injury if the side air bag module should accidentally deploy.

##### **CAUTION:**

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals then wait at least three minutes.
- Always work from the side or back of the seatback, do not work in front of seat.
- Do not use air tools or electric tools for servicing the seat assembly.
- Do not insert any objects into the side air bag module.
- Do not attempt to disassemble the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 90°C (194°F).
- Do not expose the side air bag module to any oil, grease, detergent or water.
- During disassembly, do not damage the seatback board, connectors, retainers, clips, module harness or the side air bag module.

##### **CAUTION:**


If the vehicle has been involved in a collision and the side air bag module has deployed, the seatback must be replaced.

##### **NOTE:**

Climate controlled seat shown, without climate controlled seat similar.

1. Remove the front seat assembly. Refer to [SE-79. "Removal and Installation"](#).
2. From under the rear of the front driver seat, release the seatback J-hooks (A) and position seatback flap (B) aside.

↔ : Front




3. Release seatback J-hooks, then release seatback zippers (RH/LH) and position seatback trim aside.
4. Remove seatback thermal electric device using the following procedure:
  - a. Disconnect harness connector (A) and release clip from seat frame.

△ : Clip

- b. Remove screws (B) and tie strap (C), then remove seatback thermal electric device (1) from upper blower duct (2) and seat frame.

##### **CAUTION:**

Do not reuse tie strap; new tie strap must be used for installation.



5. Remove lower tie strap, then remove upper blower duct from seat frame assembly.


# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

6. Reach in from the bottom of the seatback to release the guide clips on the headrest holder. Squeeze the clips at the bottom and push upward to remove as shown.

**CAUTION:**

Before removing/installing the headrest holder, check its orientation (front/rear and right/left).



7. The remaining parts of the seatback are serviced as part of the front driver seat frame.

### Assembly

Assembly is in the reverse order of disassembly.

**CAUTION:**

- Do not reuse tie strap; new tie strap must be used for installation.
- After work is completed, check that no system malfunction is detected causing the air bag warning lamp to illuminate.
- If a malfunction is detected by the air bag warning lamp after repair or replacement of the malfunction parts, perform the SRS final check. Refer to [SRC-16, "SRS Final Check"](#).

## DRIVER SIDE : Seat Cushion

INFOID:000000012372693

### DISASSEMBLY

**WARNING:**

Do not leave any objects (screwdrivers, tools, etc.) on the seat during seat cushion repair. It can lead to personal injury if the side air bag module should accidentally deploy.


**CAUTION:**


- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
- Always work from the side or back of the seatback assembly, do not work in front of seat.
- Do not use air tools or electric tools for servicing the seat assembly.

**NOTE:**

Climate controlled seat shown, without climate controlled seat similar.

1. Remove the front seat assembly. Refer to [SE-79, "Removal and Installation"](#).
2. Remove front finisher screws (B), release pawls and remove seat front finisher (1), then disconnect harness connectors (A).

 : Pawl





3. Remove the seat cushion outer finisher (LH) using the following procedure:



# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >



- a. Using a suitable tool, remove seat slide knob (1) and seat recline knob (2).
- b. Remove screw (A), then release clips and pawls and remove seat cushion outer finisher [LH (3)].




- c. Release pawls and remove power seat switch, then disconnect harness connector from power seat switch.




4. From under the rear of the front passenger seat, release the seatback J-hooks (A) and position seatback flap (B) aside.



5. Release the RH J-hook (A) from the driver seat frame.




6. Release the LH J-hook (A) from the driver seat frame.




## FRONT SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >


7. Release the front J-hooks (A) from the front driver seat frame.




8. Release J-hooks (A/B), then remove seat cushion trim and thigh extension pad from thigh extension bracket.



9. Release the thigh extension wire (A) from the thigh extension bracket hooks (B) as shown.



10. With the thigh extension trim and pad raised: remove screws (A).
- a. Engage thigh extension handle and remove thigh extension bracket (1) as shown.
- b. Release J-hooks (B) from the driver seat frame.




11. Release rear seat cushion J-hooks using the following procedure:
- a. For models with climate controlled seats use the following step:

# FRONT SEAT


## < UNIT DISASSEMBLY AND ASSEMBLY >

- From the rear of the seat: release clips (A), then reposition seatback duct (1) and remove J-hooks (B).




- b. For models without climate controlled seats use the following steps:
- Release the rear hinge cover J-hooks (A/B) from the seat frame assembly (1).

⇐ : Front




- For models with heated seats, disconnect the harness connector (A) from the seat cushion heater unit and harness connector (B) from the seatback heater unit, then release harness clip and route seat heater harnesses through the seat cushion trim (1).

△ : Clip



12. From the front of the seat, position thigh extender pad and trim aside, then release thigh extender wire (A) from seat frame assembly hooks (B).



13. Remove the seat cushion trim and seat cushion pad as an assembly from the seat frame assembly.  
14. Remove hog rings from under the seat cushion trim and pad.


**CAUTION:**

**Remove all pieces of hog rings and discard them.**

## FRONT SEAT


### < UNIT DISASSEMBLY AND ASSEMBLY >

15. Release the hook fasteners (A), then remove the hog rings and separate the seat cushion trim from the seat cushion pad.

 : Hog ring

**CAUTION:**


Remove all pieces of hog rings and discard them.



### ASSEMBLY

Assembly is in the reverse order of disassembly.

- Install new hog rings on the seat cushion trim in original positions.
- Use only one hog ring in each designated location.
- Make sure hog rings are correctly fastened around both the seat cushion trim and seat cushion pad wires.
- Use NISSAN standard hog rings and tools to assemble.
- Make sure hook fastener is pressed into place after seat cushion trim is assembled.
- Smooth out all wrinkles during assembly.



**CAUTION:**

- After work is completed, check that no system malfunction is detected causing the air bag warning lamp to illuminate.
- If a malfunction is detected by the air bag warning lamp after repair or replacement of the malfunction parts, perform the SRS final check. Refer to [SRC-16, "SRS Final Check"](#).

### PASSENGER SIDE

#### PASSENGER SIDE : Exploded View


INFOID:000000011932940

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

Passenger Seat - With Climate Controlled Seat



- |   |   |   |
|---|---|---|
| 1. Seatback thermal electric device             | 2. Thermal electric device nozzle         | 3. Blower duct guide                            |
| 4. Headrest                                     | 5. Seat cushion outer finisher (RH)       | 6. Seat recline knob                            |
| 7. Seat cushion outer finisher (RH) assembly    | 8. Seat slide knob                        | 9. Power seat switch                            |
| 10. Headrest holder (free)                      | 11. Seat frame assembly                   | 12. Seat cushion inner finisher (RH)            |
| 13. Seat cushion trim                           | 14. Front leg finisher (outer)            | 15. Seat cushion pad                            |
| 16. Front seat leg finisher cover               | 17. Seat cushion assembly                 | 18. Front leg finisher (inner)                  |
| 19. Climate controlled seat control unit        | 20. Seat cushion front finisher           | 21. Occupant classification system seat harness |
| 22. Occupant classification system control unit | 23. Occupant classification system sensor | 24. Seat harness                                |




# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |   |   |                                      |
|---|---|--------------------------------------|
| 25. Climate controlled seat blower assembly | 26. Climate controlled seat blower assembly bracket | 27. Seat cushion outer finisher (LH) |
| 28. Seat cushion inner finisher (LH)        | 29. Rear leg finisher (inner)                       | 30. Rear leg finisher (outer)        |
| 31. Headrest holder (locked)                | 32. Blower duct                                     | A. Refer to INSTALLATION.            |

### Passenger Seat - With Heated Seats



- |   |                                      |                                |
|---|--------------------------------------|--------------------------------|
| 1. Seat cushion outer finisher assembly | 2. Seat cushion outer finisher (RH)  | 3. Seat recline knob           |
| 4. Seat slide knob                      | 5. Power seat switch                 | 6. Seat cushion trim           |
| 7. Front seat heater                    | 8. Seat cushion pad                  | 9. Seat cushion assembly       |
| 10. Headrest holder (free)              | 11. Seat cushion inner finisher (RH) | 12. Front leg finisher (outer) |


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |  |   |   |
|--|---|---|
| 13. Front seat leg finisher cover          | 14. Front leg finisher (inner)                  | 15. Seat cushion front finisher           |
| 16. Occupant classification system harness | 17. Occupant classification system control unit | 18. Occupant classification system sensor |
| 19. Seat harness                           | 20. Seat cushion outer finisher (LH)            | 21. Seat cushion inner finisher (LH)      |
| 22. Seat frame assembly                    | 23. Rear leg finisher (inner)                   | 24. Rear leg finisher (outer)             |
| 25. Headrest holder (locked)               | 26. Headrest                                    | A. Refer to INSTALLATION.                 |

### Passenger Seat - Without Heated Seats



- |   |                                     |                      |
|---|-------------------------------------|----------------------|
| 1. Seat cushion outer finisher assembly | 2. Seat cushion outer finisher (RH) | 3. Seat recline knob |
| 4. Seat slide knob                      | 5. Power seat switch                | 6. Seat cushion trim |

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |   |  |   |
|---|--|---|
| 7. Seat cushion pad                             | 8. Seat cushion assembly                   | 9. Headrest holder (free)                 |
| 10. Seat cushion outer finisher (RH)            | 11. Front leg finisher (outer)             | 12. Front seat leg finisher cover         |
| 13. Seat cushion front finisher                 | 14. Occupant classification system harness | 15. Front leg finisher (inner)            |
| 16. Occupant classification system control unit | 17. Seat harness                           | 18. Occupant classification system sensor |
| 19. Seat cushion outer finisher (LH)            | 20. Seat cushion inner finisher (LH)       | 21. Seat frame assembly                   |
| 22. Rear leg finisher (inner)                   | 23. Rear leg finisher (outer)              | 24. Headrest holder (locked)              |
| 25. Headrest                                    | A. Refer to INSTALLATION.                  |   |

## PASSENGER SIDE : Seatback

INFOID:0000000011932941

### DISASSEMBLY

#### **WARNING:**

Do not leave any objects (screwdrivers, tools, etc.) on the seat during seatback repair. It can lead to personal injury if the side air bag module should accidentally deploy.

#### **CAUTION:**

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals then wait at least three minutes.
- Always work from the side or back of the seatback, do not work in front of seat.
- Do not use air tools or electric tools for servicing the seat assembly.
- Do not insert any objects into the side air bag module.
- Do not attempt to disassemble the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 90°C (194°F).
- Do not expose the side air bag module to any oil, grease, detergent or water.
- During disassembly, do not damage the seatback board, connectors, retainers, clips, module harness or the side air bag module.

#### **CAUTION:**


If the vehicle has been involved in a collision and the side air bag module has deployed, the seatback must be replaced.

#### **NOTE:**

Climate controlled seat shown, without climate controlled seat similar.

1. Remove the front seat assembly. Refer to [SE-79, "Removal and Installation"](#).
2. From under the rear of the front passenger seat, release the seatback J-hooks (A) and position seatback flap (B) aside.

↔ : Front




3. Release seatback J-hooks, then release seatback zippers (RH/LH) and position seatback trim aside.
4. Remove seatback thermal electric device using the following procedure:

## FRONT SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >


- a. Disconnect harness connector (A) and release clip from seat frame.

 : Clip

- b. Remove screws (B) and tie strap (C), then remove seatback thermal electric device (1) from upper blower duct (2) and seat frame.

#### NOTE:


Do not reuse tie strap; new tie strap must be used for installation.



5. Remove lower tie strap, then remove upper blower duct from seat frame assembly.
6. Reach in from the bottom of the seatback to release the guide clips on the headrest holder. Squeeze the clips at the bottom and push upward to remove as shown.

#### CAUTION:

Before removing/installing the headrest holder, check it's orientation (front/rear and right/left).



7. The remaining parts of the seatback are serviced as part of the front passenger seat frame.

#### Assembly

Assembly is in the reverse order of disassembly.

#### CAUTION:

- After work is completed, check that no system malfunction is detected causing the air bag warning lamp to illuminate.
- If a malfunction is detected by the air bag warning lamp after repair or replacement of the malfunction parts, perform the SRS final check. Refer to [SRC-16, "SRS Final Check"](#).

### PASSENGER SIDE : Seat Cushion

INFOID:000000012372697

#### DISASSEMBLY

#### WARNING:

Do not leave any objects (screwdrivers, tools, etc.) on the seat during seat cushion repair. It can lead to personal injury if the side air bag module should accidentally deploy.

#### CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
- Always work from the side or back of the seatback assembly, do not work in front of seat.
- Do not use air tools or electric tools for servicing the seat assembly.

#### NOTE:

Climate controlled seats shown, without climate controlled seats similar.

1. Remove the front seat assembly. Refer to [SE-79, "Removal and Installation"](#).


# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

2. Remove front finisher screws (B), release pawls and remove seat front finisher (1).

(A) : Harness connector

○ : Pawl




3. Remove the seat cushion outer finisher (RH) from the front passenger seat using the following procedure:

- a. Using a suitable tool, remove seat slide knob (3) and seat recline knob (2).
- b. Remove screw (A), then release clips and pawls and remove seat cushion outer finisher [RH (1)].


○ : Pawl

△ : Clip




- c. Release pawls and remove power seat switch, then disconnect harness connector from power seat switch.

○ : Pawls



4. From under the rear of the front passenger seat, release the seatback J-hooks (A) and position seatback flap (B) aside.

← : Front



5. Release rear seat cushion J-hooks using the following procedure:


- a. For models with climate controlled seats use the following step:

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >


- From the rear of the seat, release clips (A), then reposition seatback duct (1) and remove J-hooks (B).



- b. For models without climate controlled seats use the following steps:


- Release the rear hinge cover J-hooks (A/B) from the seat frame assembly (1).

⇐ : Front



- For models with heated seats disconnect the harness connector (A) from the seat cushion heater unit and harness connector (B) from the seatback heater unit, then release harness clip and route seat heater harnesses through the seat cushion trim (1).


△ : Clip



6. Release RH/LH seat cushion J-hooks (A) from the seat frame assembly.

**NOTE:**


RH shown, LH similar.



## FRONT SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >

7. Release front seat cushion J-hook (A) from the seat frame assembly.




8. Remove the seat cushion trim and seat cushion pad as an assembly from the seat frame assembly.  
9. Remove hog rings from under the seat cushion trim and pad.

**CAUTION:**


**Remove all pieces of hog rings and discard them.**

10. Release the hook fasteners (A), then remove the hog rings and separate the seat cushion trim and seat cushion pad.

 : Hog ring

**CAUTION:**


**Remove all pieces of hog rings and discard them.**



### ASSEMBLY

Assembly is in the reverse order of disassembly.

- Install new hog rings on the seat cushion trim in original positions.
- Use only one hog ring in each designated location.
- Make sure hog rings are correctly fastened around both the seat cushion trim and seat cushion pad wires.
- Use NISSAN standard hog rings and tools to assemble.
- Make sure hook fastener is pressed into place after seat cushion trim is assembled.
- Smooth out all wrinkles during assembly.



**CAUTION:**

- After work is completed, check that no system malfunction is detected causing the air bag warning lamp to illuminate.
- If a malfunction is detected by the air bag warning lamp after repair or replacement of the malfunction parts, perform the SRS final check. Refer to [SRC-16, "SRS Final Check"](#).


# REAR SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

## REAR SEAT

Exploded View

INFOID:000000011932943




AWJIA2058ZZ



# REAR SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

- |                           |                             |                             |    |
|---------------------------|-----------------------------|-----------------------------|----|
| 1. Headrest (RH)          | 2. Headrest holder (locked) | 3. Headrest holder (free)   | A  |
| 4. Seatback latch strap   | 5. Seatback latch           | 6. Armrest                  | B  |
| 7. Cup holder             | 8. Armrest finisher         | 9. Armrest assembly         | C  |
| 10. Seat cushion lock     | 11. Seat cushion assembly   | 12. Seatback assembly       | D  |
| 13. Headrest (center)     | 14. Seatback board (RH)     | 15. Seatback frame (RH)     | E  |
| 16. Seatback trim (RH)    | 17. Seatback pad (RH)       | 18. Seat cushion pad        | F  |
| 19. Seat cushion trim     | 20. Seat cushion wire cover | 21. Seatback hinge assembly | G  |
| 22. Side bolster pad (LH) | 23. Side bolster trim (LH)  | 24. Seat belt guide (LH)    | H  |
| 25. Seatback frame (LH)   | 26. Seatback trim (LH)      | 27. Headrest (LH)           | I  |
| 28. Seatback trim (LH)    | 29. Seatback pad (LH)       | 30. Seatback (LH)           | SE |
| 31. Seat belt guide (RH)  | 32. Seat bolster trim (RH)  | 33. Side bolster pad (RH)   | K  |
| 34. Grommet               | A. Refer to INSTALLATION.   | Clip                        | L  |

 Metal clip

## SEATBACK


### SEATBACK : Disassembly and Assembly

INFOID:000000012326758


#### REAR SEATBACK ASSEMBLY (RH)


##### Disassembly

1. Remove the rear seatback assembly. Refer to [SE-89. "Removal and Installation"](#).
2. Remove rear seatback hinge assembly bolts (A/B).




3. Release rear RH seatback flap J-hooks, then release hook and loop fasteners (A) then place seatback flap aside.

 : J-hook




4. Release J-hooks (A) from seatback board [RH (1)].




## REAR SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >


5. Release clips (A), then remove seatback board [RH (1)] from rear seatback frame (RH).



6. Remove nut (B) then separate rear seatbacks (LH/RH).



7. Release J-hooks (A) then position seatback flaps aside.




8. Remove headrest holder (free) and headrest holder (lock).  
**NOTE:**


# REAR SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >


Using suitable tool (B), release the center headrest holder [lock (A)] and headrest holder [free (C)] as shown.



9. Remove armrest assembly using the following procedure:
  - a. Remove armrest assembly bolt (A).



- b. Remove the armrest assembly as shown.




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


## REAR SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >


10. Remove armrest finisher (1) as shown.



11. Release J-hooks (A) from the rear seatback frame (RH), then remove seatback frame (RH) and route trim retainers (B) through seatback pad (RH).



12. Release hook and loop fasteners (A), then separate the rear seatback pad (RH) from the seatback trim (RH).




### Assembly

Assembly is in the reverse order of disassembly.

### NOTE:

When installing the seatback trim, firmly push down while sliding your hand along the seams as shown to ensure the hook fasteners below the seatback trim are fastened properly.



### REAR SEATBACK ASSEMBLY (LH)


#### Disassembly

1. Remove the rear seatback assembly. Refer to [SE-89, "Removal and Installation"](#).


# REAR SEAT


## < UNIT DISASSEMBLY AND ASSEMBLY >

2. Remove rear seatback hinge assembly bolts (A/B).




3. Release rear RH seatback flap J-hooks, then release hook and loop fasteners (A) then place seatback flap aside.


 : J-hook




4. Release J-hooks (A) from seatback board [LH (1)].



5. Release clips (A), then remove seatback board [RH (1)] from seatback frame (RH).



6. Remove nut (B) then separate rear seatbacks (LH/RH).





A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## REAR SEAT


### < UNIT DISASSEMBLY AND ASSEMBLY >

- Remove LH headrest.
- Release J-hook and hook and loop fasteners (A), then place aside LH rear seatback flap.


 : J-hook




- Release J-hooks (A) from seatback board [LH (1)].



- Release clips (A) from seatback frame and remove seatback board [LH (1)].



- Release J-hook (A) from seatback frame (1), then position J-hook (A) aside.



- Release headrest holder (lock) and headrest holder (free), then remove headrest holders.


**CAUTION:**

**Before removing/installing the headrest holder (lock) and headrest holder (free), check orientation (front/rear and right/left).**


# REAR SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >

13. Release J-hooks (A), then remove seatback frame (LH) from seatback pad and trim assembly (LH).



14. Route J-hooks through the seatback pad (LH), then release hook fasteners (A) and separate seatback pad (LH) from seatback trim (LH).




### Assembly

Assembly is in the reverse order of disassembly.

### NOTE:

When installing the seatback trim, firmly push down while sliding your hand along the seams as shown to ensure the hook fasteners below the seatback trim are fastened properly.



## SEAT CUSHION

### SEAT CUSHION : Disassembly and Assembly


### SEAT CUSHION

INFOID:000000012326759

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEAT

## < UNIT DISASSEMBLY AND ASSEMBLY >



1. Seat cushion trim

2. Seat cushion pad

A. Hook and loop fasteners

⌋ Hog rings


### Disassembly

1. Remove the seat cushion assembly. Refer to [SE-89. "Removal and Installation"](#).
2. Remove the hog rings from the bottom of the seat cushion pad and trim.  
**CAUTION:**  
**Remove all pieces of hog rings and discard them.**
3. Release the hook and loop fasteners from the top of the seat cushion.
4. Separate the seat cushion trim from the seat cushion pad.

### Assembly

Assembly is in the reverse order of disassembly.

- Install new hog rings on the seat cushion trim in original positions.
- Use only one hog ring in each designated location.
- Make sure hog rings are correctly fastened around both the seat cushion trim and seat cushion pad wires.
- Use NISSAN standard hog rings and tools to assemble.






## REAR SEAT

### < UNIT DISASSEMBLY AND ASSEMBLY >

- When installing the seat cushion trim, firmly push down while sliding your hand along the seams as shown to ensure the hook fasteners below the seat cushion trim are fastened properly.



A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P