

# SECTION **WCS**

## WARNING CHIME SYSTEM

### CONTENTS

<b>PRECAUTION</b> .....	3	List of ECU Reference .....	17
<b>PRECAUTIONS</b> .....	3	<b>WIRING DIAGRAM</b> .....	18
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	<b>WARNING CHIME SYSTEM</b> .....	18
		Wiring Diagram .....	18
<b>SYSTEM DESCRIPTION</b> .....	4	<b>BASIC INSPECTION</b> .....	23
<b>COMPONENT PARTS</b> .....	4	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	23
Component Parts Location .....	4	Work Flow .....	23
Combination Meter .....	4		
<b>SYSTEM</b> .....	5	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	25
<b>WARNING CHIME SYSTEM</b> .....	5	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	25
WARNING CHIME SYSTEM : System Description .....	5	<b>COMBINATION METER</b> .....	25
WARNING CHIME SYSTEM : Fail-Safe .....	6	COMBINATION METER : Diagnosis Procedure ....	25
<b>WARNING CHIME</b> .....	6	<b>BCM (BODY CONTROL MODULE)</b> .....	25
WARNING CHIME : Light Reminder Warning .....	6	BCM (BODY CONTROL MODULE) : Diagnosis	
WARNING CHIME : Parking Brake Release .....		Procedure .....	25
Warning Chime .....	7	<b>METER BUZZER CIRCUIT</b> .....	27
WARNING CHIME : Seat belt Warning .....	8	Component Function Check .....	27
<b>DIAGNOSIS SYSTEM (COMBINATION METER)</b> .....	9	Diagnosis Procedure .....	27
On Board Diagnosis Function .....	9		
CONSULT Function (METER/M&A) .....	11	<b>SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT</b> .....	28
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	14	Component Function Check .....	28
<b>COMMON ITEM</b> .....	14	Diagnosis Procedure .....	28
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	14	Component Inspection .....	29
<b>BUZZER</b> .....	15	<b>PARKING BRAKE SWITCH SIGNAL CIRCUIT</b> .....	30
BUZZER : CONSULT Function (BCM - BUZZER) .....	15	Component Function Check .....	30
<b>ECU DIAGNOSIS INFORMATION</b> .....	17	Diagnosis Procedure .....	30
<b>BCM, COMBINATION METER</b> .....	17	Component Inspection .....	30
		<b>SYMPTOM DIAGNOSIS</b> .....	31
		<b>WARNING CHIME SYSTEM SYMPTOMS</b> .....	31
		Symptom Table .....	31

A  
B  
C  
D  
E

WCS

O  
P

---

<b>THE LIGHT REMINDER WARNING DOES NOT SOUND .....</b>	<b>32</b>	Diagnosis Procedure .....	33
Description .....	32		
Diagnosis Procedure .....	32		
<b>THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND .....</b>	<b>33</b>		
Description .....	33		
<b>THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND .....</b>	<b>34</b>		
Description .....	34		
Diagnosis Procedure .....	34		

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000012228460

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000012226821



ALNIA1752ZZ


No.	Component	Function
1.	ABS actuator and electric unit (control unit)	<ul style="list-style-type: none"><li>Transmits the vehicle speed signal to the combination meter via CAN communication.</li><li>Refer to <a href="#">BRC-10, "Component Parts Location"</a> for detailed installation location.</li></ul>
2.	Parking brake switch	Transmits the parking brake switch signal to the combination meter.
3.	BCM	<ul style="list-style-type: none"><li>Based on the signals received from various units and switches, transmits the buzzer output signal to the combination meter via CAN communication.</li><li>Refer to <a href="#">BCS-5, "BODY CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.</li></ul>
4.	Combination meter	<ul style="list-style-type: none"><li>Receives a buzzer output signal from the BCM via CAN communication and sounds the buzzer.</li><li>Judges whether the parking brake is released using the vehicle speed signal and the parking brake switch signal, and sounds the buzzer if necessary.</li></ul>
5.	Seat belt buckle switch LH	Transmits a seat belt buckle switch signal LH to the combination meter.

#### Combination Meter

INFOID:0000000012226822

The combination meter has a built-in buzzer (1) and sounds the following warnings, according to signals from each switch and unit:

- Light reminder warning
- Parking brake release warning chime
- Seat belt warning



ALNIA1681ZZ

# SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM

### WARNING CHIME SYSTEM

#### WARNING CHIME SYSTEM : System Description

INFOID:0000000012226823

#### SYSTEM DIAGRAM



#### DESCRIPTION

##### Combination Meter:

The combination meter sounds the alarm buzzer installed in the combination meter when receiving the buzzer output signal transmitted from each unit.

##### BCM:

BCM receives signals from various units and transmits a buzzer output signal to the combination meter via CAN communication if it judges that the warning buzzer should be activated.

#### WARNING CHIME FUNCTION LIST

Warning functions	Refer to
Light reminder warning	<a href="#">WCS-6, "WARNING CHIME : Light Reminder Warning"</a>
Parking brake release warning chime	<a href="#">WCS-7, "WARNING CHIME : Parking Brake Release Warning Chime"</a>
Seat belt warning	<a href="#">WCS-8, "WARNING CHIME : Seat belt Warning"</a>

#### COMBINATION METER INPUT/OUTPUT SIGNAL (CAN COMMUNICATION SIGNAL)

##### Input signal

Signal name	Transmit unit
Vehicle speed signal	ABS actuator and electric unit (control unit)
Buzzer output signal	BCM

##### Output signal

Signal name	Reception unit
Vehicle speed signal	BCM

WCS

#### BCM INPUT/OUTPUT SIGNAL (CAN COMMUNICATION SIGNAL)

##### Input signal

O

P

# SYSTEM

## < SYSTEM DESCRIPTION >

Signal name	Transmit unit
Vehicle speed signal	Combination meter

Output signal

Signal name	Reception unit
Buzzer output signal	Combination meter

## WARNING CHIME SYSTEM : Fail-Safe

INFOID:000000012226824

The combination meter activates the fail-safe control, if CAN communication with each unit is malfunctioning.


Function	Specifications
Buzzer	The buzzer turns OFF by suspending communication.

## WARNING CHIME

### WARNING CHIME : Light Reminder Warning

INFOID:000000012226825

#### SYSTEM DIAGRAM



#### WARNING CHIME OPERATION CONDITIONS

If all of the following conditions are fulfilled:

Operation conditions	
Ignition switch	OFF
Combination switch (Lighting switch)	1st or 2nd position
Driver side door	Open [front door switch LH ON]

#### WARNING CHIME CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled:

Operation conditions	
Ignition switch	ON
Combination switch (Lighting switch)	OFF or AUTO position
Driver side door	Close [front door switch LH OFF]

#### SIGNAL PATH

1. BCM requires warning chime output to combination meter when it judges light reminder warning chime is necessary from signals below.

# SYSTEM

## < SYSTEM DESCRIPTION >

Signal name	Signal source
Ignition switch signal	—
Combination switch signal	Combination switch (Lighting switch) → BCM
Driver door switch signal	Front door switch LH → BCM


2. Combination meter sounds integrated buzzer, following the warning chime output requirement (below signal) from BCM.

Signal name	Signal source
Buzzer output signal	BCM → CAN → Combination meter

## WARNING CHIME : Parking Brake Release Warning Chime

INFOID:0000000012226826

### SYSTEM DIAGRAM



### WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled:

Operation conditions	
Ignition switch	ON
Parking brake	During the operation (parking brake switch ON).
Vehicle speed	Approximately 4.3 MPH (7 km/h) or more.

### WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled:

Operation conditions	
Ignition switch	OFF
Parking brake	Release condition (parking brake switch OFF).
Vehicle speed	Approximately 1.9 MPH (3 km/h) or less.

### SIGNAL PATH

Combination meter sounds integrated buzzer when it judges that parking brake release warning chime is necessary from signals below.

Signal name	Signal source
Ignition switch signal	—
Parking brake switch signal	Parking brake switch → Combination meter
Vehicle speed signal	ABS actuator and electric unit (control unit) → CAN → Combination meter


# SYSTEM

< SYSTEM DESCRIPTION >

## WARNING CHIME : Seat belt Warning

INFOID:000000012226827

### SYSTEM DIAGRAM



### WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled:

Operation conditions	
Ignition switch	ON
Seat belt buckle switch LH	Unfastened [seat belt buckle switch LH ON]

### WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled:

Operation conditions	
Ignition switch	OFF
Seat belt buckle switch LH	Fastened (seat belt buckle switch LH OFF)
6 seconds after the start of warning sound.	

### SIGNAL PATH

1. BCM requires warning chime output to combination meter, when it judges seat belt warning chime is necessary from signals below.

Signal name	Signal source
Ignition switch signal	—
Seat belt buckle switch signal LH	Seat belt buckle switch LH → Combination meter → CAN → BCM

2. Combination meter sounds integrated buzzer, following the warning chime output requirement (below signal) from BCM.

Signal name	Signal source
Buzzer output signal	BCM → CAN → Combination meter

# DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (COMBINATION METER)

### On Board Diagnosis Function

INFOID:000000012228514

#### COMBINATION METER SELF-DIAGNOSIS MODE

The following meter functions can be checked during Combination Meter Self-Diagnosis Mode:

- Pointer sweep of speedometer, tachometer and gauges
- Illumination of all LCD segments and color patterns for meter displays
- Illumination of all lamps/LEDs that are controlled by the combination meter (regardless of switch status)

#### STARTING COMBINATION METER SELF-DIAGNOSIS MODE

##### NOTE:


- Check combination meter power supply and ground circuits if self-diagnosis mode does not start. Refer to [WCS-25, "COMBINATION METER : Diagnosis Procedure"](#). Replace combination meter if power supply and ground circuits are found to be normal and self-diagnosis mode does not start. Refer to [MWI-68, "Removal and Installation"](#).
- Combination meter self-diagnosis mode will function with the ignition switch in ON. Combination meter self-diagnosis mode will exit upon turning the ignition switch to OFF.

##### How to Initiate Self-Diagnosis Mode

1. Turn ignition switch OFF.
2. While pressing the trip reset switch (1), turn ignition switch ON.
3. Keep pressing the trip reset switch for 1 second or more.
4. Press the trip reset switch at least 3 times within 7 seconds after the ignition switch is turned ON.
5. "Work instruction code" is indicated in the top portion of information display and self-diagnosis is started.
6. The mode switches in the order shown below each time the trip reset switch is pressed.

##### NOTE:

If the trip reset switch is not operated for 20 seconds or more, the self-diagnosis mode is automatically canceled.



AWNIA3394ZZ

Test order	Test item	Description
1	Work instruction code	
2	Part number	
3	Software code	This item is displayed, but not used.
4	EEPROM code	
5	Hardware code	
6	P.C.B code	
7	Circuit check	<p>The pointer of the following items moves from 0 to MAX twice:</p> <ul style="list-style-type: none"><li>• Speedometer</li><li>• Tachometer</li><li>• Engine coolant temperature gauge</li><li>• Fuel gauge</li></ul> <p><b>NOTE:</b> If any of the pointers does not sweep, replace combination meter.</p>
8	Color check	Performs the color check of the information display.
9	Error code	Displays the error code of the following items: <ul style="list-style-type: none"><li>• Speedometer</li><li>• Tachometer</li><li>• Engine coolant temperature gauge</li><li>• Fuel gauge</li><li>• Meter control switch</li></ul>
10	Warning/indicator lamp check	All warning/indicator lamps illuminate.

A

B

C

D

E

F

G

H

I

J

K

L

M


WCS

O

P

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >



Item	Code	Description	Action to take/Reference
(A) Speedometer	0	Normal	—
	1	A vehicle speed signal cannot be received from ABS actuator and electric unit (control unit).	Perform "Self Diagnostic Result" of "ABS." Refer to <a href="#">MWI-29, "DTC Index".</a>
	2	A vehicle speed signal received from the ABS actuator and electric unit (control unit) is abnormal.	Perform "Self Diagnostic Result" of "ABS." Refer to <a href="#">MWI-29, "DTC Index".</a>
(B) Tachometer	0	Normal	—
	1	An engine speed signal cannot be received from ECM.	Perform "Self Diagnostic Result" of "ECM." Refer to <a href="#">MWI-29, "DTC Index".</a>
(C) Fuel gauge	0	Normal	—
	1	Fuel gauge circuit is shorted.	Refer to <a href="#">MWI-54, "Component Function Check".</a>
	2	Fuel gauge circuit is open.	Refer to <a href="#">MWI-54, "Component Function Check".</a>
(D) Engine coolant temperature gauge	0	Normal	—
	1	An engine coolant temperature signal cannot be received from ECM.	Perform "Self Diagnostic Result" of "ECM." Refer to <a href="#">MWI-29, "DTC Index".</a>
(E) Meter control switch	0	Normal	—
	1	When judging that the illumination control switch signal circuit is shorted for 5 minutes or more.	Refer to <a href="#">MWI-52, "Diagnosis Procedure".</a>
	2	When judging that the trip reset switch signal circuit is shorted for 5 minutes or more.	
	3	When judging that both switch signal circuit are shorted for 5 minutes or more.	
(F)	—	0	Displays "0" constantly.
(G)	—	0	Displays "0" constantly.
(H)	—	0	Displays "0" constantly.

### How to Reset Error Code

Error codes stored in combination meter can be reset by following the instructions below:

1. Turn ignition switch OFF.
2. While pressing the trip reset switch, turn ignition switch ON.
3. Keep pressing the trip reset switch for 1 second or more.
4. Press the trip reset switch at least 3 times within 7 seconds after the ignition switch is turned ON.
5. Turn ignition switch OFF.
6. Perform self-diagnosis and check that the error codes are reset.

# DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

## CONSULT Function (METER/M&A)

INFOID:000000012228515

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown.

METER/M&A Diagnosis mode	Description
Self Diagnostic Result	Displays combination meter self-diagnosis results.
Data Monitor	Displays combination meter input/output data in real time.
Work support	Displays diagnosis procedure of each work item.
Warning History	Lighting history of the warning lamp and indicator lamp can be checked.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAG RESULT

Refer to [MWI-29, "DTC Index"](#).

### DATA MONITOR

#### Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER	X	Displays the value of vehicle speed signal.
SPEED OUTPUT [mph or km/h]	X	Vehicle speed signal value transmitted to other units via CAN communication.
ODO OUTPUT [mph or km/h]		Odometer signal value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM via CAN communication.
FUEL METER [L]	X	Fuel level indicated on combination meter.
W TEMP METER [°F] or [°C]	X	Displays the value of engine coolant temperature signal, which is input from ECM.
ABS W/L [On/Off]		Displays [ON/OFF] condition of ABS warning indicator.
VDC/TCS IND [On/Off]		Displays [ON/OFF] condition of VDC OFF indicator lamp.
SLIP IND [On/Off]		Displays [ON/OFF] condition of SLIP indicator lamp.
BRAKE W/L [On/Off]		Displays [ON/OFF] condition of brake warning indicator.
DOOR W/L [On/Off]		Displays [ON/OFF] condition of door warning message in the information display.
TRUNK/GLAS-H [On/Off]		Displays [ON/OFF] condition of trunk warning message in the information display.
HI-BEAM IND [On/Off]		Displays [ON/OFF] condition of high beam indicator.
TURN IND [On/Off]		Displays [ON/OFF] condition of turn indicator.
LIGHT IND [On/Off]		Displays [ON/OFF] condition of light indicator.
FR FOG IND [On/Off]		Displays [ON/OFF] condition of front fog lamp indicator.
OIL W/L [On/Off]		Displays [ON/OFF] condition of low oil pressure warning message in the information display.

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
MIL [On/Off]		Displays [ON/OFF] condition of malfunction indicator.
BA W/L [On/Off]		Displays [ON/OFF] condition of FEB warning lamp indicator.
ATC/T-AMT W/L [On/Off]		Displays [ON/OFF] condition of CVT error warning message in the information display.
SPORT IND [On/Off]		Displays [ON/OFF] condition of SPORT indicator in the information display.
FUEL W/L [On/Off]		Displays [ON/OFF] condition of low-fuel warning message in the information display.
WASHER W/L [On/Off]		Displays [ON/OFF] condition of low washer fluid warning message in the information display.
AIR PRES W/L [On/Off]		Displays [ON/OFF] condition of tire pressure warning lamp.
KEY G/Y W/L [On/Off]		Displays [ON/OFF] condition of key green warning lamp.
EPS W/L [On/Off]		Displays [ON/OFF] condition of EPS warning indicator.
LCD		Displays the value of Intelligent Key system message indication.
ACC TARGET [On/Off]		Displays [ON/OFF] condition of vehicle ahead detection indicator in the information display.
ACC DISTANCE [Off, Short, Middle, Long]		Displays [Off, Short, Middle, Long] condition of set distance indicator in the information display.
SHIFT IND [P, R, N, D]		Displays shift selector position.
FUEL CAP W/L [On/Off]		Displays [ON/OFF] condition of loose fuel cap warning message in the information display.
PKB SW [On/Off]		Displays [ON/OFF] condition of parking brake switch.
BUCKLE SW [On/Off]		Displays [ON/OFF] condition of seat belt buckle switch LH.
BRAKE OIL SW [On/Off]		Displays [ON/OFF] condition of brake fluid level switch.
DISTANCE [Mi] or [km]		Displays distance to empty.
OUTSIDE TEMP [°F or °C]		Displays the ambient air temperature which is input from the ambient sensor.
FUEL LOW SIG [On/Off]		Displays [ON/OFF] condition of low-fuel warning signal.
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter.
BATTERY CIRCUIT STATUS [Normal/Open]		Displays [Normal/Open] condition of battery power supply circuit.
TPMS PRESS L [On/Off]		Displays [ON/OFF] condition of tire pressure low message in the information display.
BSW IND [On/Off]		Displays [ON/OFF] condition of blind spot warning indicator.
CHASSIS CONTROL WARN [On/Off]		Displays [ON/OFF] condition of chassis control system error warning message in the information display.

## WORK SUPPORT

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

Work support item	Description
Outside air temperature diagnosis	A possible malfunction can be narrowed down by following the displayed instructions.
Fuel meter diagnosis (Analog pointer)	
Warning/Indicator lamp diagnosis	

## WARNING HISTORY

### Special menu

Display item	Description
W/L ON HISTORY	Lighting history of warning lamp and indicator lamp can be checked.

### W/L ON HISTORY

- “W/L ON HISTORY” indicates the “TIME” when the warning/indicator lamp is turned on.
- The “TIME” above is:
  - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
  - 1 - 39: The number of times the engine was restarted after the 0 condition.
  - NO W/L ON HISTORY: No warning/indicator lamp history is stored.

### NOTE:

- “W/L ON HISTORY” is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000012248766

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"><li>• The vehicle specification can be read and saved.</li><li>• The vehicle specification can be written when replacing BCM.</li></ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions:

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Trunk	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×	×			
TPMS	AIR PRESSURE MONITOR		×	×	×			

### FREEZE FRAME DATA (FFD)

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed at the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) at the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status at the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK").
	SLEEP>OFF		
	LOCK>ACC		
	ACC>ON		
	RUN>ACC		
	CRANK>RUN		
	RUN>URGENT		
	ACC>OFF		
	OFF>LOCK		
	OFF>ACC		
	ON>CRANK		
	OFF>SLEEP		
	LOCK>SLEEP		
	LOCK		
	OFF		
	ACC		
	ON		
	ENGINE RUN		
	CRANKING		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

### NOTE:

\*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

### BUZZER

#### BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:0000000012248768

### DATA MONITOR

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
PUSH -SW [On/Off]	Indicates condition of push button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TAIL LAMP SW [On/Off]	Indicates condition of combination switch.
FR FOG SW [On/Off]	Indicates condition of front fog lamp switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.

## ACTIVE TEST

Test Item	Description
SEAT BELT WARN TEST	This test is able to check seat belt warning chime operation [On/Off].
LIGHT WARN ALM	This test is able to check light warning chime operation [On/Off].
REVERSE WARNING	This test is able to check reverse warning chime operation [On/Off].

# BCM, COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### BCM, COMBINATION METER

#### List of ECU Reference

INFOID:000000012226832

ECU	Reference
BCM	<a href="#">BCS-31, "Reference Value"</a>
	<a href="#">BCS-51, "Fail_Safe"</a>
	<a href="#">BCS-52, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-53, "DTC Index"</a>
COMBINATION METER	<a href="#">MWI-23, "Reference Value"</a>
	<a href="#">MWI-28, "Fail-safe"</a>
	<a href="#">MWI-29, "DTC Index"</a>

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

# WARNING CHIME SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### WARNING CHIME SYSTEM

#### Wiring Diagram

INFOID:0000000012226833



AANWA1371GB

# WARNING CHIME SYSTEM

< WIRING DIAGRAM >

## WARNING CHIME SYSTEM CONNECTORS

Connector No.	M1	Connector No.	M5	Connector No.	M17
Connector Name	WIRE TO WIRE	Connector Name	FUSE BLOCK (J/B)	Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH80FW-CS16-TM4	Connector Type	NS16FW-CS	Connector Type	FEA09FW-FH46-SA
Connector Color	WHITE	Connector Color	WHITE	Connector Color	WHITE
					
Terminal No.	8P	Color of Wire	BR	Terminal No.	132
	13P		G		135
					138
					142
Connector No.	M6	Color of Wire	W	Signal Name	
Connector Name	WIRE TO WIRE			No.	
Connector Type	TH80FDGY-CS16-TM4				
Connector Color	GRAY				
					
Terminal No.	5G	Color of Wire	P	Signal Name	
	29G		LG	No.	
Connector No.	M3	Color of Wire	P	Signal Name	
Connector Name	FUSE BLOCK (J/B)			No.	
Connector Type	CS06FW-M2				
Connector Color	WHITE				
					
Terminal No.	73J	Color of Wire	P	Signal Name	
	82J		LG	No.	

AANIA3950GB

# WARNING CHIME SYSTEM

**< WIRING DIAGRAM >**

---

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH
Connector Color	BLACK




Connector No.	M23
Connector Name	COMBINATION METER
Connector Type	TH16FW-NH
Connector Color	WHITE



Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH
Connector Color	GREEN




Connector No.	M28
Connector Name	COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH)
Connector Type	TH16FW-NH
Connector Color	WHITE



H.S.

Terminal No.	Color of Wire	Signal Name	Signal Name	Signal Name
43	B	CAN-L	GND1	-
44	BR	CAN-H	POWER (IGN)	-
45	B	COMBI SW OUT 5	GND2	-
46	G	COMBI SW OUT 4	POWER (BAT)	-
52	P	COMBI SW OUT 3	CAN-L	-
53	L	COMBI SW OUT 2	CAN-H	-
78	P	COMBI SW OUT 1	-	-
79	G	COMBI SW OUT 1	-	-




H.S.

Connector No.	M21
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Connector No.	M24
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



H.S.

Connector No.	M28
Connector Name	COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH)
Connector Type	TH16FW-NH
Connector Color	WHITE




H.S.

Terminal No.	Color of Wire	Signal Name	Signal Name
26	v	COMBI SW IN 5	PKB SW
28	LG	COMBI SW IN 4	SEAT BELT SW (DR)
10	W	COMBI SW IN 3	-
11	BR	COMBI SW IN 2	-
12	R	COMBI SW IN 1	-
13	G	-	-
14	P	-	-

# WARNING CHIME SYSTEM

< WIRING DIAGRAM >




AANIA3952GB

# WARNING CHIME SYSTEM

< WIRING DIAGRAM >

---

Connector No.	B202
Connector Name	SEAT BELT BUCKLE SWITCH LH
Connector Type	TH04FW-NH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

AANIA4147GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000012226834

#### OVERALL SEQUENCE



A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

#### DETAILED FLOW

##### 1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

##### 2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check if any other malfunctions are present.

>> GO TO 3.

##### 3. CHECK CONSULT SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [MWI-29, "DTC Index"](#).

O

P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

Is the inspection result normal?

YES    >> GO TO 4.

NO    >> GO TO 5.

## 4. NARROW DOWN MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Refer to [WCS-31, "Symptom Table"](#).

>> GO TO 5.

## 5. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace malfunctioning parts.

**NOTE:**

If DTC is displayed, erase DTC after repairing or replacing malfunctioning parts.

>> GO TO 6.

## 6. FINAL CHECK

Check that the warning buzzer in the combination meter operates normally.

Is the inspection result normal?

YES    >> Inspection End.

NO    >> GO TO 2.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

#### COMBINATION METER : Diagnosis Procedure

INFOID:0000000012228516

Regarding Wiring Diagram information, refer to [MWI-31. "Wiring Diagram"](#).

#### 1. CHECK FUSES

Check that the following fuses are not blown:

Unit	Power source	Fuse No.
Combination meter	Battery	13
	Ignition switch ON or ACC	21
	Ignition switch ON or START	31

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect combination meter harness connectors M23 and M24.
2. Check voltage between combination meter harness connectors M23 and M24 and ground.

Combination meter		Ground	Ignition switch position		
Connector	Terminal		OFF	ON or ACC	START
M24	14	(-)	0 V	Battery voltage	Battery voltage
M23	44		0 V	Battery voltage	Battery voltage
	46		Battery voltage	Battery voltage	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connector.

#### 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between combination meter harness connector M23, M24 and ground.

Combination meter		Ground	Continuity	WCS
Connector	Terminal			
M24	10	(-)	Yes	WCS
M23	43			
	45			

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connector.

#### BCM (BODY CONTROL MODULE)

#### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:0000000012228517

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Regarding Wiring Diagram information, refer to [BCS-56, "Wiring Diagram".](#)

## 1. CHECK FUSE AND FUSIBLE LINK

Check if the following BCM fuses or fusible link are blown.

Signal name	Fuse and fusible link No.
Fusible link battery power	I (40A)
BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.  
NO >> GO TO 2.

## 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector M17.
3. Check voltage between BCM harness connector M17 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM	Ground	Battery voltage
Connector Terminal		
M17 135	Ground	Battery voltage
142		

Is the measurement normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector M17 and ground.

BCM		Continuity
Connector	Terminal	
M17	138	Yes
	132	

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness.

# METER BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## METER BUZZER CIRCUIT

### Component Function Check

INFOID:0000000012226837

#### 1. CHECK OPERATION OF METER BUZZER

##### CONSULT

1. Select "BUZZER" of "BCM".
2. Select "LIGHT WARN ALM" in "Active Test" mode.

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [WCS-27. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012226838

#### 1. CHECK POWER SUPPLY OF COMBINATION METER

Check power supply of combination meter. Refer to [WCS-25. "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-68. "Removal and Installation"](#).

NO >> Repair power supply circuit of combination meter.

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

### Component Function Check

INFOID:0000000012226839

#### 1. CHECK COMBINATION METER INPUT SIGNAL

##### CONSULT

1. Select "Data Monitor" mode of "METER/M&A".
2. Select "BUCKLE SW".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
BUCKLE SW	When seat belt LH is fastened	OFF
	When seat belt LH is unfastened	ON

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [WCS-28, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012226840

Regarding Wiring Diagram information, refer to [WCS-18, "Wiring Diagram"](#).

#### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector M24 terminal 28 and ground.

Combination meter			Condition	Voltage (Approx.)
Connector	Terminals			
M24	28	Ground	When driver seat belt is fastened	Battery voltage
			When driver seat belt is unfastened	0 V

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-68, "Removal and Installation"](#).  
NO >> GO TO 2.

#### 2. CHECK SEAT BELT BUCKLE SWITCH LH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector M24 and seat belt buckle switch LH harness connector B202.
3. Check continuity between combination meter harness connector M24 terminal 28 and seat belt buckle switch LH harness connector B202 terminal 1.

Combination meter		Seat belt buckle switch LH		Continuity
Connector	Terminal	Connector	Terminal	
M24	28	B202	1	Yes

4. Check continuity between combination meter harness connector M24 terminal 28 and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	28		No

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connector.

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 3. CHECK SEAT BELT BUCKLE SWITCH LH GROUND CIRCUIT

Check harness continuity between seat belt buckle switch LH harness connector B202 terminal 2 and ground.

Seat belt buckle switch LH		Ground	Continuity
Connector	Terminal		
B202	2		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connector.

## Component Inspection

INFOID:0000000012226841

### 1. CHECK SEAT BELT BUCKLE SWITCH LH

1. Turn ignition switch OFF.
2. Disconnect the seat belt buckle switch LH connector.
3. Check continuity between the seat belt buckle switch LH terminals 1 and 2.

Condition	Terminals	Continuity
When seat belt buckle LH is fastened	1– 2	No
When seat belt buckle LH is unfastened		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the seat belt buckle switch LH. Refer to [SB-10, "FRONT SEAT BELT BUCKLE : Removal and Installation".](#)

# PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PARKING BRAKE SWITCH SIGNAL CIRCUIT

### Component Function Check

INFOID:0000000012226842

#### 1. COMBINATION METER INPUT SIGNAL

##### (E) CONSULT

1. Select "Data Monitor" mode of "METER/M&A".
2. Select "PKB SW".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
PKB SW	When parking brake is applied	ON
	When parking brake is released	OFF

Is the inspection result normal?

- YES    >> Inspection End.  
NO    >> Refer to [WCS-30, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012226843

Regarding Wiring Diagram information, refer to [WCS-18, "Wiring Diagram"](#).

#### 1. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Disconnect combination meter harness connector M24 and parking brake switch harness connector E35.
2. Check continuity between combination meter harness connector M24 terminal 26 and parking brake switch harness connector E35 terminal 1.

Combination meter		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
M24	26	E35	1	Yes

3. Check continuity between combination meter harness connector M24 terminal 26 and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	26		No

Is the inspection result normal?

- YES    >> Inspection End.  
NO    >> Repair or replace harness or connector.

### Component Inspection

INFOID:0000000012226844

#### 1. CHECK PARKING BRAKE SWITCH

Check continuity between parking brake switch terminal 1 and switch case ground.

Component	Terminal	Condition	Continuity
Parking brake switch	1	Parking brake applied	Yes
		Parking brake released	No

Is the inspection result normal?

- YES    >> Inspection End.  
NO    >> Replace parking brake switch. Refer to [PB-11, "Removal and Installation"](#).

## WARNING CHIME SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

### SYMPTOM DIAGNOSIS

#### WARNING CHIME SYSTEM SYMPTOMS

##### Symptom Table

INFOID:000000012226845

**CAUTION:**  
Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
The light reminder warning does not sound.	<ul style="list-style-type: none"><li>• Harness between BCM and front door switch LH.</li><li>• Front door switch LH</li><li>• BCM</li><li>• Combination meter</li></ul>	Refer to <a href="#">WCS-32</a> .
The parking brake release warning continues sounding or does not sound.	<ul style="list-style-type: none"><li>• Harness between combination meter and parking brake switch.</li><li>• Parking brake switch</li><li>• BCM</li><li>• Combination meter</li></ul>	Refer to <a href="#">WCS-34</a> .
The seat belt warning continues sounding or does not sound.	<ul style="list-style-type: none"><li>• Harness between combination meter and seat belt buckle switch LH.</li><li>• Seat belt buckle switch LH</li><li>• BCM</li><li>• Combination meter</li></ul>	Refer to <a href="#">WCS-33</a> .
Warning chime does not sound at all.	Combination meter	Refer to <a href="#">WCS-27</a> .

# THE LIGHT REMINDER WARNING DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

## THE LIGHT REMINDER WARNING DOES NOT SOUND

### Description

INFOID:0000000012226846

Light reminder warning does not sound even though headlamp is illuminated.

### Diagnosis Procedure

INFOID:0000000012226847

#### 1. CHECK COMBINATION SWITCH (LIGHTING SWITCH) OPERATION

Check that the headlamps operate normally by operating the combination switch (lighting switch).

Do they operate normally?

YES >> GO TO 2.

NO >> Refer to [EXL-95, "Symptom Table"](#) (with LED headlamps) or [EXL-213, "Symptom Table"](#) (with halogen headlamps).

#### 2. CHECK FRONT DOOR SWITCH LH SIGNAL CIRCUIT

Check the front door switch LH signal circuit. Refer to [DLK-98, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

#### 3. CHECK FRONT DOOR SWITCH LH

Check the front door switch LH. Refer to [DLK-99, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-82, "Removal and Installation"](#).

NO >> Replace front door switch LH. Refer to [DLK-197, "Removal and Installation"](#).

# THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

## THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

### Description

INFOID:000000012226848

- Seat belt warning does not sound even though driver seat belt is not fastened.
- Seat belt warning sounds even though driver seat belt is fastened.

### Diagnosis Procedure

INFOID:000000012226849

#### 1. CHECK WARNING CHIME OPERATION

##### CONSULT

1. Select "BUZZER" of "BCM".
2. Select "SEAT BELT WARN TEST" in "Active Test" mode.
3. Touch "ON/OFF" to check that the function operates normally.

Component	CONSULT	Condition
Buzzer	SEAT BELT WARN TEST	ON
		OFF

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-68, "Removal and Installation"](#).

#### 2. CHECK COMBINATION METER INPUT SIGNAL

Check the combination meter input signal. Refer to [WCS-28, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-82, "Removal and Installation"](#).

NO >> GO TO 3.

#### 3. CHECK SEAT BELT BUCKLE SWITCH LH CIRCUIT

Check the seat belt buckle switch LH circuit. Refer to [WCS-28, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connector.

#### 4. CHECK SEAT BELT BUCKLE SWITCH LH

Check the seat belt buckle switch LH. Refer to [WCS-29, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the combination meter. Refer to [MWI-68, "Removal and Installation"](#).

NO >> Replace the seat belt buckle switch LH. Refer to [SR-33, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

WCS

O

P

# THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

## THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

### Description

INFOID:0000000012226850

- The parking brake warning buzzer sounds continuously during vehicle travel, even though the parking brake is released.
- The parking brake warning buzzer does not sound at all, even while driving the vehicle with the parking brake applied.

### Diagnosis Procedure

INFOID:0000000012226851

#### 1. CHECK PARKING BRAKE WARNING LAMP

1. Start the engine.
2. Check the operation of the brake warning lamp by operating the parking brake.

Condition	Warning lamp status
Parking brake applied	ON
Parking brake released	OFF

Is the inspection result normal?

- YES    >> Replace the combination meter. Refer to [MWI-68, "Removal and Installation"](#).  
NO     >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

Check the parking brake switch signal circuit. Refer to [WCS-30, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES    >> GO TO 3.  
NO     >> Repair or replace harness or connector.

#### 3. CHECK PARKING BRAKE SWITCH UNIT

Check the parking brake switch. Refer to [WCS-30, "Component Inspection"](#).

Is the inspection result normal?

- YES    >> Replace the combination meter. Refer to [MWI-68, "Removal and Installation"](#).  
NO     >> Replace the parking brake switch. Refer to [PB-11, "Removal and Installation"](#).