

ALPHABETICAL INDEX

SECTION **IDX**

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ALPHABETICAL INDEX

A

ABS (anti-lock brake system) BR-23
 ABS - Wiring diagram BR-32
 Absolute pressure sensor..... EC-110
 A/C air flow..... HA-17
 A/C component layout..... HA-16
 A/C compressor clutch removal and
 installation..... HA-133
 A/C compressor description..... HA-12
 A/C compressor mounting HA-132
 A/C compressor precaution HA-6
 A/C compressor special service tool HA-6
 A/C control linkage adjustment (auto
 A/C)..... HA-113
 A/C control operation (auto A/C)..... HA-60
 A/C control operation (manual A/C)..... HA-18
 A/C diagnostic work flow (auto A/C) HA-64
 A/C diagnostic work flow (manual A/C) HA-21
 A/C harness layout (auto A/C)..... HA-88
 A/C harness layout (manual A/C) HA-37
 A/C HFC134a (R134a) system
 precaution..... HA-2
 A/C HFC134a (R134a) system service
 procedure..... HA-125
 A/C HFC134a (R134a) system service
 tools..... HA-7
 A/C HFC134a system service equip-
 ment precaution..... HA-9
 A/C lubricant (R134a) HA-127
 A/C operational check (auto A/C) HA-65
 A/C operational check (manual A/C) HA-22
 A/C performance chart..... HA-33
 A/C performance test diagnoses HA-31
 A/C relay..... HA-57, 112
 A/C self-diagnoses (auto A/C) HA-70
 A/C service data specification..... HA-139
 A/C switch HA-56
 A/C symptom chart (auto A/C)..... HA-68
 A/C symptom chart (manual A/C) HA-24
 A/C system description (auto A/C)..... HA-114
 A/C trouble diagnoses (auto A/C)..... HA-62
 A/C trouble diagnoses (manual A/C) HA-20
 A/C, A - Wiring diagram HA-91
 A/C, M - Wiring diagram HA-40
 Accelerator control system FE-2
 Accelerator wire adjustment FE-2
 Air bag RS-5
 Air bag disposal RS-13
 Air bleeding (hydraulic clutch) CL-5
 Air bleeding for brake system BR-5
 Air cleaner filter replacement..... MA-13
 Air conditioner cut control EC-19
 Air flow meter - See Mass air flow
 sensor..... EC-104
 Air mix door control linkage adjustment
 (auto A/C)..... HA-113
 Air mix door control linkage adjustment
 (manual A/C)..... HA-58

Air mix. door motor..... HA-118
 Air spoiler, rear BT-22
 Alternator EL-40
 Ambient sensor..... HA-116
 Angular tightening application EM-2
 Antenna..... EL-132
 Anti-lock brake system - See ABS..... BR-23
 Anti-lock brake system - Wiring
 diagram..... BR-32
 ASCD (automatic speed control device) EL-146
 ASCD - Wiring diagram EL-151
 A/T - Wiring diagram AT-11
 A/T control..... EC-265
 AT control unit AT-55
 A/T diagnosis communication line EC-337
 AT fluid temperature sensor..... AT-67
 AT removal and installation..... AT-141
 AT self-diagnoses AT-26
 AT shift lock system AT-131
 A/T shift lock system - Wiring diagram AT-132
 Audio..... EL-125
 AUDIO - Wiring diagram..... EL-127
 Audio and A/C control removal and
 installation - See Instrument panel BT-13
 Auto air conditioner - Wiring diagram HA-91
 Automatic speed control system - See
 ASCD EL-146
 Automatic transmission fluid
 replacement..... MA-18
 Auxiliary air control (AAC) valve EC-255

B

Back-up lamp..... EL-60
 Back-up lamp switch (MT) MT-7
 BACK/L - Wiring diagram EL-60
 Battery..... EL-24
 Baulk ring (MT)..... MT-11
 Blower motor HA-56, 112
 Blower resistor HA-56
 Board-on lift GI-39
 Body alignment..... BT-37
 BPT valve EC-221
 Brake booster..... BR-9
 Brake control valve (Proportioning
 valve)..... BR-4
 Brake fluid change BR-5
 Brake fluid level MA-19
 Brake fluid level and line check BR-5
 Brake hydraulic line..... BR-3
 Brake inspection MA-19
 Brake lines and cables inspection..... MA-19
 Brake master cylinder BR-7
 Brake pedal BR-6
 Bumper, front BT-6
 Bumper, rear BT-9
 BUZZER - Wiring diagram..... EL-94

ALPHABETICAL INDEX

C

Camshaft inspection	EM-37
Camshaft position sensor (CMPS)	EC-205
Camshaft position sensor (PHASE).....	EC-205
Canister-See EVAP canister	EC-21
CHARGE - Wiring diagram.....	EL-37
Charging system.....	EL-36
Chassis and body maintenance	MA-17
Cigarette lighter.....	EL-114
Circuit breaker	EL-19
Clock	EL-114
Closed loop control	EC-139
Closed throttle position switch	EC-261
Clutch cover.....	CL-9
Clutch disc	CL-9
Clutch fluid level	MA-17
Clutch master cylinder.....	CL-6
Clutch operating cylinder.....	CL-7
Clutch pedal.....	CL-4
Clutch release bearing	CL-8
Clutch withdrawal lever	CL-8
Coil spring (front).....	FA-21
Coil spring (rear)	RA-10
Collision diagnosis	RS-36
Combination lamp, front, removal and installation	BT-6
Combination lamp, rear, removal and installation	BT-22
Combination meter	EL-80
Combination meter removal and installation - See Instrument panel.....	BT-13
Combination switch.....	EL-41
COMM - Wiring diagram.....	EL-197
Compression pressure.....	EM-10
Compressor clutch removal and installation.....	HA-133
Compressor description	HA-12
Compressor mounting.....	HA-132
Compressor precaution.....	HA-6
Compressor special service tool.....	HA-6
Connecting rod	EM-56
Connecting rod bearing clearance	EM-60
Connecting rod bushing clearance.....	EM-61
Console box - See Instrument panel.....	BT-13
CONSULT for ABS	BR-39
CONSULT for ECCS	EC-59
CONSULT general information.....	GI-34
Control lever (MT).....	MT-9
Control valve (AT)	AT-168
Converter housing installation.....	AT-142
Coolant mixture ratio	MA-9
Coolant replacement.....	MA-11
Cooling circuit (engine).....	LC-8
Cooling fan control	EC-340
Cooling fan control system.....	LC-15
Cooling fan motor.....	EC-352
Cooling fan relay	EC-352
Coupling sleeve (MT)	MT-11

Crankshaft.....	EM-58
Crankshaft position sensor (POS)	EC-199
Crankshaft position sensor (POS) chipping	EC-303
Crankshaft position sensor (REF).....	EC-298
Cruise control - See ASCD.....	EL-146
Cylinder block	EM-54
Cylinder head.....	EM-34
Cylinder head bolt tightening.....	EM-43

D

Daytime light system	EL-47
Daytime running light - See Daytime light system	EL-47
DEF - Wiring diagram	EL-117
Detonation sensor - See Knock sensor.....	EC-196
Diagnosis sensor unit.....	RS-8
Differential gear (FF AT).....	AT-211, 215
Differential gear (FF MT).....	MT-11, 25
Direct ignition system.....	EC-29
Distributor ignition (DI) system.....	EC-18
D/LOCK - Wiring diagram.....	EL-223
Door lock.....	BT-11
Door mirror.....	BT-36
Door trim	BT-19
Door, front	BT-11
Door, rear.....	BT-12
Drive belt inspection	MA-10
Drive plate runout	EM-61
Drive shaft (front).....	FA-12
Dropping resistor (AT).....	AT-96
DTRL - Wiring diagram.....	EL-49

E

ECCS basic inspection	EC-78
ECCS circuit diagram.....	EC-9
ECCS component parts location	EC-11
ECCS on board diagnostic system.....	EC-38
ECCS system diagram and chart	EC-10
ECM input/output signal.....	EC-91
EGR control (EGRC) - BPT valve.....	EC-220
EGR control (EGRC) - solenoid valve	EC-309
EGR control valve	EC-218
EGR temperature sensor	EC-314
EGR valve & EVAP canister purge con- trol solenoid valve.....	EC-313
Electric sun roof.....	EL-140
Electrical load signal circuit.....	EC-376
Electrical unit	Foldout
Electronic ignition system	EC-18
Engine compartment.....	BT-37
Engine control module (ECM).....	EC-269
Engine coolant temperature sensor (ECTS).....	EC-123, 134
Engine mounting control (Front)	EC-365
Engine oil filter replacement.....	MA-14

ALPHABETICAL INDEX

Engine oil replacement.....	MA-14
Engine outer component parts	EM-6
Engine removal.....	EM-51
Engine room - See Engine compartment	BT-37
EVAP canister	EC-21
EVAP canister purge control valve	EC-233
EVAP canister purge volume control valve	EC-323
EVAP canister vent control valve.....	EC-241
EVAP control system (small leak) diagnosis.....	EC-225
EVAP control system purge flow monitoring diagnosis.....	EC-330
EVAP vapor lines inspection.....	MA-16
Evaporative emission (EVAP) system.....	EC-21
Exhaust system	FE-4
Exhaust system inspection	MA-17
Exterior.....	BT-22
Exterior lamp.....	EL-56

F

Fan control amp.	HA-123
Fan switch.....	HA-56
Fast idle cam (FIC) inspection and adjustment	EC-28
F/FOG - Wiring diagram	EL-62
Final drive (FF AT)	AT-211, 215
Final drive (FF MT)	MT-11, 25
Finisher, interior - See Trim	BT-16
Floor trim.....	BT-16
Fluid temperature sensor (AT)	AT-67
Fluids	MA-8
Flywheel (clutch).....	CL-10
Flywheel runout	EM-61
Fog lamp, front	EL-61
Fog lamp, front, removal and installation	BT-6
Fork rod (MT)	MT-12
Forward clutch.....	AT-189
Freeze frame data.....	EC-40
Front axle	FA-8
Front bumper	BT-6
Front combination lamp removal and installation	BT-6
Front disc brake.....	BR-11
Front door.....	BT-11
Front engine mounting control	EC-365
Front fog lamp	EL-61
Front fog lamp removal and installation	BT-6
Front heated oxygen sensor (HO2S).....	EC-141
Front heated oxygen sensor (HO2S) (Left bank)	EC-159
Front heated oxygen sensor (HO2S) (Right bank)	EC-141
Front heated oxygen sensor (HO2S) monitor.....	EC-50, 53
Front heated oxygen sensor heater (Left bank)	EC-165

Front heated oxygen sensor heater (Right bank).....	EC-146
Front passenger air bag.....	RS-5
Front seat.....	BT-27
Front seat belt	RS-3
Front suspension	FA-20
Front washer	EL-102
Front wiper.....	EL-102
Fuel cut control (at no load & high engine speed).....	EC-20
Fuel filler lid	BT-9
Fuel filter replacement	MA-12
Fuel gauge	EL-81
Fuel injection system (Left bank).....	EC-179, 184
Fuel injection system (Right bank)	EC-169, 174
Fuel lid opener, electric	EL-145
Fuel line inspection	MA-12
Fuel pressure check.....	EC-26
Fuel pressure release	EC-26
Fuel pump	EC-364
Fuel pump control module	EC-283, 360
Fuel pump relay	EC-364
Fuel system	FE-3
Fuse	EL-19
Fuse block	Foldout
Fusible link.....	EL-19

G

Garage jack and safety stand	GI-40
Gauges	EL-79
Gears (MT)	MT-11
Generic scan tool (GST)	EC-72
Ground distribution	EL-20

H

Harness connector.....	EL-3
Harness layout	EL-311
Hazard warning lamp.....	EL-64
Headlamp.....	EL-44
Headlamp removal and installation	BT-6
Headlining - See Roof trim	BT-20
Heated oxygen sensor (HO2S) (front).....	EC-141
Heated oxygen sensor (HO2S) (Front) (Left bank)	EC-159
Heated oxygen sensor (HO2S) (Front) (Right bank).....	EC-141
Heated oxygen sensor (HO2S) monitor	EC-53
Heated oxygen sensor (rear)	EC-150
Heated oxygen sensor heater (Front)(Left bank).....	EC-165
Heated oxygen sensor heater (Fron- t)(Right bank).....	EC-146
Heated oxygen sensor monitor (HO2S) (front).....	EC-53
Heated seat.....	BT-29, EL-143
HFC134a (R134a) system precaution	HA-2

ALPHABETICAL INDEX

HFC134a (R134a) system service procedure.....	HA-125
HFC134a (R134a) system service tools	HA-7
HFC134a system service equipment precaution.....	HA-9
High clutch.....	AT-185
H/LAMP - Wiring diagram.....	EL-45
Hood	BT-6
Horn.....	EL-114
HORN - Wiring diagram.....	EL-114
How to erase DTC for ECCS OBD system	EC-48
HSEAT - Wiring diagram	EL-143

I

IACV - FICD solenoid valve.....	EC-375
IACV-AAC valve.....	EC-260
IACV-FICD solenoid valve	EC-373
Idle air control valve (IACV).....	EC-255
Idle mixture ratio	EC-31
Idle speed.....	EC-31
Ignition coil	EC-297
Ignition timing	EC-31
ILL - Wiring diagram	EL-73
Illumination.....	EL-71, 287
In vehicle sensor	HA-115
Inhibitor switch.....	AT-63
Injector.....	EC-357
Injector removal and installation	EC-27
Input shaft.....	MT-11, 16
Instrument panel.....	BT-13
INT/L - Wiring diagram	EL-77
Intake air temperature sensor.....	EC-117
Intake door control linkage adjustment (auto A/C).....	HA-113
Intake door control linkage adjustment (manual A/C).....	HA-58
Intake door motor.....	HA-122
Intake manifold	EM-8
Integrated homelink transmitter.....	EL-305
Interior.....	BT-16
Interior lamp.....	EL-71
Interior lamp on-off control.....	EL-291
IVMS (In-Vehicle Multiplexing System)	EL-170
IVMS-System description	EL-170
IVMS-Trouble diagnoses	EL-197
IVMS-Trouble diagnoses system.....	EL-185

J

Jacking points.....	GI-40
Junction box (J/B)	Foldout

K

Key illumination.....	EL-291
-----------------------	--------

Keyless entry system - See Multi-remote control system.....	EL-240
Knock sensor (KS)	EC-196

L

License lamp.....	EL-56	GI
Lifting points	GI-41	MA
Line pressure solenoid valve.....	AT-85, 93, 96	EM
Line pressure test (AT).....	AT-129	EM
Liquid gasket application	EM-2	EM
Location of electrical units	EL-307	LC
Lock, door	BT-11	LC
Low and reverse brake	AT-195	LC
Lubricant (R134a) A/C	HA-127	EC
Lubricants	MA-8	EC
Lubrication circuit (engine)	LC-4	EC
Lubrication-locks, hinges and hood latches.....	MA-21	FE

M

Magnet clutch.....	HA-133	MT
Main drive gear (MT).....	MT-11	MT
Mainshaft (MT)	MT-11, 21	MT
Maintenance	MA-1	AT
Maintenance (engine)	MA-10	AT
Malfunction indicator lamp (MIL).....	EC-50	FA
Manual air conditioner - Wiring diagram.....	HA-40	FA
Manual transmission oil replacement.....	MA-17	FA
MAP/BARO switch solenoid valve	EC-277	RA
Mass air flow sensor (MAFS).....	EC-104	RA
Master cylinder (brake)	BR-7	BR
Master cylinder (clutch)	CL-6	BR
Meter.....	EL-79	BR
METER - Wiring diagram	EL-81	BR
MIL & Data link connectors circuit	EC-379	ST
MIRROR - Wiring diagram	EL-144	ST
Mirror, door	BT-36	ST
Mirror, out side.....	BT-36	ST
Misfire.....	EC-192	RS
Mode door control linkage adjustment (auto A/C).....	HA-113	BT
Mode door control linkage adjustment (manual A/C).....	HA-57	BT
Mode door motor.....	HA-120	HA
Molding - See Exterior.....	BT-22	HA
MT removal and installation.....	MT-7	HA
Mud guard - See Exterior	BT-22	HA
MULTI - Wiring diagram.....	EL-243	EL
Multi-remote control system	EL-240	EL
Multipoint fuel injection (MFI) system.....	EC-16	EL

N

Neutral position switch (MT)	MT-7
------------------------------------	------

ALPHABETICAL INDEX

O

Oil pan (engine)	EM-11
Oil pressure (engine)	LC-5
Oil pump (AT)	AT-164
Oil pump (engine)	LC-5
Oil pump regulator valve (engine)	LC-7
Oil seal replacement (engine)	EM-31
Operating cylinder (clutch)	CL-7
Out side mirror	BT-36
Overdrive control switch	AT-63
Overrun clutch	AT-189
Overrun clutch solenoid valve	AT-85, 93, 107
Oxygen sensor monitor (O2S) (front)	EC-53

P

P/ANT - Wiring diagram	EL-133
Park/Neutral position switch	EC-272
Parking brake control	BR-21
Parking lamp	EL-56
PCV (positive crankcase ventilation)	EC-25
PHONE - Wiring diagram	EL-139
Piston assembly	EM-62
Piston pin inspection	EM-55
Piston ring inspection	EM-56
Piston to bore clearance	EM-57
POWER - Wiring diagram	EL-7
Power antenna	EL-132
Power door lock	EL-221
Power door mirror	EL-144
Power seat	EL-141
Power steering fluid level	MA-20, ST-5
Power steering gear	ST-12
Power steering hydraulic pressure	ST-7
Power steering oil pressure switch	EC-368, 372
Power steering oil pump	ST-22
Power steering system bleeding	ST-5
Power supply routing	EL-6
Power transistor	EC-297
Power transistor & ignition coil	EC-290
Power window	EL-206
Pressure plate - See Clutch cover	CL-9
Pressure test (AT)	AT-129

R

Radiator	LC-15
Radio - See Audio	EL-125
Rear air spoiler	BT-22
Rear axle	RA-6
Rear bumper	BT-9
Rear disc brake	BR-15
Rear door	BT-12
Rear heated oxygen sensor (HO2S)	EC-150
Rear heated oxygen sensor (HO2S) heater	EC-154

Rear seat	BT-30
Rear seat belt	RS-4
Rear suspension	RA-9
Rear window	BT-35
Rear window defogger	EL-116
Refrigerant connection precaution	HA-3
Refrigerant general precaution	HA-2
Refrigerant lines	HA-129
Release bearing (clutch)	CL-8
Reverse clutch	AT-182
Reverse gear (MT)	MT-11
Reverse idler shaft (MT)	MT-11
Reverse lamp switch (MT) - See Back-up lamp switch (MT)	MT-7
Revolution sensor (AT)	AT-69
Road wheel size	GI-38
Roof trim	BT-20
ROOM/L - Wiring diagram	EL-292

S

SAE J1979 - Mode 1 ~ 7	EC-38, 73
Seal - See Exterior	BT-22
SEAT - Wiring diagram	EL-141
Seat belt inspection	MA-21
Seat belt, front	RS-3
Seat belt, rear	RS-4
Seat, front	BT-27
Seat, rear	BT-30
Self-diagnostic results	EC-50
SHIFT - Wiring diagram	AT-132
Shift control (MT)	MT-12
Shift fork (MT)	MT-12
Shift lock system	AT-131
Shift schedule	AT-49
Shift solenoid valve (AT)	AT-73, 76, 79, 85, 93, 99, 102
Shock absorber (rear)	RA-10
Side trim	BT-16
SMJ (super multiple junction)	Foldout
Spark plug replacement	MA-15
Speedometer	EL-81
Spiral cable	RS-8
Spot lamp	EL-77
Spring (Wheelarch) height	FA-5
SROOF - Wiring diagram	EL-140
SRS - See Supplemental Restraint System	RS-5
SRS - Wiring diagram	RS-20
SRS Trouble diagnoses	RS-17
Stabilizer bar (front)	FA-22
Stall test (AT)	AT-126
Standardized relay	EL-4
START - Wiring diagram	EL-30
Starter	EL-35
Starting system	EL-28
Steering gear and linkage inspection	MA-20
Steering linkage	ST-12
Steering switch	EL-43
Steering wheel and column	ST-8

ALPHABETICAL INDEX

Steering wheel play	ST-4
Steering wheel turning force.....	ST-6
Step lamp.....	EL-299
STEP/L - Wiring diagram.....	EL-300
Stop lamp.....	EL-58
STOP/L - Wiring diagram	EL-58
Striking rod (MT)	MT-12
Strut (front).....	FA-21
Sunload sensor.....	HA-116
Sunroof	BT-31
Supplemental Restraint System.....	RS-5
Supplemental restraint system - Wiring diagram.....	RS-20
SW/ILL - Wiring diagram	EL-288
Synchronizer (MT).....	MT-11
System readiness test (SRT) code.....	EC-40

T

2-pole lift.....	GI-41
Tachometer	EL-81
Tail lamp.....	EL-56
TAIL/L - Wiring diagram.....	EL-56
Tank fuel temperature sensor	EC-189
Telephone	EL-139
THEFT - Wiring diagram.....	EL-266
Theft warning system	EL-260
Thermostat.....	LC-14
Three way catalyst.....	EC-222
Three way catalyst function (Left bank).....	EC-222
Three way catalyst function (Right bank).....	EC-222
Throttle bodies	EM-8
Throttle position sensor (TPS).....	EC-128
Throttle position switch.....	AT-64
Throwout bearing - See Clutch release bearing.....	CL-8
Tie-rod.....	ST-16
Tie-rod ball joints	ST-16
Timing chain.....	EM-17
Tire rotation.....	MA-19
Tire size	GI-38
TLID - Wiring diagram	EL-145
Torque converter clutch solenoid valve	AT-85, 88, 93
Torque converter installation	AT-141
Tow truck towing.....	GI-42
Transmission case (MT).....	MT-10
TRANSMT - Wiring diagram.....	EL-305
Transverse link (front).....	FA-23
Trim	BT-16
Triple pressure switch	HA-11, 57, 112
Trunk lid	BT-9
Trunk lid opener - See Trunk lid.....	BT-9
Trunk lid opener, electric	EL-145
Trunk room lamp.....	EL-77
Trunk room trim	BT-21

TURN - Wiring diagram.....	EL-66
Turn signal lamp	EL-64
Two trip detection logic	EC-38

U

Under body	BT-39
------------------	-------

V

Vacuum cut valve.....	EC-322
Vacuum cut valve bypass valve.....	EC-318
Vacuum hose (brake system)	BR-10
Vacuum hose drawing (ECCS)	EC-14
Valve clearance.....	EM-47
Valve guide	EM-38
Valve seat	EM-40
Valve spring	EM-40
Vehicle recovery (freeing a stuck vehicle).....	GI-42
Vehicle speed sensor (VSS)	EC-251
Viscosity number (SAE).....	MA-8
Viscous coupling (FF AT).....	AT-215
Viscous coupling (FF MT).....	MT-7, 11

W

WARN - Wiring diagram	EL-88
Warning buzzer.....	EL-93
Warning lamps.....	EL-87
Washer, front.....	EL-102
Water pump.....	LC-9
Water temperature gauge.....	EL-81
Weatherstrip - See Exterior.....	BT-22
Wheel alignment (front)	FA-6
Wheel alignment (rear)	RA-5
Wheel balance	MA-19
Wheel bearing (front axle).....	FA-6
Wheel bearing (rear)	RA-4
Wheel hub (rear).....	RA-6
Wheel hub and steering knuckle	FA-8
Wheel sensors (ABS).....	BR-26
Wheelarch height.....	FA-5
Wide open & closed throttle position switch.....	EC-128
WINDOW - Wiring diagram	EL-208
Window antenna	EL-136
Windshield	BT-35
WIPER - Wiring diagram	EL-104
Wiper and washer.....	EL-102
Wiper, front	EL-102
Withdrawal lever (clutch)	CL-8
Wrist pin - See Piston pin inspection	EM-55

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX